

WISeNeT

4/16-KANALIGER NETZWERK- VIDEO-ENCODER

Benutzerhandbuch

SPE-410/1610



4/16-kanaliger Netzwerk-Video-Encoder

Benutzerhandbuch

Copyright

©2019 Hanwha Techwin Co., Ltd. Alle Rechte vorbehalten.

Handelsmarke

Alle Marken in diesem Dokument sind registriert. Der Name dieses Produkts und andere Marken in diesem Handbuch gelten als eingetragenes Warenzeichen der jeweiligen Unternehmen.

Richtlinien

Alle Rechte dieses Dokuments sind vorbehalten. Unter keinen Umständen darf dieses Dokument reproduziert, verteilt oder ganz oder teilweise ohne ausdrückliche Genehmigung modifiziert werden.

Haftungsausschluss

Hanwha Techwin ist bemüht, die Korrektheit Integrität des Inhaltes dieses Dokuments sicherzustellen, wird aber keine Garantie zur Verfügung gestellt. Die Verwendung dieses Dokuments und der darauffolgenden Ergebnisse erfolgt auf alleinige Verantwortung des Benutzers. Hanwha Techwin behält sich das Recht vor, Änderungen der Dokumenteninhalte ohne vorherige Ankündigung vorzunehmen.

❖ Design und technische Daten können ohne vorherige Ankündigung geändert werden.

❖ Die initiale Administrator-ID ist "Administrator" und das Passwort sollte eingestellt werden, wenn Sie sich das erste Mal anmelden.
Bitte ändern Sie das Passwort alle drei Monate um die persönlichen Daten zu schützen und Schaden infolge Datendiebstahl zu vermeiden.
Beachten Sie bitte, der Benutzer ist für die Sicherheit und alle weiteren Probleme, die sich aus einem Missmanagement des Passworts ergeben verantwortlich.

WICHTIGE SICHERHEITSHINWEISE

1. Lesen Sie diese Anweisungen.
2. Bewahren Sie sie auf.
3. Beachten Sie alle Warnungen.
4. Befolgen Sie alle Anweisungen.
5. Verwenden Sie dieses Gerät nicht in der Nähe von Wasser.
6. Die verunreinigte Stelle auf der Produktoberfläche mit einem weichen, trockenen oder feuchten Tuch reinigen. (Keine Reinigungs- oder kosmetischen Mittel verwenden, die Alkohol, Lösungsmittel oder Ölbestandteile enthalten, da diese das Produkt deformieren oder schädigen können.)
7. Blockieren Sie keine Belüftungsöffnungen. Installieren Sie es gemäß den Herstelleranweisungen.
8. Installieren Sie das Gerät nicht in der Nähe von Wärmequellen wie beispielsweise von Radiatoren, Heizkörpern oder anderen Geräten (einschließlich Verstärkern), die Wärme erzeugen.
9. Bitte achten Sie darauf, die Schutzvorrichtung des gepolten bzw. geerdeten Steckers nicht zu beschädigen. Ein gepolter Stecker verfügt über zwei Stifte, von denen einer breiter als der andere ist. Ein geerdeter Stecker hat zwei Stifte und einen Erdungsstift. Der breite Stift oder der dritte Stift ist für Ihre Sicherheit vorgesehen. Wenn der vorgesehene Stecker nicht in Ihre Steckdose passt, wenden Sie sich an einen Elektriker, um die veraltete Steckdose austauschen zu lassen.
10. Schützen Sie das Netzkabel so, dass nicht darauf getreten wird, und dass es insbesondere an den Steckern oder passenden Steckdosen bzw. der Stelle, an der das Kabel das Gerät verlässt, nicht abgeklemmt wird.
11. Verwenden Sie nur die vom Hersteller angegebenen Zusatzgeräte/Zubehörteile.
12. Verwenden Sie für das Gerät nur Gestelle, Ständer, Stative, Konsolen und Tische, die vom Hersteller empfohlen oder in Verbindung mit dem Gerät verkauft werden. Bei Verwendung eines Transportwagens bewegen Sie das Gerät nur mit äußerster Vorsicht, um Verletzungen durch Umkippen zu vermeiden.
13. Trennen Sie das Gerät bei Gewitter oder längerer Abwesenheit vom Stromnetz.
14. Überlassen Sie alle Wartungsarbeiten qualifiziertem Kundendienstpersonal. Wartungsarbeiten sind erforderlich, wenn das Gerät in irgendeiner Weise beschädigt wurde, wie zum Beispiel ein beschädigtes Netzkabel oder Stecker, verschüttete Flüssigkeiten oder Gegenstände, die in das Gerät gefallen sind, das Gerät Regen oder Feuchtigkeit ausgesetzt wurde, nicht normal funktioniert oder fallen gelassen wurde.
15. Dieses Produkt soll mit einem aufgelisteten Netzteil geliefert werden, welches als „Klasse 2“ oder „LPS“ gekennzeichnet und mit 12 Vdc, min. 0,8 A oder PoE (37 V~57 V), min. 0,28 A. (SPE-410) ausgelegt wurde.
16. Falls Sie beim Installieren des Produkts zu viel Kraft anwenden, kann der Encoder beschädigt werden und eine Fehlfunktion verursachen. Falls Sie das Produkt mit nicht konformen Werkzeugen installieren, kann das Produkt beschädigt werden.
17. Stellen Sie das Produkt nicht an Orten auf, an denen chemische Stoffe oder Ölnebel vorhanden sind oder entstehen können. Da Speiseöle wie Sojaöl das Produkt beschädigen oder verwerfen können, darf das Produkt nicht in der Küche oder in der Nähe des Küchentisches installiert werden. Dies kann zu Schäden am Produkt führen.
18. Achten Sie beim Einbau des Produkts darauf, dass die Oberfläche des Produkts nicht mit chemischer Substanz gefärbt wird. Einige chemische Lösungsmittel wie Reiniger oder Klebstoffe können schwere Schäden an der Oberfläche des Produkts verursachen.
19. Wenn Sie das Produkt in einer nicht empfohlene Weise installieren oder demontieren, können die Produktionsfunktionen / Leistung nicht garantiert werden. Installieren Sie das Produkt unter "Installation und Anschluss (Installation and connection)" in der Bedienungsanleitung.
20. Installation oder Verwendung des Produkts ins Wasser kann zu ernsthaften Schäden am Produkt führen.



WARNUNG

SETZEN SIE DIESES GERÄT NICHT REGEN ODER FEUCHTIGKEIT AUS, UM DIE GEFAHR EINES BRANDS ODER ELEKTROSCHOCKS ZU REDUZIEREN. STECKEN SIE KEINE METALLGEGENSTÄNDE DURCH DIE BELÜFTUNGSSCHLITZE ODER ANDERE ÖFFNUNGEN DER AUSRÜSTUNG.

Schützen Sie das Gerät vor Flüssigkeitsspritzern und Tropfen. Stellen Sie keine mit Flüssigkeiten gefüllten Behälter auf dem Gerät ab (z. B. Vasen).

Zur Vermeidung von Verletzungen muss das Gerät gemäß der Montageanleitung sicher an der Wand oder Decken befestigt werden.

VORSICHT

	VORSICHT GEFAHR EINES ELEKTROSCHOCKS NICHT ÖFFNEN	
VORSICHT : NICHT DIE RÜCKSEITIGE ABDECKUNG ÖFFNEN, ABDECKUNG (ODER RÜCKSEITE) NICHT ABNEHMEN. KEINE VOM BENUTZER ZU WARTENDE TEILE INNEN. WENDEN SIE SICH AN QUALIFIZIERTES KUNDENDIENSTPERSONAL.		

ERKLÄRUNG DER GRAPHISCHEN SYMBOLE



Das Blitzsymbol im gleichseitigen Dreieck warnt den Benutzer davor, dass im Inneren des Produkts nicht isolierte, „gefährliche Spannungen“ anliegen. Dies kann zu einem elektrischen Schlag führen und stellt eine ernsthafte Verletzungsgefahr dar.



Das Ausrufezeichen im gleichseitigen Dreieck soll Benutzer darauf hinweisen, dass die zum Lieferumfang des Produkts gehörende Dokumentation wichtige Bedienungs- und Instandhaltungsanweisungen (Reparaturanweisungen) enthält.

Klasse I nbauart

Ein Gerät der KLASSE I sollte nur an einen NETZ-Anschluss mit Schutzerdung angeschlossen werden.

Akku

Akkus (Akkusatz oder eingelegerter Akku) dürfen keiner extremen Hitze, z. B. Sonneneinstrahlung, Feuer oder Ähnlichem, ausgesetzt werden.

Trennung des Geräts

Trennen Sie den Hauptstecker vom Gerät, wenn dieser beschädigt ist. Und wenden Sie sich bitte für die Reparatur an einen Fachmann in Ihrer Nähe.

Außerhalb der USA könnte ein HAR-Code verwendet werden. Eine Fachwerkstatt wird mit Zubehör einer Fachwerkstatt beauftragt.

ACHTUNG

Wird die Batterie nicht mit der richtigen Batterie ausgetauscht, besteht Explosionsgefahr. Entsorgen Sie gebrauchte Batterien vorschriftsgemäß.

Diese Hinweise zur Wartung und Reparatur gelten nur für qualifiziertes Kundendienstpersonal. Um die Gefahr von Stromschlägen zu verringern, führen Sie nur die Reparaturen aus, die in der Bedienungsanleitung enthalten sind. Überlassen Sie alle weiterführenden Reparaturarbeiten qualifiziertem Personal.

Der HDMI-Ausgang des Produkts ist für eine vereinfachte Installation vorgesehen und wird nicht für Überwachungszwecke empfohlen.

Bitte verwenden Sie die Eingangsleistung nur für einen Encoder. Weitere Geräte dürfen nicht angeschlossen werden.

Der ITE darf nur mit PoE-Netzwerken und ohne Routing zur äußeren Anlage verbunden werden.

Lesen Sie die folgenden empfohlenen Sicherheitsmaßnahmen sorgfältig durch.

- Stellen Sie das Gerät nicht auf eine unebene Fläche.
- Setzen Sie das Gerät keiner direkten Sonneneinstrahlung aus, stellen Sie es nicht in der Nähe von Heizgeräten oder in sehr kalten Bereichen auf.
- Das Gerät nicht in der Nähe von leitendem Material aufstellen.
- Versuchen Sie auf keinen Fall, selbst Reparaturarbeiten auszuführen.
- Stellen Sie kein Glas Wasser auf das Produkt.
- Stellen Sie das Gerät nicht in der Nähe einer magnetischen Quelle auf.
- Blockieren Sie nicht die Belüftungsöffnungen.
- Legen Sie keine schweren Gegenstände auf das Produkt.
- Tragen Sie bei der Montage/Demontage des Encoders Schutzhandschuhe. Die hohe Temperatur der Produktoberfläche könnte zu Verbrennungen führen.

Das Benutzerhandbuch ist ein Anleitungsbuch zur Art der Verwendung von Produkten.

Die Verwendungshinweise im Handbuch bedeuten folgendes.

- Referenz : Im Falle einer weiterleitenden Information als Hilfe bei der Produktverwendung
 - Hinweis : Wenn die Möglichkeit besteht, dass Güter oder Menschen durch das Nichtbefolgen der Anleitung zu Schaden kommen
- ※ Bitte lesen Sie das vorliegende Benutzerhandbuch zur eigenen Sicherheit vor der Verwendung von Gütern sorgfältig durch, und heben Sie es an einem sicheren Ort auf.

VOR DEM START

Diese Bedienungsanleitung stellt Informationen für den Betrieb bereit, die für die Nutzung des Geräts erforderlich sind.

Darüber hinaus enthält es eine Beschreibung aller Bestandteile und Funktionen sowie über das Menü und die Netzwerkeinstellungen.

Sie müssen folgende Hinweise berücksichtigen:

- Hanwha Techwin bewahrt sich das Urheberrecht auf diese Anleitung vor.
- Diese Anleitung darf ohne das vorherige, schriftliche Einverständnis von Hanwha Techwin nicht vervielfältigt werden.
- Wir haften nicht für irgendwelche oder alle Schäden am Gerät, die durch die Verwendung eines nicht standardmäßigen Produktes oder eines Verstoßes gegen die in dieser Anleitung aufgeführten Anweisungen, anfallen.
- Wenn Sie das Gerät wegen der Überprüfung eines Problems öffnen möchten, wenden Sie sich bitte an einen Fachmann in dem Geschäft, in dem Sie das Produkt erworben haben.

Warnung

Batterie

Ein falscher Batterietausch in Ihrem Gerät kann zu einer Explosion führen. Deshalb müssen Sie denselben Batterietyp verwenden, wie der im Gerät verwendete.

Nachfolgend die Spezifikationen der Batterie, die Sie gerade verwenden.

- Normalspannung: 3 V
- Normalleistung: 220 mAh
- Entladestrom: 0,2 mA
- Betriebstemperatur: -30°C ~ +60°C (-22°F ~ +140°F)

Betriebstemperatur

Der garantierte Betriebstemperaturbereich dieses Geräts beträgt

SPE-1610 : -10°C ~ +45°C (14°F ~ 113°F) (-10°C ~ +40°C (14°F ~ 104°F), bei Rack-Installation)

SPE-410 : -10°C ~ 50°C (14°F ~ 122°F).

Das Gerät kann eventuell nicht korrekt funktionieren, wenn Sie es nach einer langen Aufbewahrungszeit bei einer Temperatur unterhalb der garantierten, in Betrieb nehmen.

Wenn Sie das Gerät nach einer langen Aufbewahrungszeit bei niedrigen Temperaturen benutzen, stellen Sie es zuerst einige Zeit bei Raumtemperatur auf und nehmen Sie es dann in Betrieb.

Sicherheitsmaßnahmen

Die Erst Administrator-ID lautet "admin" und das Passwort muss bei der allerersten Anmeldung eingestellt werden.

Ändern Sie Ihr Passwort alle drei Monate, damit persönliche Angaben geschützt sind und Schäden durch Informationsdiebstahl verhindert werden.

Beachten Sie bitte, dass der Benutzer die Verantwortung für die Sicherheit und alle Probleme, die sich aus einem mangelhaften Umgang mit dem Passwort ergeben, trägt.

INHALTE

ÜBERSICHT

3

- 3 Wichtige Sicherheitshinweise
- 5 Vor Dem Start
- 7 Produkt-Funktionen
- 7 Empfohlene PC-Spezifikationen
- 8 Lieferumfang
- 9 Teilebezeichnungen Und Funktionen (Vorderseite)
- 10 Teilebezeichnungen Und Funktionen (Rückseite)

INSTALLATION & VERBINDUNG

11

- 11 Überprüfung Der Installationsumgebung
- 11 Rack-Installation
- 12 Anschluss an Andere Geräte

NETZWERKVERBINDUNG UND KONFIGURATION

16

- 16 Mit dem Netzwerk über Ethernet (10/100/1000BaseT) verbinden
- 16 Den encoder direkt an ein DHCP-basiertes dsl-/kabelmodem anschliessen
- 17 Mit dem Netzwerk über PPPoE verbinden
- 17 Mit dem Netzwerk über den Router verbinden
- 18 Schaltflächen des IP-Installationsprogramms
- 18 Einstellung der Statischen IP
- 20 Einstellung der Dynamischen IP
- 20 Portbereichweiterleitung Konfigurieren (Port Mapping)
- 21 Mit dem encoder von einem gemeinsamen lokalen PC aus verbinden
- 21 Mit dem encoder von einem ferngesteuerten PC über das internet verbinden

WEB VIEWER

22

- 22 Mit dem encoder verbinden
- 23 Passworteinstellung
- 23 Anmelden
- 23 Den Live-Bildschirm Benutzen (Plug-In Freier Web-Viewer)

SETUP-BILDSCHIRM

26

- 26 Konfiguration
- 26 Standard-Einstellungen
- 30 PTZ-Setup
- 31 Video und Audio-Setup
- 32 Netzwerk-Setup
- 36 Ereigniss-Setup
- 39 Konfigurieren der Analyseinstellungen
- 40 System-Setup

ANHANG

42

- 42 Spezifikationen
- 43 Detaillierte unterstützte Spezifikationen des Web Viewers
- 43 Gerätetyp Setup-Guide
- 44 Produktansicht
- 45 Fehlersuche
- 46 Open Source Announcement

PRODUKT-FUNKTIONEN

Dieses Produkt kann Videos mit verschiedenen Auflösungen und Qualitätsstufen gleichzeitig an verschiedene Codecs ausgeben und bietet eine Umgebung, die von einem ferngesteuerten PC über ein Netzwerk überwacht werden kann.

- Bietet einen komfortablen Betrachter
- Videoeingangsklemmen für 4/16 Kanäle
- Unterstützt verschiedenste Auflösungen über das Netzwerk
 - NTSC : 2560x1440, 1920x1080, 1280x720, 928x480, 704x480, 928x240, 704x240, 352x240
 - PAL : 2560x1440, 1920x1080, 1280x720, 928x576, 704x576, 928x288, 704x288, 352x288
- Alarmschnittstelle
- Fernüberwachungsfunktion von Network Viewer, Smart Viewer und Mobile Viewer
- Unterstützt Koaxial- und RS-485-Protokolle
- Manipulationserkennung
- ONVIF Compliance



EMPFOHLENE PC-SPEZIFIKATIONEN

- CPU : Intel(R) Core(TM) i7 3.4 GHz oder höher
- RAM : 8G oder höher
- Unterstützte Betriebssystem : Windows, Mac OS X
- Unterstützte Webbrowser: Google Chrome, MS Edge, MS IE, Firefox (wird nur bei Windows 64bit), Apple Safari (wird nur bei Mac OS X)


Sie können detaillierte Informationen zu verifizierten Betriebssystemen und Browsern im Anhang finden. Einige Funktionen können in unterstützten Browsern ebenfalls eingeschränkt sein.

LIEFERUMFANG


Entnehmen Sie das Produkt aus der Verpackung und positionieren Sie es auf einem ebenen Untergrund oder an seinem Installationsort.
Bitte kontrollieren Sie, ob im Lieferumfang zusätzlich zum Hauptgerät die folgenden Teile inkludiert sind.

- 
- Das Erscheinungsbild der Komponenten kann vom gezeigten Bild abweichen.
 - Zubehörkategorie und Qualität können je nach Verkaufsregion verschieden sein.

SPE-410


		
Netzwerk-Video-Encoder	Leistungsreihenklamme	Garantiekarte (Optional)
		
Bedienungsanleitung oder Kurzanleitung	Blechschaube	Klemmleiste-Anschluss (15 Pin)

SPE-1610

		
Netzwerk-Video-Encoder	Netzteil	Netzkabel
		
Garantiekarte (Optional)	Bedienungsanleitung oder Kurzanleitung	Klemmleiste-Anschluss (8 Pin)
		
Klemmleiste-Anschluss (10 Pin)	Befestigungsschraube der Halterung	Konsole


TEILEBEZEICHNUNGEN UND FUNKTIONEN (VORDERSEITE)

SPE-410



Teilebezeichnungen	Funktionen
1 Videoeingang	Dies ist die Videosignal-Eingangsklemme (BNC-Typ).
2 Audioeingang	Dies ist die Audiosignal-Eingangsklemme (RCA-Buchse) und die optionale Buchse des Audio-Verlängerungskabels.
3 Videoeingangsstatusanzeige	Zeigt den Betriebsstatus jedes Videoeingangskanals an.
4 Initialisierung	Diese Taste wird dazu verwendet, die Encoder-Einstellungen auf die Werkseinstellungen zurückzusetzen. Halten Sie sie für ca. 5 Sekunden gedrückt, um neu zu starten. i Wird der Encoder initialisiert, wird die Netzwerkeinstellung geändert, um DHCP verwenden zu können. Sollte im Netzwerk kein DHCP-Server vorhanden sein, können Sie mit dem IP-Installationsprogramm die grundlegenden Netzwerkeinstellungen (IP-Adresse, Subnetzmaske, Gateway usw.) neu konfigurieren.


SPE-1610



Teilebezeichnungen	Funktionen
1 LED-Lampe	CH#1~#4 : Videoeingangskanäle. Das Licht wird nur dann ausgeschaltet, wenn keines der vier Videosignale verbunden ist.
	CH#5~#8 : Videoeingangskanäle. Das Licht wird nur dann ausgeschaltet, wenn keines der vier Videosignale verbunden ist.
	CH#9~#12 : Videoeingangskanäle. Das Licht wird nur dann ausgeschaltet, wenn keines der vier Videosignale verbunden ist.
	CH#13~#16 : Videoeingangskanäle. Das Licht wird nur dann ausgeschaltet, wenn keines der vier Videosignale verbunden ist.
	NETWORK : Zeigt den Netzwerkverbindungsstatus und den Datenübertragungsstatus an.
	POWER : Zeigt den Netz-EIN-/AUS-Status an.

TEILEBEZEICHNUNGEN UND FUNKTIONEN (RÜCKSEITE)


SPE-410



Teilebezeichnungen	Funktionen
1 Netzwerkverbindung	Dies ist ein Terminal, das über PoE oder Ethernet-Kabel mit dem Netzwerk verbunden ist.
2 DC 12V	Dies ist eine Stromverbindungsklemme für einen Netzwerk-Video-Encoder.
3 LED-Lampe	ALARM : Leuchtet auf, wenn ein Ereignis eintritt. POWER : Zeigt den Netz-EIN-/AUS-Status an.
4 E/A-Klemme * NVR-Kompatibilität ist in Vorbereitung.	RS485 : Wird für die RS-485-Kommunikation verwendet. ALARM IN : Alarmeingangsklemme. (1 bis 4 Kanäle) ALARM OUT : Alarmausgangsklemme. (1 bis 2 Kanäle)
5 Masseverbindung	Ein Eingang zur Verbindung eines separaten Massekabels. ■ Stellen Sie sicher, ein Massekabel zu verwenden, um das Gerät sicher benutzen zu können.
6 KONSOLE	Dies ist die Konsolenverbindungsklemme.
7 HDMI-Videoausgang	Dies ist die Klemme, die für die Überprüfung des Testvideos verwendet wird. Sie können das Testvideo überprüfen, indem Sie es mit dem HDMI-Kabel an das tragbare Display anschließen. ■ Sie können das Video in 4 geteilten Bildschirmen betrachten. Es werden nur FHD-Videos unterstützt.
8 Audioausgang	Dies ist der Videosignal-Ausgangsklemme (RCA-Buchse).

■ [CONSOLE] ist ausschließlich für Servicereparaturen bestimmt.

SPE-1610



Teilebezeichnungen	Funktionen
1 Videoeingang	Dies ist die Videosignal-Eingangsklemme (BNC-Typ).
2 Audioeingang	Dies ist die Audiosignal-Eingangsklemme (RCA-Buchse) und die optionale Buchse des Audio-Verlängerungskabels.
3 Audioausgang	Dies ist der Videosignal-Ausgangsklemme (RCA-Buchse).
4 HDMI-Videoausgang	Dies ist die Klemme, die für die Überprüfung des Testvideos verwendet wird. Sie können das Testvideo überprüfen, indem Sie es mit dem HDMI-Kabel an das tragbare Display anschließen. ■ Sie können das Video in 16 geteilten Bildschirmen betrachten. Es werden nur FHD-Videos unterstützt.
5 Netzwerkverbindung	Dies ist die Netzwerkverbindungsklemme.
6 Initialisierung	Diese Taste wird dazu verwendet, die Encoder-Einstellungen auf die Werkseinstellungen zurückzusetzen. Halten Sie sie für ca. 5 Sekunden gedrückt, um neu zu starten. ■ Wird der Encoder initialisiert, wird die Netzwerkeinstellung geändert, um DHCP verwenden zu können. Sollte im Netzwerk kein DHCP-Server vorhanden sein, können Sie mit dem IP-Installationsprogramm die grundlegenden Netzwerkeinstellungen (IP-Adresse, Subnetzmaske, Gateway usw.) neu konfigurieren.
7 KONSOLE	Dies ist die Konsolenverbindungsklemme.
8 E/A-Klemme * NVR-Kompatibilität ist in Vorbereitung.	RS485 : Wird für die RS-485-Kommunikation verwendet. ALARM IN : Alarmeingangsklemme. (1 bis 16 Kanäle) ALARM OUT : Alarmausgangsklemme. (1 bis 4 Kanäle)
9 Eingangsleistung	Dies ist die Klemme für die Eingangsleistung.

■ [CONSOLE] ist ausschließlich für Servicereparaturen bestimmt.


Vor der Verwendung des Produkts möchten wir Sie über Folgendes informieren.

- Verwenden Sie das Produkt nicht im Freien.
- Achten Sie darauf, dass weder Wasser noch Flüssigkeiten in die Anschlussstelle des Produkts gelangen.
- Setzen Sie das System keinen starken Stößen oder einer großen Krafteinwirkung aus.
- Vermeiden Sie es, den Netzstecker mit voller Kraft herauszuziehen.
- Nehmen Sie das Gerät nicht selbst auseinander.
- Überschreiten Sie nicht die Eingangs-/Ausgangsleistung.
- Verwenden Sie ausschließlich ein geprüftes Netzkabel.
- Für Geräte mit einem geerdeten Eingang verwenden Sie bitte einen geerdeten Netzstecker.

ÜBERPRÜFUNG DER INSTALLATIONSUMGEBUNG

Befolgen Sie bei der Montage des SPE-1610 in einem Schrank die nachfolgenden Anweisungen.

1. Stellen Sie sicher, dass das Innere des Racks nicht abgedichtet ist.
2. Achten Sie darauf, dass Luft durch die Eingänge/Ausgänge – wie im Bild dargestellt – zirkulieren kann.
3. Wenn sie das Gerät oder andere für die Rack-Montage bestimmten Geräte wie in der Abbildung dargestellt übereinander aufstellen, stellen Sie genug Freiraum für die Lüftung sicher oder installieren Sie einen Lüfter.
4. Für den natürlichen Luftaustausch positionieren Sie die Lufteingänge am Boden des Racks und die Ausgänge ganz oben.
5. Es wird dringend empfohlen, beim Lufteingang und -ausgang einen Lüftermotor zu installieren, damit die Luft zirkulieren kann. (Setzen Sie beim Eingang bitte einen Filter ein, um Staub oder Fremdkörper fernzuhalten.)
6. Die Temperatur im Innern des Racks oder der Umgebung, wie in der Abbildung dargestellt, in einem Bereich von -10°C - 40°C (14°F ~ 104°F) halten.




[Abbildung 1]

RACK-INSTALLATION

Montieren Sie die Rack-Halterung wie in der Abbildung dargestellt, dann ziehen Sie die Schrauben an beiden Seiten an (2 Schrauben auf jeder Seite).

- Entfernen Sie vor der Installation die Schrauben an der linken und rechten Seite des Encoders.
- Ziehen Sie die Schrauben an, damit sich diese bei Vibrationen nicht lockern.




ANSCHLUSS AN ANDERE GERÄTE


Verbinden der Kamera

Verbinden Sie den **[VIDEO IN]**-Port des Netzwerk-Video-Encoders mit dem Video-Ausgangsport der Kamera.

SPE-410



SPE-1610



- Der HDMI-Ausgang des Produkts ist für eine vereinfachte Installation vorgesehen und wird nicht für Überwachungszwecke empfohlen.

Ethernet-Verbindung

Verbinden Sie das Ethernetkabel mit dem lokalen Netzwerk oder dem Internet.

Stromversorgung

Verwenden Sie einen Schraubendreher, um jede Leitung (+, -) des Stromkabels mit dem entsprechenden Stromanschluss des Encoders zu verbinden.

- !

 - Bei gleichzeitigem Anschluss an PoE und DC 12V verwendet das Gerät die externe Stromversorgung (DC 12V). (SPE-410)
 - Es kann ebenfalls ein Router mit PoE Funktion für die Stromversorgung der Encoder verwendet werden.
 - Verwenden Sie PoE, das mit den IEEE802.3af Protokollen kompatibel ist.
 - Es wird empfohlen, nur eine einzige Quelle zu verwenden, wenn die Stromversorgung für das Gerät PoE und DC 12V zur Auswahl hat.
 - Achten Sie beim Anschluss des Stromkabels darauf, Plus- und Minuspol nicht zu vertauschen.
 - Wenn ein externes Gerät angeschlossen werden soll, muss das Gerät vor dem Anschließen abgeschaltet werden.
 - Zuerst das Netzteil und das Netzteil des Netzkabels anschließen und dann das Netzkabel an die Steckdose an der Wand anschließen.

Netzkabel-Spezifikation für jedes Modell

Falls der Eingang DC 12V lautet:


Kabeltyp (AWG)	#22	#20	#18
Kabellänge (max.)	24m	38m	60m

Netzwerk-kabel-Spezifikation


Artikel	Inhalte	Anmerkung
Stecker	RJ45 (10/100/1000BASE-T)	
Ethernet	10/100/1000Base-T	Für den Betrieb mit 1000BASE-T muss für den Giga-Hub ein Kabel der Kategorie UTP-6 oder höher verwendet werden.
Kabel	Kategorie 6	
Max. Entfernung	100M	DC-Widerstand ≤ 0,188 Ω/m
PoE Support	IEEE 802.3af	SPE-410

Audio E/A Blockdiagramm

SPE-410



SPE-1610



1. Verbinden Sie den AUDIO IN-Anschluss des Encoders mit dem Mikrofon- oder LINE OUT-Anschluss des Verstärkers, an dem das Mikrofon angeschlossen ist.
2. Verbinden Sie den AUDIO OUT-Anschluss des Encoders mit dem Lautsprecher- oder LINE IN-Anschluss des Verstärkers, an dem der Lautsprecher angeschlossen ist.
3. Überprüfen Sie die Spezifikationen für den Audioeingang.

■ Audio-Eingang ist möglich an Kanal1 bis Kanal4, während Audio-Ausgang nur möglich ist auf Kanal1.

• Audio Codec

- Audioeingang : G.711 PCM (Bitrate: 64kbps / Abtastfrequenz: 8kHz)
- Audioausgang : G.711 PCM (Bitrate: 64kbps / Abtastfrequenz: 8kHz)

• Vollduplex Audio


- **Audio Ein** : Eingang Mono Signalkabel (Max. 1.0 Vpp)
- **Audio Aus** : Ausgabe Mono Signalkabel (Max. 1.0 Vpp)
- **Line out Impedanz** : 600Ω

Anschluss an die I/O-Port-Box

Zum Verbinden des Alarめingangs/Alarめausgangs mit dem entsprechenden Port auf der hinteren Port-Box.

- Wir bereiten die Bereitstellung der Alarめin- und -ausgabefunktion vor, indem wir den Encoder mit dem NVR verbinden. (Sie können es auf der Homepage überprüfen.)


SPE-410



Alarめin- und -ausgänge werden wie nachfolgend dargestellt konfiguriert.

- G : Masseklemme für Alarm
- ALARM OUT 1 : NO(normal offen), COM(Common), NC(normal geschlossen)
- ALARM OUT 2 : NO(normal offen), COM(Common)
- ALARM IN 1 - 4 : Alarめingangsklemme


SPE-1610



Alarmein- und -ausgänge werden wie nachfolgend dargestellt konfiguriert.

- G : Masseklemme für Alarm
- ALARM OUT 1 : NO(normal offen), COM(Common), NC(normal geschlossen)
- ALARM OUT 2 ~ 4 : NO(normal offen), COM(Common)
- ALARM IN 1 ~ 16 : Alarmeingangsklemme

! ■ Das Massesignal des Encoders nicht mit der Versorgung des Alarms verbinden (DC-).



Anschließen des Alarmeingangs

Verbinden Sie ein Signalkabel (von 2) des entsprechenden Sensors mit dem [ALARM IN]-Port, und das andere mit dem [G]-Port.

Anschließen des Alarmausgangs

Verbinden Sie ein Signalkabel (von 2) des entsprechenden externen Gerät mit dem [ALARM OUT]-Port, und das andere mit dem [COM]-Port.

! ■ Sie müssen spezifische RS-485-Alarm-E/A-Anschlüsse für jeden Kanal verwenden.

Mit dem RS-485-Gerät verbinden

Verbinden Sie das externe Gerät an die [RS-485 +, -]-Ports an. Sie können eine PTZ-Kamera anschließen und steuern, welche die RS-485-Kommunikation unterstützt.


- ! ■ Sie können eine PTZ-Kamera anschließen und steuern, welche die RS-485-Kommunikation unterstützt.
- Sie können diese steuern, indem Sie die AUX-Funktion verbinden, welche die RS-485-Kommunikation unterstützt.
- Überprüfen Sie zunächst, ob das RS-485-Gerät mit dem Produkt kompatibel ist.
- Achten Sie darauf, die Polarität (+/-) des RS-485-Geräts beim Anschließen nicht zu vertauschen.
- Weitere Informationen finden Sie in der Dokumentation der jeweiligen Kamera.

Sie können die Netzwerkeinstellungen gemäß Ihrer Netzwerkkonfigurationen einrichten.

MIT DEM NETZWERK ÜBER ETHERNET (10/100/1000BASET) VERBINDEN

Die Verbindung erfolgt über den Netzwerkanschluss auf der Rückseite des Produkts. Die nachfolgende beispielhafte Abbildung zeigt das Produkt SPE-1610.


1. Starten Sie einen Internetbrowser am lokalen PC.
2. Geben Sie die IP-Adresse des Encoders in die Adressleiste des Browsers ein.



- Ein ferngesteuerter PC in einem externen Internet außerhalb des LAN-Netzwerks kann möglicherweise keine Verbindung zum im Intranet installierten Encoder herstellen, wenn immer die Port-Weiterleitung nicht ordnungsgemäß oder eine Firewall festgelegt wurde. Wenden Sie sich in dem Fall zur Lösung des Problems an Ihren Netzwerkadministrator.
- Bei dem IP-Installer können Sie das Anfangspasswort "4321" zum Einstellen der IP-Adresse, Subnet Mask, Gateway, HTTP Port, VNP Port, IP-Typ verwenden. Nach Änderung der Netzwerk-Schnittstelle greifen Sie zwecks besserer Sicherheit auf den Webviewer zu und ändern Sie das Passwort.
- Standardmäßig wird die IP-Adresse vom DHCP-Server automatisch zugeteilt. Wenn keinen DHCP-Server verfügbar ist, wird die IP-Adresse auf 192.168.1.100 gesetzt. Verwenden Sie die IP-Adresse, um den IP-Installer zu ändern. Weitere Informationen zur Verwendung des IP-Installers finden Sie unter „Einstellung der statischen IP“; (Seite 18)

DEN ENCODER DIREKT AN EIN DHCP-BASIERTES DSL-/KABELMODEM ANSCHLIESSEN

Die Verbindung erfolgt über den Netzwerkanschluss auf der Rückseite des Produkts. Die nachfolgende beispielhafte Abbildung zeigt das Produkt SPE-410.




1. Verbinden Sie den Benutzer-PC direkt mit dem Netzwerk-Encoder.
2. Führen Sie das IP-Installationsprogramm aus und ändern Sie die IP-Adresse des Encoders in einer Weise, dass Sie den Webbrowser auf Ihrem Desktop verwenden können, um eine Verbindung zum Internet herzustellen.
3. Verwenden Sie den Webbrowser, um eine Verbindung mit dem Web Viewer herzustellen.
4. Gehen Sie weiter zur **[Setup]** Seite.
5. Gehen Sie weiter zum **[Netzwerk] – [DDNS]** und konfigurieren Sie die DDNS-Einstellungen.
6. Zu **[Basic] – [IP & Port]** navigieren und den IP-Typ auf **[DHCP]** einstellen.
7. Verbinden Sie den von Ihrem PC getrennten Encoder direkt mit dem Modem.
8. Starten Sie den Encoder erneut.

- Für die Konfiguration der DDNS-Einstellungen, siehe „**DDNS**“; (Seite 32)
- Für das Registrieren der DDNS-Einstellungen, siehe „**Registrierung unter DDNS vornehmen**“; (Seite 32)
- Siehe **"IP & Port"** für Information über das IP-Setup; (Seite 29)

MIT DEM NETZWERK ÜBER PPPoE VERBINDEN

Die Verbindung erfolgt über den Netzwerkanschluss auf der Rückseite des Produkts. Die nachfolgende beispielhafte Abbildung zeigt das Produkt SPE-410.




1. Verbinden Sie den Benutzer-PC direkt mit dem Netzwerk-Encoder.
2. Führen Sie das IP-Installationsprogramm aus und ändern Sie die IP-Adresse des Encoders in einer Weise, dass Sie den Webbrowser auf Ihrem Desktop verwenden können, um eine Verbindung zum Internet herzustellen.
3. Verwenden Sie den Webbrowser, um eine Verbindung mit dem Web Viewer herzustellen.
4. Gehen Sie weiter zur **[Setup]** Seite.
5. Gehen Sie weiter zum **[Netzwerk]** – **[DDNS]** und konfigurieren Sie die DDNS-Einstellungen.
6. Zu **[Basic]** – **[IP & Port]**-Setup-Seite navigieren und den IP-Typ auf **[PPPoE]** sowie die ID und das Passwort des Netzwerkdienstes eingeben.
7. Verbinden Sie den von Ihrem PC getrennten Encoder direkt mit dem Modem.
8. Starten Sie den Encoder erneut.

- Für die Konfiguration der DDNS-Einstellungen, siehe „**DDNS**“. (Seite 32)
- Für das Registrieren der DDNS-Einstellungen, siehe „**Registrierung unter DDNS vornehmen**“. (Seite 32)
- Siehe „**IP & Port**“ für Information über das IP-Setup. (Seite 29)

MIT DEM NETZWERK ÜBER DEN ROUTER VERBINDEN

Das ist für eine kleine Netzwerkumgebung wie zum Beispiel Eigenheime, SOHO und gewöhnliche Geschäfte. Die Verbindung erfolgt über den Netzwerkanschluss auf der Rückseite des Produkts. Die nachfolgende beispielhafte Abbildung zeigt das Produkt SPE-410.




Konfigurieren der Netzwerkeinstellungen des an einen Breitband-Router

Befolgen Sie die nachfolgenden Anweisungen zur Konfiguration der Netzwerkeinstellungen des an einen Breitband-Router angeschlossenen lokalen PCs.

- Wählen Sie : **<Network>** → **<Properties>** → **<Local Area Connection>** → **<General>** → **<Properties>** → **<Internet Protocol (TCP/IP)>** → **<Properties>** → **<Obtain an IP address automatically>** oder **<Use the following IP address>**.
- Befolgen Sie die nachfolgenden Anweisungen bei der Auswahl von **<Use the following IP address>**:
 - bsp1) Wenn die Adresse (LAN IP)des Breitband-Routers 192.168.1.1 ist
 IP-Adresse : 192.168.1.100
 Subnetz Maske : 255.255.255.0
 Standard Gateway : 192.168.1.1
 - bsp2) Wenn die Adresse (LAN IP)des Breitband-Routers 192.168.0.1 ist
 IP-Adresse : 192.168.0.100
 Subnetz Maske : 255.255.255.0
 Standard Gateway : 192.168.0.1
 - bsp3) Wenn die Adresse (LAN IP)des Breitband-Routers 192.168.xxx.1 ist
 IP-Adresse : 192.168.xxx.100
 Subnetz Maske : 255.255.255.0
 Standard Gateway : 192.168.xxx.1
- Sehen Sie bezüglich der Adresse des Breitband-Routers in der Dokumentation des Gerätes nach.
- Für weitere Informationen über die Portweiterleitung des Breitband Routers, bitte unter **„Portbereichweiterleitung Konfigurieren (Port Mapping)“** nachschlagen. (Seite 20)

SCHALTFLÄCHEN DES IP-INSTALLATIONSPROGRAMMS



Bezeichnung	Beschreibung
1 Device Name	Modellname der verbundenen Encoders. Klicken Sie auf die Spalte, um die Liste nach Modellnamen zu sortieren. Wenn Sie jedoch während einer Suche darauf klicken, wird die Suche gestoppt.
2 Alias	Diese Funktion steht zurzeit nicht zur Verfügung.
3 Mode	Für den aktuellen Verbindungsstatus des Netzwerkes wird entweder <Static>, <Dynamic> oder <PPPoE> angezeigt.
4 MAC(Ethernet) Address	Ethernet-Adresse für den angeschlossenen Encoder. Klicken Sie auf die Spalte, um die Liste nach Ethernetadressen zu sortieren. Wenn Sie jedoch während einer Suche darauf klicken, wird die Suche gestoppt.
5 IP Address	IP-Adresse. Klicken Sie auf die Spalte, um die Liste nach IP-Adressen zu sortieren. Wenn Sie jedoch während einer Suche darauf klicken, wird die Suche gestoppt.
6 Protocol	Netzwerkeinstellung für den Encoder. Standardmäßig ist „IPv4“ eingestellt. Encoder mit IPv6-Einstellung werden als „IPv6“ angezeigt.
7 URL	DDNS URL-Adresse für den externen Zugriff vom Internet aus. Dies wird jedoch durch die <IP Address> des Encoders ersetzt, falls die DDNS-Registrierung fehlschlägt.
8 IPv4	Scannt nach Encodern mit IPv4-Einstellung.

Bezeichnung	Beschreibung
9 IPv6	Scannt nach Encodern mit IPv6-Einstellung. Ist nur in einer IPv6 kompatiblen Umgebung aktiviert.
10 Search	Scannt nach Encodern, die derzeit mit dem Netzwerk verbunden sind. Wenn weder IPv4 noch IPv6 aktiviert sind, wird diese Schaltfläche grau dargestellt.
11 Auto Set	Der IP-Installer konfiguriert die Netzwerkeinstellungen automatisch.
12 Manual Set	Sie müssen die Netzwerkeinstellungen manuell vornehmen.
13 Exit	Damit wird das IP-Installationsprogramm beendet.

- Bei der Installation des IP-Installers nur das auf der Installations-CD gelieferte Installationsprogramm oder, falls vorhanden, die neueste Version verwenden. Die neueste Softwareversion kann von der Hanwha Techwin Electronics-Website heruntergeladen werden.
- Wenn das unterstützte Betriebssystem Windows 8.1 ist, wird es empfohlen, den Wisenet Device Manager anstelle des IP Wisenet zu verwenden.
Das Wisenet Device Manager Programm kann auf der Website von Hanwha Techwin (<http://www.hanwha-security.com>) unter dem Menüpunkt <Technisches Handbuch> - <Online-Werkzeug> heruntergeladen werden.


EINSTELLUNG DER STATISCHEN IP

Manuelle Netzwerkeinstellung


Führen Sie <IP Installer_v2.XX.exe> aus, um die Suchliste für Encoder anzuzeigen.
Anfangs werden sowohl [Auto Set] als auch [Manual Set] grau dargestellt.

- Werden Encoder mit IPv6-Einstellung gefunden, werden diese Tasten ausgegraut, da die Encoder diese Funktion nicht unterstützen.

- Wählen Sie einen Encoder in der Suchliste aus.
Überprüfen Sie die MAC-Adresse, die sich auf dem Aufkleber am Encoder befindet.
Die Schaltflächen [Auto Set] und [Manual Set] sind nun aktiviert.
- Klicken Sie auf [Manual Set].
Das Dialogfenster für die Manual Setting erscheint.
<IP Address>, <Subnet Mask>, <Gateway>, <HTTP Port>, und <VNP Port> des Encoders werden in den Voreinstellungswerten angezeigt.



- Geben Sie die nötigen Informationen in dem Fenster <Address> an.
 - MAC Address : Die MAC-Adresse muss nicht eingestellt werden, da sie voreingestellt und auf dem am Encoder befestigten Aufkleber angezeigt wird.



- Auf das IP bezogene Parameter lassen sich nur einstellen, wenn DHCP nicht aktiviert ist.

Wenn Sie keinen Breitband-Router verwenden


Kontaktieren Sie ihren Netzwerkadministrator für die Einstellung der <IP Address>, <Subnet Mask> und für das <Gateway>.

- Geben Sie die nötigen Informationen in dem Fenster <Port> an.

- HTTP Port : Wird für den Zugriff auf den Encoder über den Internetbrowser verwendet.
- VNP Port : Wird verwendet, um die Videosignalübertragung zu steuern. Der Standardwert lautet 4520.

- Geben Sie das Kennwort ein.

Geben Sie das Passwort des „admin“-Kontos ein, das für den Zugriff auf den Encoder verwendet wurde.




- Es wird empfohlen, dass Sie für Ihr Passwort aus Sicherheitsgründen eine Kombination aus Zahlen, alphabetischen Groß- und Kleinbuchstaben und Sonderzeichen verwenden.
- Wenn das Passwort geändert werden soll, bitte unter „Administrator-Kennwort Ändern“ im Benutzer Setup nachschlagen. (Seite 28)

- Klicken Sie auf [OK].

Die manuelle Netzwerkeinstellung ist beendet.

Bei Verwendung eines Breitband-Routers

- IP Address : Geben Sie eine Adresse ein, die sich im IP-Bereich des Breitband-Routers befindet.
bsp) 192.168.1.2~254, 192.168.0.2~254, 192.168.XXX.2~254
- Subnet Mask : Die <Subnet Mask> des Breitbandrouters wird zur <Subnet Mask> des Encoders.
- Gateway : Die <Local IP Address> des Breitbandrouters wird zum <Local IP Address> des Encoders.



<Beispiel für einen Router>

- Die Netzwerkeinstellungen können sich je nach verbundenem Breitband-Router modell unterscheiden.
Für mehr Informationen, lesen Sie im Benutzerhandbuch des Routers nach.
- Für weitere Informationen über die Portweiterleitung des Breitband Routers, bitte unter „Portbereichweiterleitung Konfigurieren (Port Mapping)“ nachschlagen. (Seite 20)

Falls der Breitband-Router mehr als einen Encoder angeschlossen hat

Konfigurieren Sie die IP- und Port-Einstellungen für jede Kamera einzeln und in Übereinstimmung mit den anderen.

bsp)

Kategorie		Encoder #1	Encoder #2
IP-Einstellungen	IP Address	192.168.1.100	192.168.1.101
	Subnet Mask	255.255.255.0	255.255.255.0
	Gateway	192.168.1.1	192.168.1.1
Port-Einstellungen	HTTP Port	8080	8081
	VNP Port	4520	4521


- Falls <HTTP port> nicht auf 80 eingestellt wird, müssen sie die <Port>-Nummer in der Adressleiste des Internetbrowsers bereitstellen, um einen Zugang zum Encoder zu bekommen.
bsp) http://IP-Adresse: HTTP-Port
http://192.168.1.100:8080

Automatische Netzwerkeinstellung

Führen Sie <IP Installer_v2.XX.exe> aus, um die Suchliste für Encoder anzuzeigen.
Anfangs werden sowohl [Auto Set] als auch [Manual Set] grau dargestellt.


- Werden Encoder mit IPv6-Einstellung gefunden, werden diese Tasten ausgegraut, da die Encoder diese Funktion nicht unterstützen.

- Wählen Sie einen Encoder in der Suchliste aus.
Überprüfen Sie die MAC-Adresse, die sich auf dem Aufkleber am Encoder befindet.
Die Schaltflächen [Auto Set] und [Manual Set] sind nun aktiviert.



- Klicken Sie auf [Auto Set].
Das Dialogfenster für die Auto Setting erscheint.
Die <IP Address>, <Subnet Mask> und das <Gateway> werden automatisch eingerichtet.

- Geben Sie das Kennwort ein.
Geben Sie das Passwort des „admin“-Kontos ein, das für den Zugriff auf den Encoder verwendet wurde.



- Es wird empfohlen, dass Sie für Ihr Passwort aus Sicherheitsgründen eine Kombination aus Zahlen, alphabetischen Groß- und Kleinbuchstaben und Sonderzeichen verwenden.
- Wenn das Passwort geändert werden soll, bitte unter „Administrator-Kennwort Ändern“ im Benutzer Setup nachschlagen. (Seite 28)

- Klicken Sie auf [OK].

Die automatische Netzwerkeinstellung ist beendet.


EINSTELLUNG DER DYNAMISCHEN IP

Einstellung der dynamischen IP-Umgebung

- Beispiel einer dynamischen IP-Umgebung
 - Falls einem Breitband-Router mit angeschlossenen Encodern vom DHCP-Server eine IP-Adresse zugewiesen wird
 - Falls der Encoder über die DHCP-Protokolle direkt mit dem Modem verbunden wird
 - Wenn die IP-Adressen von dem internen DHCP-Server über eine LAN-Verbindung zugewiesen werden

Die dynamische IP überprüfen

- Führen Sie den IP-Installer auf dem lokalen Computer des Benutzers aus.
Encoder, denen eine <Dynamic IP>-Adresse zugewiesen wurde, werden in der Liste angezeigt.
- Wählen Sie einen Encoder in der Suchliste aus.
- Klicken Sie auf die [Manual Set]-Taste und überprüfen Sie die <Dynamic IP>-Adresse des Routers.
Wenn die Markierung von <DHCP>, gelöscht wird, kann IP auf <Static> eingestellt werden.




PORTBEREICHWEITERLEITUNG KONFIGURIEREN (PORT MAPPING)

Falls Sie einen Breitband-Router mit angeschlossenen Encoder installiert haben, müssen Sie die Port-Bereichsweiterleitung auf dem Breitband-Router so einstellen, dass ein ferngesteuerter PC auf den darin befindlichen Encoder zugreifen kann.

Manuelle Portbereichsweiterleitung

- Wählen Sie aus dem Einstellungs Menü des Breitband-Routers <Applications & Gaming> - <Port Range Forward>.
Für die Einstellung der Portbereichsweiterleitung eines Breitband-Routers von einem anderen Anbieter lesen Sie die Bedienungsanleitung dieses Breitband-Routers.
- Wählen Sie <TCP> und <UDP Port> für jeden am Breitband-Router angeschlossenen Encoder aus.
Die Nummer jedes Ports, der für den IP-Router konfiguriert werden soll, muss entsprechend der unter <Setup> - <Basic> - <IP & Port> zugewiesenen Portnummer des Encoder-Webviewers festgelegt werden.



<Beispiel für einen Router>

- Wenn Sie fertig sind, klicken Sie auf [Save Settings].
Ihre Einstellungen werden gespeichert.




- Die oben Beispielanweisungen basieren auf dem CISCO's Breitband-Router.
- Die Netzwerkeinstellungen können sich je nach Breitband-Routermodell unterscheiden.
Für mehr Informationen, lesen Sie im Benutzerhandbuch des Routers nach.

Einrichten des Port-Bereichs für eine Weiterleitung für mehrere Netzwerk-Encoder

- Sie können auf dem Breitband-Router-Gerät durch seine Webseitekonfiguration Portweiterleitung-Richtlinien setzen.
- Ein Benutzer kann jeden Port im Encoder-Einstellbildschirm ändern.


Falls Encoder1 und Encoder2 mit einem Router verbunden sind:



- Die Port-Weiterleitung lässt sich ohne zusätzliche Router-Einstellung vornehmen, wenn der Router die UPnP (Universal Plug and Play) Funktion unterstützt.
Nachdem Sie den Netzwerk-Encoder angeschlossen haben, aktivieren Sie den Kontrollkästchen im Menü <Schnelle Verbindung> in <Wissenet-DDNS> in „Einstellungen -> Netzwerk -> DDNS“.

MIT DEM ENCODER VON EINEM GEMEINSAMEN LOKALEN PC AUS VERBINDEN

1. Führen den IP-Installer aus.
Es scannt nach angeschlossenen Encodern und zeigt sie in einer Liste an.
2. Doppelklicken Sie auf einen Encoder, um ihn zu öffnen.
Der Internetbrowser startet und stellt eine Verbindung mit dem Encoder her.



- Einen Zugriff auf den Encoder kann auch durch Eingabe der IP-Adresse des Encoders in der Adressleiste des Internetbrowsers erhalten werden.

MIT DEM ENCODER VON EINEM FERNGESTEUERTEN PC ÜBER DAS INTERNET VERBINDEN

Da die Verwendung des IP-Installationsprogramms auf einem ferngesteuerten Computer, der nicht im Netzwerk-Cluster des Breitbandrouters enthalten ist, unzulässig ist, können Benutzer mithilfe der DDNS-URL eines Encoders auf Encoder im Netzwerk eines Breitbandrouters zugreifen.


1. Bevor Sie auf einen Encoder im Breitband-Router-Netzwerk zugreifen können, müssen Sie den Port-Bereich für eine Weiterleitung für den Breitband-Router festlegen.
2. Starten Sie den Internet-Browser auf dem ferngesteuerten PC und geben Sie die DDNS-URL-Adresse des Encoders oder die IP-Adresse des Breitbandrouters in die Adressleiste ein.
bsp) <http://ddns.hanwha-security.com/ID>

- Für das Registrieren der DDNS-Einstellungen, siehe „Registrierung unter DDNS vornehmen“. (Seite 32)

MIT DEM ENCODER VERBINDEN

Sie würden, normalerweise

1. Starten Sie den Internetbrowser.
2. Geben Sie den Typ der IP-Adresse des Encoders in die Adressleiste ein.
 bsp) • IP Adresse (IPv4) : 192.168.1.100 →
 http://192.168.1.100
 - Der Anmeldedialog sollte erscheinen.
 • IP Adresse (IPv6) : 2001:230:abcd:ffff:0000:0000:ffff:1111
 → http://[2001:230:abcd:ffff:0000:0000:ffff:1111] - Der Anmeldedialog sollte erscheinen.



Falls die Nummer des HTTP-Ports nicht 80 ist

1. Starten Sie den Internetbrowser.
2. Geben Sie in die Adressleiste des Browsers die IP-Adresse und die HTTP-Portnummer ein.
 bsp) IP Adresse: 192.168.1.100:HTTP-Portnummer(8080)
 → http://192.168.1.100:8080 - Der Anmeldedialog sollte erscheinen.

URL Benutzen

1. Starten Sie den Internetbrowser.
2. Geben Sie die DDNS URL des Encoders in die Adressleiste ein.
 bsp) URL-Adresse: http://ddns.hanwha-security.com/ID
 - Der Anmeldedialog sollte erscheinen.



■ Die Netzwerkverbindung ist in der nur LAN-Umgebung deaktiviert.

Verbindung über UPnP

1. Das Kunden- oder Betriebssystem zur Unterstützung des UPnP-Protokolls ausführen.
2. Klicken Sie für eine Suche auf den Encoder-Namen.
 Klicken Sie im Windows-Betriebssystem auf den Namen des Encoders, der im Netzwerkmenü gefunden wurde.
 - Das Fenster Anmelden wird angezeigt.

Verbindung über Bonjour

1. Das Kunden- oder Betriebssystem zur Unterstützung des Bonjour- Protokolls ausführen.
2. Klicken Sie für eine Suche auf den Encoder-Namen.
 Klicken Sie im Mac-Betriebssystem auf den Namen des Encoders, der über den Bonjour-Tab von Safari gefunden wurde.
 - Das Fenster Anmelden wird angezeigt.

So überprüfen Sie die DDNS-Adresse

Falls der Encoder entweder mit dem DHCP-Kabelmodem, dem DSL-Modem oder dem PPPoE-Modem verbunden wurde, wird die IP-Adresse Ihres Netzwerks immer dann geändert, wenn Sie versuchen, eine Verbindung mit dem ISP-Server (Internet Service Provider) herzustellen.


In diesem Fall werden Sie nicht über die durch DDNS geänderte IP-Adresse informiert.

Sobald Sie ein auf dynamischer IP basierendes Gerät beim DDNS-Server registrieren, können Sie die geänderte IP-Adresse einfach überprüfen, wenn Sie versuchen auf das Gerät zuzugreifen.

Um das Gerät auf dem <DDNS> Server zu registrieren, besuchen Sie bitte <http://ddns.hanwha-security.com>, registrieren Sie zuerst Ihr Gerät stellen Sie anschließend im Net Viewer unter <Netzwerk> - <DDNS> auf <Wisenet DDNS> und geben Sie ebenfalls die <Produkt-ID> ein, die Sie bei der DDNS-Registrierung verwendet haben.

PASSWORTEINSTELLUNG

Beim ersten Zugriff auf das Produkt, müssen Sie das Anmelde-Passwort registrieren. Beim Erscheinen des Fensters **"Passwort ändern"**, ein neues Passwort eingeben.




- Für ein neues Passwort mit 8 bis 9 Ziffern müssen Sie mindestens drei der Folgenden verwenden: Groß-/Kleinbuchstaben, Zahlen und Sonderzeichen. Für ein Passwort mit 10 bis 15 Ziffern müssen Sie mindestens zwei dieser Zeichentypen verwenden.
 - Zulässige Sonderzeichen sind: ~!@#\$%^&*()_+=|{}[]?/
- Zur erhöhten Sicherheit wird empfohlen, nicht die gleichen Zeichen oder aufeinanderfolgende Eingaben der Tastatur zu wiederholen.
- Falls Sie Ihr Passwort vergessen haben, können Sie die Schaltfläche **[RESET]** drücken und das Produkt initialisieren. Verwenden Sie ein Memo-Pad oder merken Sie sich Ihr Passwort.

ANMELDEN


Immer wenn Sie auf den Encoder zugreifen, wird das Anmeldefenster erscheinen. Um auf das Produkt zuzugreifen, geben Sie die Benutzer-ID und das Passwort ein.

1. Geben Sie „**admin**“ in das **<User name>** Eingabefeld ein. Die Administrator ID, „**admin**“, kann nicht verändert werden.
2. Geben Sie das Passwort in dem Eingabefeld **<Password>** ein.
3. Klicken Sie auf **[OK]**. Wenn Sie sich erfolgreich angemeldet haben, werden Sie den Live Viewer Bildschirm sehen.



- Achten Sie beim Zugriff auf den Encoder-Webviewer besonders auf die Sicherheit, indem Sie nachprüfen, ob die Bilddaten verschlüsselt sind.
- Wenn Sie die Option **„Remember my credentials“** wählen, nachdem Ihre Eingabe beendet ist, werden Sie automatisch angemeldet ohne zukünftig aufgefordert zu werden, Ihre Anmeldedaten einzugeben.
- Die beste Bildqualität wird erreicht, wenn die Bildschirmgröße auf 100% eingestellt ist. Reduzierung des Bildseitenverhältnis kann das Bild an den Rändern abschneiden.

DEN LIVE-BILDSCHIRM BENUTZEN (PLUG-IN FREIER WEB-VIEWER)



Bezeichnung	Beschreibung
1 Live	Wechselt zum Live-Bildschirm.
2 Setup	Gehen Sie zum Setup-Bildschirm.
3 Viewer-Bildschirm	Gibt das Live-Video auf dem Bildschirm wieder. ■ Sie können das Mausexplorer verwenden, um den Digitalzoom auf dem Viewer Bildschirm zu aktivieren.
4 Onlinehilfe	Die Online-Hilfe bietet detaillierte Beschreibungen für jede Funktion.
5 Kanalwechsel	Legt den Kamerakanal fest, der auf dem Live-Bildschirm angezeigt werden sollen. (Einzelbildschirm / 4-fach unterteilter Bildschirm)

Bezeichnung	Beschreibung	
6 Profiltyp	Sie können einen Profiltyp in <Video Profil> im <Basic> Setupmenü auswählen. - Klicken Sie auf das Symbol, um den Namen des aktuellen Profils anzuzeigen. i ■ Nachbilder lassen sich auf dem Bildschirm unter folgenden Bedingungen angezeigt werden, wenn das Video in der Überwachungsseite abgespielt wird: - Die Auflösung wurde aufgrund einer Profiländerung geändert. - Eingehende Daten werden bei einer Profiländerung durch eine Netzwerkverzögerung verlangsamt. - Die Fenstergröße und -Position vom Webbrowser wurden geändert.	
7 PTZ	PTZ	Steuert die SCHWENKEN/NEIGEN/ZOOM-Bewegung.
	Manueller Fokus ( / )	Stellt den Fokus des Bildschirms auf Nahabstand oder Fernabstand ein.
	Vergrößern ()	Die Leiste auf der rechten Seite der Benutzeroberfläche nach oben ziehen oder auf die Schaltfläche [] klicken, um den Bildschirm zu vergrößern. Je weiter die Stangenposition von der Mitte entfernt ist, desto schneller wird der Bildschirm gezoomt.
	Verkleinern ()	Die Leiste auf der rechten Seite der Benutzeroberfläche nach unten ziehen oder auf die Schaltfläche [] klicken, um den Bildschirm zu verkleinern. Je weiter die Stangenposition von der Mitte entfernt ist, desto schneller wird der Bildschirm herausgezoomt.
	Bildschirm bewegen ()	Bewegt sich in die Richtung, in der sich der Cursor befindet.
8 Profilzugriffsinformation	OSD-Menü	Sie können die Funktionen der angeschlossenen Kamera steuern.
	Sie können die Profilinformation lesen.	
9 Ansichtsmodus ändern	Vollbildschirm ()	Klicken Sie doppelt auf den Videobildschirm, um das aktuelle Video im Vollbildschirm auf dem Monitor abzuspielen.
	An Bildschirm anpassen ()	Ein Ansichtsmodus, bei dem die Größe des Kameravideos automatisch an die Größe des Webbrowsers angepasst wird.
	Größe der Originaldatei ()	Ansichtsmodus, in dem das Video in der tatsächlichen Auflösung abgespielt wird.
	Seitenverhältnis beibehalten ()	Ansichtsmodus, der das Seitenverhältnis anpasst, um die bestmögliche Auflösung zu erzielen.
10 Aufnahme	Speichert das aktuelle Bild als Bilddatei ab.	
11 Pixelzähler	Prüft die Anzahl der Pixel im ausgewählten Bereich des Videobildschirms.	
12 Mikrofonesteuerung	Aktiviert das Mikrofon.	

Bezeichnung	Beschreibung
13 Alarmsignal	Aktiviert den Alarm Ausgang.
14 Audiosteuerung	Aktiviert Audio und passt die Lautstärke an.



- Einige Funktionen funktionieren möglicherweise nicht auf einem bestimmten Browser oder Codec.

Um Kanäle zu wechseln

- Wählen Sie die gewünschte Kanalnummer aus.
 - Klicken Sie auf die [ ,  ,  , ]-Symbole, um einen Kanal für SPE-1610-Modelle auszuwählen.
- Der Betrachterbildschirm zeigt den entsprechenden Kanal an.
- Um den 4-teiligen Bildschirm anzuzeigen, müssen Sie auf das []-Symbol klicken.
- Um zum einzelnen Bildschirm zurückzukehren, müssen Sie auf das []-Symbol klicken.

Den Schnappschuss aufnehmen

- Klicken Sie [Aufnahme ()] auf die Szene um aufzunehmen.
- Wird ein aufgenommenes Video gespeichert, wird eine Meldung angezeigt.
Das aufgenommene Bild wird im dafür vorgesehenen Ordner für jeden Browser gespeichert.



- Wenn der Bildschirm durch den IE-Browser in Windows 7 nicht angezeigt werden kann, sollten Sie den IE-Browser mit Administratorenrechten ausführen.

An den Vollbildschirm anpassen

- Auf das Symbol [Vollbild ()] klicken.
- Dadurch wird der Viewer in den Vollbildschirmmodus gebracht.
- Um den Vollbildmodus zu verlassen, erneut auf [Vollbild ()] klicken oder die [ESC] -Taste auf der Tastatur drücken.

Anwendung von Audio

- Klicken Sie auf das [Audio ()] Symbol, um die Audio Kommunikation einzuschalten.
- Verwenden Sie die [] Leiste, um die Lautstärke einzustellen.



- Gibt es während der Betriebsnahme beim Einstecken und Herausziehen der Audiobuchse keinen Ton, dann klicken Sie auf das [Audio ()] Symbol, um Audio erneut zu aktivieren.
- Um Audio zu verwenden, <Audioeingang> in "Video Profil" auf <Aktivieren> setzen. (Seite 26).

Anwendung des Mikrofons

Klicken Sie auf das **[Mikrofon ()]** Symbol, um das Mikrofon einzuschalten.

Zur Zählung der Pixelanzahl

1. Klicken Sie auf das Symbol **[Pixel zählen ()]** icon to activate it.
2. Ziehen Sie die Maus auf das Video, um den Bereich auszuwählen.
3. Die Pixelanzahl im ausgewählten Bereich wird auf dem Bildschirm angezeigt.

Zur Steuerung von PTZ

1. Auf das Symbol **[PTZ ()]** klicken.
2. Bewegen Sie den Jog-Dial [] auf dem Verschiebe-Bildschirm-Pad, um die Kamerarichtung zu verschieben, oder zoomen Sie ein oder aus, indem Sie den Balken auf der rechten Seite der Benutzeroberfläche nach oben oder unten verschieben.
3. Wählen Sie [ ] im Bildschirmfokus, um den Fokus anzupassen.

Um die Voreinstellung anzuwenden

- Voreinstellung : Wendet die abgespeicherte Voreinstellung an.
Siehe „**Externes PTZ**“ für detaillierte Voreinstellungen. (Seite 30)
 - Bewegen: Wendet die abgespeicherte Voreinstellung an.
 - Einrichtung: Legt die Voreinstellung fest.

So überprüfen Sie den Profilstatus

Sie können die Angaben der Profil überprüfen.

1. Auf das Symbol **[Status ()]** klicken.
2. Der Bildschirm für den Profilzugriff wird aktualisiert, sobald der Bildschirm aktiviert ist.
 - Profil Zugriff : Zeigt die Angaben des neu hinzugefügten Profils an.
 - Profil : Zeigt die Angaben des neu hinzugefügten Codecs an.
 - Bitrate(kbps) : Zeigt sowohl die aktuelle als auch die eingestellte Bitrate an.
 - Bildfrequenz(fps) : Zeigt sowohl die aktuelle als auch die eingestellte Bildfrequenz an.
 - Anzahl der gleichzeitigen benutzer : Zeigt die Anzahl der Benutzer an, die zur gleichen Zeit auf das Profil zugreifen.
 - Aktuelle Benutzer : Zeigt Informationen über die Benutzer an, die auf den Web Viewer zugreifen und Überwachungsvideo anzeigen.
 - Profil : Zeigt den Namen des Profils an, auf das vom Benutzer zugegriffen wird.
 - Bitrate(kbps) : Zeigt die aktuelle Bitrate an.
 - Netzwerk Verbindungsstatus : Das zeigt, ob das Netzwerk ordnungsgemäß funktioniert.
 - IP-Adresse : Zeigt die IP-Adresse des aktuellen Benutzers an.

KONFIGURATION


Sie können die grundlegenden Encoder-Informationen, PTZ-, Video- und Audio-, Netzwerk-, Ereignis-, Analysen-, Systemeinstellungen konfigurieren.

1. Klicken Sie auf dem Live-Bildschirm auf die Schaltfläche [Setup ()].
2. Der Setup-Bildschirm erscheint.

STANDARD-EINSTELLUNGEN


Kameraeingang

1. Wählen Sie die Registerkarte <Basic ()> aus dem Setup-Menü.
2. Klicken Sie <Kameraeingang>.
 - Videotyp : CVBS/AHD/CVI/TVI
 - Auflösung : SD/1M/2M/4M
 - Modus : Auto
 - Audio : Aktivieren/Deaktivieren



Video profil

1. Wählen Sie die Registerkarte <Basic ()> aus dem Setup-Menü.
2. Klicken Sie <Video profil>.
3. Einzustellender Kanal auswählen.
4. Jedes Objekt im Video-Profil einstellen.
Auch wenn die Einstellung des Profils aktuell zugegriffen geändert wird, wird die vorherige Einstellung für die Ausgabe verwendet.
5. Wählen Sie die Profileigenschaften aus.
Lesen Sie für weitere Einzelheiten "Hinzufügen/Ändern beim Videoprofil". (Seite 27)
6. Profiltyp auswählen.
 - Das Kontextmenü kann abhängig vom gewählten Codec-Typ verschieden sein.
 - Standard profil : Wenn bei der Verwendung des Web Viewer kein Profil angegeben wird, wird das Standard Videoprofil verwendet.
 - E-mail/FTP profil : Video-Profil zur festgelegten E-Mail oder FTP-Seite übertragen.
 - Nur der MJPEG Codec kann als das E-mail/FTP Profil festgelegt werden.
7. Wählen Sie aus, ob eine Audiodatei im Video eingegeben wird oder nicht.
Wählen Sie das Kontrollkästchen <Audioeingang>, dann können Sie in das Video eine Audiodatei hinzufügen.
8. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.



Hinzufügen/Ändern beim Videoprofil

Die Profileinstellungen können hinzugefügt oder geändert werden, um je nach den Aufnahmebedingungen verschiedene Profile anzupassen.

1. Klicken Sie im <**Video Profil**>, auf die Schaltfläche <**Hinzufügen**>.
 2. Geben Sie einen Namen und wählen Sie ein Codec aus.
 3. Legen Sie die Umstände fest unter welchen der Codec angewendet werden wird.
 4. Legen Sie die Details des gewählten Codec fest, inklusive Auflösung und Bildwiederholrate.
 - Auflösung : Bestimmen Sie die Videogröße von H.264 und MJPEG Dateien.
 - Bildrate : Die maximale Anzahl der Videobilder pro Sekunde einstellen.
 - Maximale Bitrate : Die maximale Bitrate des Videos festlegen, wenn die Steuerung der Bitrate auf VBR eingestellt ist.
-  ■ Da die Bitrate entsprechend der Auflösung, der Bildfrequenz, und der Bildschirmkomplexität eingestellt werden kann, kann die aktuelle Bitrate höher sein, als die maximale Bitrate. Beachten Sie also diese Bedingungen bei der Einstellung dieses Werts.
- Ziel-Bitrate : Die Zielbitrate festlegen, wenn die Steuerung der Bitrate auf CBR eingestellt ist.
 - Bitrate-Steuerung : Sie können eine der Konstante Bitrate und variable Bitrate für die Komprimierung auswählen. Fixierte Bitfrequenz bedeutet, dass die Netzwerkübertragungsbitfrequenz fixiert ist, während die Qualität des Videos oder Rahmenfrequenz variiert: variable Bitfrequenz bedeutet, dass eine höhere Priorität auf die Videoqualität gelegt wird, während die Bitfrequenz variiert.
-  ■ Wenn Sie nach der Einstellung der fixen Bitrate-Steuerung den Video-Qualitätsprioritätsmodus wählen, kann die tatsächlich übermittelte Bildrate, je nach der Komplexität des Bildschirms, von dem Setup der Bildrate differieren, damit die optimale Videoqualität für die vorhandene Bitrate garantiert werden kann.
- Priorität Kodierung : Sie können die Priorität der Videoübertragung zu Bildfrequenz bzw. Kompression einstellen.
 - GOV Länge : Es gibt den Abstand (in Bezug auf die Anzahl der Bilder) zwischen zwei aufeinander folgenden I-Frames in einer Videosequenz, wenn H.264-Codec ausgewählt wurde. (Eine I-Frame + 0 ~ Mehrere P-Frames)
 - Profil : Das Profil von H.264 Codec kann von Ihnen ausgewählt werden.
 - Entropiekodierung : Dies ist eine variable Längencodierung, welche Syntaxstatistiken verwendet. Es verwendet verlustfreie Kompressionstechniken. Sie können die Entropie-Codierungsmethode festlegen. Die Kompressionsrate von CABAC ist besser als die von CAVLC.

- Multicast (RTSP) : Legen Sie die Benutzung des RTSP-Protokolls fest.
 - IP-Adresse : Geben Sie eine IPv4 Adresse ein, mit der Sie eine Verbindung zum IPv4 Netzwerk herstellen können.
 - Port : Legen Sie den Port für die Videokommunikation fest.
 - TTL : Sie können die TTL für das RTP-Paket festlegen.



- Wenn Sie die Multicast-Adresse bei 224.0.0.0~224.0.0.255 festlegen, wird Multicast eventuell nicht in allen Umgebungen richtig arbeiten. In diesem Falle empfehlen wir Ihnen, die Multicast-Adresse zu ändern.

Was ist die GOV-Länge?

GOV (Group of Video object planes) ist ein Satz an Videobildern für die H.264 Kompression, die eine Sammlung an Einzelbildern vom ersten I-Frame bis zum nächsten I-Frame anzeigt. GOV besteht aus zwei Arten an Einzelbildern I-Frame und P-Frame.

I-Frame ist der Grundrahmen der Komprimierung und enthält Daten für ein abgeschlossenes Einzelbild. P-Frame enthält nur die Daten, die sich seit dem vorhergehenden I-Frame geändert haben.

Was den H.264 Codec betrifft, können Sie die GOV-Länge ermitteln.

Wenn Sie ein Aufnahmeprofil mit H.264 Codec einstellen, wird die GOV-Länge $\text{Framerate}/2$ betragen.

Benutzer

1. Wählen Sie die Registerkarte <Basic (Basic) > aus dem Setup-Menü.

2. Klicken Sie auf <Benutzer>.

3. Geben Sie die nötigen Benutzerinformationen an.

- Administrator-Kennwort Ändern : Ändern Sie das Administrator-Kennwort.




■ Es wird empfohlen, dass Sie für Ihr Passwort aus Sicherheitsgründen eine Kombination aus Zahlen, alphabetischen Groß- und Kleinbuchstaben und Sonderzeichen verwenden.

■ Es wird empfohlen, dass Sie Ihr Passwort alle drei Monate ändern.

■ Die Passwortlänge und Einschränkungen sind wie folgt.

- Eine Kombination aus mindestens drei Typen von Groß- und Kleinbuchstaben, numerischen und Sonderzeichen: 8 bis 9 Zeichen.
- Eine Kombination aus mindesten zwei Arten von Groß- und Kleinbuchstaben, Zahlen und Sonderzeichen: 10-15 Zeichen.
- Sollte anders als die ID sein.
- Nicht 4 oder mehr aufeinanderfolgende Zeichen verwenden. (Beispiele: 1234, abcd)
- Nicht 4 oder mehr Zeichen wiederholt verwenden. (Beispiele: !!!!, 1111, aaaa)
- Zulässige Sonderzeichen sind: ~!@#%&^*()_+=[\]{}.,?/
- Nach der Werkseinstellung werden der Administrator und das Benutzerpasswort initialisiert. Sie müssen das Passwort zurückzusetzen.
- Sie werden, wenn Sie das erste Mal auf die Webseite des Encoders zugreifen oder beim Zugriff nach der Initialisierung zum Administrator-Passwort-Einstellungsmenü geleitet.
- In diesem Menü müssen Sie sich mit dem neuen Passwort erneut anmelden, bevor Sie die Encoder-Webseitenmenüs verwenden können.
- Wenn das vorhandene Passwort nicht übereinstimmt, können Sie durch Ändern des Administratorpassworts das Passwort ändern.
- Falls nach der Änderung Ihres Passworts ein Encoder mit einem CMS- oder NVR-Client verbunden wird, müssen Sie diesen erneut mit dem neu geänderten Passwort registrieren. Falls der Encoder immer noch über das identische Passwort verbunden ist, wird das Konto möglicherweise gesperrt, da ein weiterer Client das vorherige Passwort verwendet.
- Wenn Sie versuchen sich bei dem registrieren Konto anzumelden und die Passwort-Authentifizierung ist fünf mal oder öfter hintereinander fehlgeschlagen, kann das Konto eventuell für dreißig Sekunden gesperrt werden.
- Wenn das Passwort während mehrere Verbindungen von einem PC aus aktiv sind geändert wird, kann es zu einer Fehlfunktion des Browsers kommen. Stellen Sie in diesem Falle eine neue Verbindung zum Server her.



- Einstellung : Wenn Sie <Gast Zugriff erlauben> ausgewählt haben, kann über das Gast Konto auf den Web Viewer zugegriffen werden, wobei jedoch nur der Live Viewer Bildschirm betrachtet werden kann.
 - Die ID/das Passwort für das Gast Konto lautet <guest/guest> und kann nicht geändert werden.
- Authentifizierungseinstellungen : Wenn Sie <RTSP Verbinden ohne Authentifizierung ermöglichen>, wählen, können Sie auf RTSP ohne Anmeldung zugreifen und Videobilder betrachten.
- Aktueller Benutzer : Wenn Sie <Verwenden> wählen, können Sie die Benutzerberechtigungen einstellen oder bearbeiten.
 - Der Administrator kann die Audioeingang-, Audioausgang-, Alarmeingang- und PTZ-Steuerung- Berechtigungen festlegen.
 - Audioeingabe/Audioausgabe/Alarmausgabe : Sie können die Audioeingabe/Audioausgabe/Alarmausgabe im Live-Modus im aktuellen Benutzerkonto aktivieren/deaktivieren.
 - PTZ-Steuerung: Auswahl der <PTZ>.
 - Profil : Wenn Sie <Stand.> wählen, können Sie nur Videobilder mit dem Voreinstellung Profil ansehen; wenn Sie <Alle> wählen, können Sie Videobilder aller Profile ansehen.




- Die für registrierte Benutzer verfügbaren ONVIF Funktionen sind auf die Benutzer beschränkt, die über die entsprechenden Rechte verfügen.

4. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.

Datum und Zeit


- Wählen Sie die Registerkarte **<Basic (Basic)>** aus dem Setup-Menü.
- Klicken Sie auf **<Datum und Zeit>**.
- Geben Sie die Uhrzeit und das Datum an, die für den Encoder verwendet werden sollen.
 - Aktuelle Systemzeit : Die aktuellen Zeiteinstellungen Ihres Systems werden angezeigt.
 - Timezone (Zeitzone) : Legen Sie die lokale Zeitzone basierend auf der Greenwich-Zeit (GMT) fest.
 - Daylight Saving Time (Sommerzeit) : Wenn diese Option ausgewählt ist, wird die Zeit für den festgelegten Zeitraum eine Stunde vor der lokalen Zeitzone eingestellt. Diese Option wird nur in Gegenden angezeigt, in denen die Sommerzeit angewendet wird.
 - Einstellung der Systemzeit : Legen Sie das Datum und die Zeit fest, die für Ihr System angewendet werden.
 - Benutzerhandbuch : Stellt die aktuelle Zeit des Encoders manuell ein. Wenn Sie das Auswahlfeld **<Mit dem PC Viewer Synchronisieren>** auswählen, wird die Zeit des Webviewers auf die des PC gestellt, auf dem der Webviewer läuft.
 - Mit dem NTP-Server Synchronisieren : Die Zeit wird mit der Zeit der festgelegten Serveradresse synchronisiert.
- Klicken Sie auf **[Anwenden]**, wenn Sie die Einstellungen vorgenommen haben.



- Wenn **<Mit dem PC Viewer Synchronisieren>** eingestellt wurde, muss die eingestellte Standard-Zeitzone dieselbe sein, wie im PC.

IP & Port

- Wählen Sie die Registerkarte **<Basic (Basic)>** aus dem Setup-Menü.
- Klicken Sie auf **<IP & Port>**.
- Klicken Sie auf **<IP-Adresse>**.
- Konfigurieren Sie das **<IPv4 Setup>**.
 - IP-Typ : Wählen Sie einen IP-Verbindungs-Typ.
 - Manuell : Stellen Sie IP-Adresse, Subnetzmaske, Gateway, DNS1, DNS2 und den Host-Namen ein.
 - DHCP : Legt DNS1, DNS2, und den Hostnamen fest.
 - PPPoE : Legt DNS1, DNS2, Hostnamen und das Passwort fest.
 - Wenn Sie auf **<Manuell>** stellen, sollten Sie IP, SubnetzMaske, Gateway und DNS 1 & 2 manuell festlegen.
 - MAC-Adresse : Zeigt die MAC Adresse an.
 - IP-Adresse : Zeigt die gegenwärtige IP Adresse an.
 - Subnetzmaske : Zeigt die **<Subnetzmaske>** für die gewählte IP.
 - Gateway : Hier wird das **<Gateway>** für die gewählte IP-Adresse angezeigt.
 - DNS1/DNS2 : Hier wird die Adresse des DNS (Domain Name Service)-Servers angezeigt.
 - Hostname : Hostname wird angezeigt.



- Konfigurieren Sie das **<IPv6 Setup>**.
 - Stellen Sie diese Option auf **<Verwendung>** um IPv6 Adressen verwenden zu können.
 - Stand. : Verwenden Sie die Standard IPv6 Adresse.
 - DHCP : Die über den DHCP-Server bezogene IPv6-Adresse anzeigen und verwenden.
 - Manuell : Geben Sie die zu verwendende IP-Adresse und das Gateway manuell ein.

- Die Zuweisung der IP-Adresse wird auf DHCP voreingestellt. Wenn kein DHCP-Server gefunden wird, werden die vorherigen Einstellungen automatisch wieder hergestellt.
- Wenn die Bearbeitung abgeschlossen ist, auf **[Anwenden]** klicken, um die Änderungen zu übernehmen und den Browser zu verlassen. Stellen Sie nach einer gewissen Zeit erneut eine Verbindung mit der geänderten IP her.

- Klicken Sie auf **<Port>**.
- Machen Sie nach Bedarf Ihre Eingaben im Port-Menü.
 - Der Port-Bereich kann sich nicht zwischen 0 und 1023 befinden und der Port 3702 steht nicht zur Verfügung.
 - HTTP : HTTP-Port für den Zugriff auf den Encoder via Webbrowser. Die Standardeinstellung ist 80 (TCP).
 - Die Einstellung des HTTP-Ports auf 65535 ist aufgrund der Sicherheitsrichtlinie für Safari und Google Chrome nicht erlaubt.
 - HTTPS : In dieser Version wird die Sicherheit des Web-Kommunikationsprotokolls HTTP verstärkt. Lässt sich verwenden, wenn der HTTPS-Modus auf SSL eingestellt ist. Der Anfangswert ist auf 443(TCP) eingestellt.
 - Der verfügbare Einstellungsbereich liegt bei 1024~65535. (Möglicherweise können Sie aus Sicherheitsgründen bei Ihrem Safari oder Google Chrome Browser 65535 nicht als Ihren HTTPS-Port verwenden.)
 - RTSP : Wird verwendet, um Videos im RTSP-Modus zu übertragen; die Standardeinstellung ist 554.
 - Time out : Bei Verbindung mit RTSP wird durch diese Funktion die Verbindung zurückgesetzt, wenn es eine bestimmte Zeitlang keine Reaktion gibt.

- Wenn der HTTP-Port geändert wurde, wird der Browser verlassen. Anschließend muss die Adresse den neu zugewiesenen HTTP-Port gefolgt von der IP-Adresse enthalten. Beisp.: IP-Adresse 192.168.1.100, HTTP-Port : 8080 → http://192.168.1.100:8080 (Wenn der HTTP-Port auf 80 eingestellt ist, muss keine Portnummer angegeben werden.)
- Es wird empfohlen RTSP und HTTPS zu verwenden, damit verhindert wird, dass die Bildinformationen wiederhergestellt werden.

- Klicken Sie auf **[Anwenden]**, wenn Sie die Einstellungen vorgenommen haben.


PTZ-SETUP

Externes PTZ

Stellt den Verbindungswert der externen PTZ-Kamera so ein, dass die PTZ über die an die RS-485-Buchse des Encoders angeschlossene Kamera gesteuert werden kann.

- 1. Wählen Sie die Registerkarte <PTZ (+)> aus dem Setup-Menü.
- 2. Klicken Sie <Externes PTZ>.
- 3. Einzustellender Kanal auswählen.
- 4. Bitte legen Sie den Verbindungspost fest.
 - RS-485 : Wählen Sie diese Option aus, wann immer Sie die Kamera und den ferngesteuerten AUX über den RS-485-Anschluss steuern möchten.
 - Koaxial : Kamerasteuerung festlegen. PTZ und OSD können gesteuert werden.
- 5. Bitte legen Sie den seriellen Port fest. Falls Sie <RS-485> als Verbindungspost auswählen, können Sie den RS-485-Kommunikationsmodus der angeschlossenen PTZ-Kamera festlegen.
 - ProtokollWählt das gleiche Protokoll wie für die Kamera, unter den Modellen Samsung-T / Pelco-D / Pelco-P aus.
 - Kamera-ID : Zeigt die festgelegte Kamera-ID an.
 - Baudrate : Übertragungsrate für die RS-485 Datenübertragung.
 - Daten : Das Daten Bit festlegen.
 - Parität : Das Paritätsbit festlegen.
 - Stoppbit : Das Stoppbit einstellen.
- 6. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.

- Für diesen Betrieb müssen Encoder und PTZ-Kamera normal verbunden sein. Außerdem muss der serielle Anschluss für den Betrieb der PTZ-Kamera festgelegt sein.
- Überprüfen Sie die von der Kamera unterstützten Funktionen, wann immer sie angeschlossen wird. Abhängig von der Kamera- oder Protokollspezifikation können einige Funktionen deaktiviert sein. Beziehen Sie sich auf die nachfolgende Tabelle für weitere Details.



- 7. Den Cursor [+] auf das Bildschirm-Bewegungs-Pad klicken, um die Bewegung des Bildschirms zu steuern.
 - Bildschirm bewegen: Den Cursor in die gewünschte Richtung scrollen.
 - Die Bildschirm-Bewegungsgeschwindigkeit steuern: Je weiter der Cursor vom Zentrum entfernt ist, desto schneller bewegt er sich auf dem Bildschirm.
- 8. Zoom-Bewegung steuern.
 - Vergrößern: Rechts auf der Benutzeroberfläche die Leiste nach oben bewegen oder die Taste [+] drücken. Je weiter die Leiste vom Mittelpunkt entfernt ist, desto schneller erfolgt die Erweiterung des gezeigten Bildschirms.
 - Verkleinern: Rechts auf der Benutzeroberfläche die Leiste nach unten bewegen oder die Taste [-] drücken. Je weiter die Leiste vom Mittelpunkt entfernt ist, desto schneller erfolgt die Reduzierung des gezeigten Bildschirms.
- 9. Den Fokus anpassen.
 - Manueller Fokus (/) : Passt den Fokus des Bildschirms für kurze oder lange Distanz an.

■ Die Schwenk-/Neige-/Zoomsteuerung ist nur möglich, falls der Encoder an die PTZ-Kamera angeschlossen ist und die <Setup des Serienanschlusses> auf normal festgelegt wird.

Zum Hinzufügen eine Voreinstellung

- 1. Wählen Sie zum Hinzufügen die voreingestellte Nummer ein.
- 2. Stellen Sie den Namen für die Voreinstellung ein.
- 3. Drücken Sie die Taste [Los].

Zum Löschen einer Voreinstellung

- 1. Wählen Sie zum Löschen die voreingestellte Nummer ein.
- 2. Drücken Sie die Taste [Hinzufügen].

Eine Voreinstellung verschieben


- 1. Wählen Sie einen voreingestellten Wert den Sie verschieben möchten.
- 2. Drücken Sie die Taste [Entfernen].

Funktionen, die bei jedem Protokoll unterstützt werden

Protokoll	PT-Steuerung	PT-Bewegungsgeschwindigkeit	T-Steuerung	T-Bewegungsgeschwindigkeit	Zoom-Steuerung	Zoom-Bewegungsgeschwindigkeit	Schärfesteuerung	Winkelbewegungsgeschwindigkeit	Voreinstellung speichern	Voreinstellung Bewegung	Bemerkungen
SAMSUNG-T	0	0	0	0	0	0	0	X	0	0	
PELCO-D	0	0	0	0	0	0	0	X	0	0	
PELCO-P	0	0	0	0	0	0	0	X	0	0	

Video Setup

1. Wählen Sie die Registerkarte <Video und Audio (≡)> aus dem Setup-Menü.
2. Klicken Sie <Video Setup>.
3. Einstellender Kanal auswählen.
4. Legen Sie die Privatsphärenzone fest.
5. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.



Privatezone einrichten

Sie können einen speziellen Bereich des Videos als geschützten Bereich für ihre Privatsphäre festlegen.

1. Wählen Sie das <Datenschutzbereich aktivieren>-Kontrollkästchen aus.
2. Klicken Sie [OK].
3. Klicken und ziehen Sie mit der Maus über das Video, um einen Bereich auszuwählen.
4. Den Namen eingeben und die Farbe wählen und dann [OK] anklicken.
5. Wenn Sie einen Namen auf der Liste löschen möchten, wählen Sie ihn und drücken Sie auf [Löschen].

Audio setup

Sie können den Eingangs-/Ausgangswert des mit dem Encoder verbundenen Audios einstellen.


1. Wählen Sie die Registerkarte <Video und Audio (≡)> aus dem Setup-Menü.
2. Klicken Sie <Audio setup>.
3. Einstellender Kanal auswählen.
4. Den Wert für den Audio Eingang festlegen.

- Quelle: Das Kabel mit dem Audiogerät verbinden.
 - Line: Zu verwendender Audio-Codec.
- Codec: Den Audio-Codec angeben.
 - G.711: Ein Audio Codec der eine 64 Kbps PCM (Pulse Code Modulation) Codierung verwendet. Ein ITU-Standard Audio Codec, der sich für die digitale Tonübertragung in PSTN Netzwerken oder über PBX eignet.
- Samplingrate: Die Sampling-Frequenz gibt an, wie viel Mal pro Sekunde das Sample eines analogen Audiosignals abgetastet wird. Je höher dieser Wert ist, desto besser ist die Tonqualität.
- Bitrate: Stellen Sie das Komprimierungsverhältnis entsprechend der Bitrate ein.
- Verstärkung: Die Audioeingabe-Lautverstärkung angeben.



- Eine Verschlechterung der Tonqualität oder Pfeifen kann auftreten, wenn die Lautstärke der Tonquelle oder der Verstärkungswert unverhältnismäßig eingestellt wurden.

5. Stellt den Audio Ausgangspegel ein.
 - Aktivieren: Stellt die Audioausgabe auf Ein.
 - Verstärkung: Die Audioausgabe-Lautverstärkung angeben.
6. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.




NETZWERK-SETUP

DDNS

DDNS ist eine Abkürzung für Dynamic Domain Name Service, welcher die IP-Adresse eines Encoders in einen allgemeinen Hostnamen umwandelt, so dass sich der Benutzer leicht daran erinnern kann.

- Sie können den DDNS-Service nur verwenden, wenn eine Internetverbindung besteht.

1. Wählen Sie die Registerkarte <Netzwerk ()> aus dem Setup-Menü.
2. Klicken Sie auf <DDNS>.
3. Wählen Sie als Verbindungstyp <DDNS> aus.
4. Geben Sie entsprechend des ausgewählten Typs die DDNS-Angebaben ein.



- Wisenet DynDNS : Wählen Sie diese Option, wenn Sie den von Hanwha Techwin zur Verfügung gestellten DDNS-Server benutzen.
 - Produkt-ID : Geben Sie die im Wisenet DynDNS Dienst registrierte Produkt-ID ein.
- Quick connect : Stellt die Portweiterleitung automatisch ein, wenn ein Router mit UPnP (Universal Plug and Play) verwendet wird.



- Wenn Sie DDNS-Dienstleistungen verwenden möchten, ohne den Hub zur Unterstützung von UPnP-Funktion zu verwenden, drücken Sie auf schnelle Verbindung, dann gehen Sie zum Hub-Menü und aktivieren Sie den Anschluss für die Weiterleitung an Ihren Hub.

Für mehr Informationen dazu, wie man ein Port für die Weiterleitung an Ihr Hub einstellt, wenden Sie sich auf „Portbereichweiterleitung Konfigurieren (Port Mapping)“ . (Seite 20)

- Öffentliche DynDNS : Wählen Sie einer der verfügbaren Öffentlichen DDNS-Server aus, wenn Sie einen Öffentlichen DDNS-Server benutzen.
 - Servername : Wählen Sie den gewünschten Server für den DDNS-Service aus.
 - Hostname : Geben Sie den Hostnamen ein, der auf dem DDNS-Server registriert ist.
 - Benutzername : Geben Sie einen Benutzernamen für den DDNS-Service ein.
 - Kennwort : Geben Sie das Kennwort für den DDNS-Service ein.

5. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.

- Wenn <Quick connect>, eingestellt wurde, wählen Sie den Wisenet DDNS Service aus.

Registrierung unter DDNS vornehmen

Ihr Produkt unter Wisenet DynDNS registrieren

1. Besuchen Sie die Webseite von Wisenet DynDNS (<http://ddns.hanwha-security.com>) und melden Sie sich mit einem gültigen Benutzerkonto an.

2. Wählen Sie aus der oberen Menüleiste <MY DDNS>.



3. Klicken Sie auf die Registerkarte [Register Product].

4. Die Produkt-ID eingeben.


5. Wählen Sie eine <Type> und geben Sie die <Model> an.

6. Wenn nötig, geben Sie den Standort des Produktes und eine Beschreibung an.

7. Klicken Sie auf [Product Registration]. Das Produkt wird zu der Produktliste hinzugefügt, die Sie überprüfen können.

Zur Verbindung mit dem Wisenet DDNS innerhalb der Encoder-Einrichtung

1. Stellen Sie im DDNS-Setup <DDNS> auf <Wisenet DDNS>.
2. Den <Produkt-ID> eingeben, der bei der Registrierung des Produkts auf der DDNS-Seite festgelegt wurde.
3. Klicken Sie auf [Anwenden].
Wenn die Verbindung erfolgreich hergestellt wurde, erscheint die Nachricht <(Success)> auf dem Bildschirm.



Öffentliches DDNS in den Encoder-Einstellungen konfigurieren

1. Öffnen Sie die Seite der DDNS-Einstellungen und wählen Sie <Öffentliche DynDNS> für <DDNS> aus.
2. Geben Sie der entsprechenden Hostname der Seite, das Benutzerkennwort und Passwort ein.
3. Klicken Sie auf die Taste [Anwenden].
Wenn die Verbindung ordnungsgemäß hergestellt wird, erscheint <(Success)>.
4. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.

- Um den DDNS-Dienst richtig nutzen zu können, ist ein DDNS-Setup und die Einrichtung der Portweiterleitung des Routers erforderlich.
Für die Portweiterleitung bitte unter "Portbereichweiterleitung Konfigurieren (Port Mapping)" (Seite 20)

IP Filterung

Sie können eine Liste von IPs erstellen, denen der Zugang erlaubt oder verweigert wird.

1. Wählen Sie die Registerkarte <Netzwerk ()> aus dem Setup-Menü.
2. Klicken Sie auf <IP Filterung>.
3. Wählen Sie <Filterung-Typ>.
 - Abgelehnt : Wenn Sie diese Option wählen, wird den IP-Adressen, die dieser Filterliste hinzugefügt wurden, der Zugang verweigert.
 - Zulassen : Wenn Sie diese Option wählen, wird nur den IP-Adressen, die dieser Filterliste hinzugefügt wurden, der Zugang erlaubt.
4. Klicken Sie auf die [Hinzufügen] Schaltfläche.
Die IP-Liste wird erstellt.
5. Geben Sie die IP-Adresse ein, für die Sie den Zugriff gewähren oder verbieten wollen.
Wenn Sie eine IP-Adresse und einen Präfix eingeben, erscheint die Liste der verfügbaren IP-Adressen in der rechten Filterbereichspalte.




- Wenn für die IP-Filterung <Zulassen> und für <IPv6 Setup> unter <IP & Port> auf <Verwendung> gestellt wurde, müssen die IPv4 und IPv6 Adressen des gerade konfigurierten Computers zugewiesen werden.
- Die IP-Adresse des für die Einrichtung verwendeten Computers darf nicht zu der <Abgelehnt> Liste hinzugefügt werden, sondern muss zur <Zulassen> Liste hinzugefügt werden.
- Nur die IP-Adressen, die auf <Verwendung> eingestellt sind, werden in der Filterspalte angezeigt.

6. Die zu löschende IP-Adresse aus der Liste auswählen.
Klicken Sie auf die [Löschen] Schaltfläche.
7. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.

HTTPS

Sie können ein sicheres Verbindungssystem oder ein öffentliches Zertifikat zu diesem Zweck auswählen.

1. Wählen Sie die Registerkarte <Netzwerk ()> aus dem Setup-Menü.
2. Klicken Sie auf <HTTPS>.
3. Wählen Sie ein sicheres Verbindungssystem aus.
 - Um den Encoder im HTTPS-Modus öffnen zu können, müssen Sie die IP-Adresse für den Encoder in Form von „https://<encoder_IP>“ eingeben.
Wenn im Internet Explorer die Konfiguration der Web Viewer Einstellungen im HTTPS-Modus fehlergeschlagen ist, könne die Internetoptionen wie folgt eingestellt werden: <Menü → Extras → Internetoptionen → Erweitert → Sicherheit → Markierung bei TLS 1.0 löschen und bei TLS 1.1, TLS 1.2 setzen>
4. Suchen Sie nach dem öffentlichen Zertifikat, das Sie für den Encoder installieren möchten.
Um das Zertifikat für den Encoder zu installieren, müssen Sie einen Zertifikatsnamen (der vom Benutzer beliebig zugewiesen werden kann), eine Zertifikatsdatei, die von der Zertifizierungsstelle ausgestellt wurde, und eine Schlüsseldatei bereitstellen.
 - Die Option <HTTPS (Sicherer Verb.modus verw. öffentliches Zertifikat)> ist nur aktiv, wenn ein öffentliches Zertifikat installiert wurde.
5. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.



Einlegen des Zertifikats

1. Zertifikatsname eingeben.
2. Klicken Sie die Schaltfläche [Durchsuchen ()] an, wählen Sie zur Installation eine öffentliche Zertifikatsdatei und Schlüsseldatei und klicken Sie auf die Schaltfläche [Installation].


Das Zertifikat Löschen

1. Klicken Sie auf die Taste [Löschen].
2. Um ein öffentliches Zertifikat zu löschen, muss auf den Netzwerk Video Decoder im <HTTP (Keine sichere Verb. verwend.)> oder <HTTPS (Sicherer Verb.modus verw. besonderes Zertifikat)> Modus zugegriffen werden.

802.1x

Bei dem Verbindungsaufbau mit einem Netzwerk kann festgelegt werden, ob das 802.1x Protokoll verwendet werden soll und anschließend das Zertifikat installiert werden.

1. Wählen Sie die Registerkarte <Netzwerk ()> aus dem Setup-Menü.
2. Klicken Sie auf <802.1x>.
3. <IEEE 802.1x einstellung> einstellen.
 - IEEE 802.1x : Die Verwendung des 802.1x Protokolls einstellen.
 - EAPOL version : EAP-TLS oder LEAP wählen.
 - EAPOL version : Version 1 oder 2 auswählen.
 - ID : Geben Sie die Client-Zertifikats-ID in EAP-TLS und die Benutzer-ID in LEAP ein.
 - Kennwort : Geben Sie das private Schlüssel-Passwort vom Client in EAP-TLS und das Benutzerpasswort in LEAP ein. Das Passwort muss nicht in EAP-TLS eingegeben werden, wenn eine nicht verschlüsselte Schlüsseldatei verwendet wird.



- Wenn das angeschlossene Netzwerkgerät das 802.1x Protokoll nicht unterstützt, funktioniert das Protokoll nicht einwandfrei, selbst wenn sie es eingestellt haben.
- LEAP ist eine Authentifizierungstechnik mit geringer Sicherheit. Verwenden Sie sie nur in einer Umgebung, in der EAP-TLS nicht verfügbar ist.

4. Installieren/Entfernen von Zertifikaten.
Das Zertifikat wird nur für EAP-TLS benötigt.
 - CA Zertifikate : Wählen Sie ein öffentliches Zertifikat, das einen öffentlichen Schlüssel enthält.
 - Kundenzertifikat : Wählen Sie ein öffentliches Zertifikat, das einen Client Zertifikat Schlüssel enthält.
 - Privater Kundenschlüssel : Wählen Sie ein öffentliches Zertifikat, das den Privaten Client Schlüssel enthält.
5. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.


Installieren/Löschen der 802.1x Zertifikate

1. Die [Durchsuchen ()] Tasten für jede Position drücken und das zu installierende Zertifikat auswählen.
2. Wenn kein Zertifikat installiert ist, erscheint die Meldung "Nicht verfügbar" neben der ausgewählten Position.
3. Die [Installation] Taste neben der Information "Installiert" drücken.
4. Die [Löschen] Taste drücken, um das Zertifikat zu löschen.

QoS

Es kann die Priorität festgelegt werden, um eine stabile Übertragungsgeschwindigkeit für eine bestimmte IP zu sichern.

1. Wählen Sie die Registerkarte <Netzwerk ()> aus dem Setup-Menü.
2. Klicken Sie auf <QoS>.
3. Klicken Sie auf die [Hinzufügen] Schaltfläche.
Die IP-Liste wird erstellt.
4. Geben Sie eine IP-Adresse ein, der QoS zugeordnet werden soll.



- Der voreingestellte Präfix für IPv4 lautet 32;
Für DSCP ist die Voreinstellung 63.
 - Nur die IP-Adressen, die auf <Verwendung> eingestellt sind, können priorisiert werden.
5. Die zu löschende IP-Adresse aus der Liste auswählen.
Klicken Sie auf die [Löschen] Schaltfläche.
 6. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.

SNMP


Mit Hilfe des SNMP Protokolls kann der System- oder Netzwerk Administrator die Netzwerkgeräte aus der Ferne überwachen und die Umgebungseinstellungen konfigurieren.

1. Wählen Sie die Registerkarte <Netzwerk ()> aus dem Setup-Menü.
2. Klicken Sie auf <SNMP>.
3. Das <SNMP> festlegen.

- SNMP v1 aktivieren : SNMP Version 1 ist aktiviert.
- SNMP v2c aktivieren : SNMP Version 2 ist aktiviert.
 - Lesen Gruppe : Den Namen der Read Community die auf die SNMP Informationen zugreifen kann. Der voreingestellte Name lautet <public>.
 - Schreiben Gruppe : Den Namen der Write Community die auf die SNMP Informationen zugreifen kann. Der voreingestellte Name lautet <write>.
- SNMP v3 aktivieren: SNMP Version 3 ist aktiviert.
 - Kennwort: Das Standard Passwort für SNMP Version 3 festlegen.
 - Das voreingestellte Passwort kann einem Hacker angriff ausgesetzt sein. Es wird daher empfohlen, das Passwort nach der Installation zu ändern. Beachten Sie, dass für die Sicherheit und andere durch ein unverändertes Passwort verursachte Probleme der Benutzer die Verantwortung trägt.
 - Das Passwort sollte wenigstens 8 und nicht mehr als 16 Zeichen haben.
- SNMP Trap aktivieren: SNMP Trap wird verwendet, um wichtige Ereignisse und Bedingungen an den Admin System zu senden.
 - Gemeinschaft: Den Namen der Trap Community eingeben, um Nachrichten zu empfangen.
 - IP-Adresse: Die IP-Adresse eingeben, an die die Nachrichten gesendet werden.
 - Authentifizierungsfehler: Gibt an, ob ein Ereignis generiert werden soll, wenn die Community-Information ungültig ist.
 - Netzwerkverbindung: Gibt an, ob ein Ereignis generiert werden soll, nachdem die Netzwerkunterbrechung wieder hergestellt ist.

4. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.

-  ■ SNMP v3 kann nur dann eingestellt werden, wenn der sichere Datenübertragungsmodus HTTPS eingestellt ist. Schlagen Sie unter „HTTPS“ nach. (Seite 33)
- Falls Sie SNMP v3 nicht verwenden, kann es ein Sicherheitsproblem geben.



Autom. IP-Konfiguration

Sie können die IP für den Zugriff und die Encoder-Suche automatisch festlegen.

1. Wählen Sie die Registerkarte <Netzwerk ()> aus dem Setup-Menü.
2. Klicken Sie auf <Autom. IP-Konfiguration>.
3. <Link- Lokale IPv4 Adresse> einstellen.
Eine zusätzliche IP-Adresse kann zugewiesen werden, um den Encoder im Link-lokalen Netzwerk zu öffnen.

- Auto-Konfiguration : Gibt Befähigen oder Deaktivieren für die Link-Lokale IPv4-Adresse an.
- IP-Adresse : Die zugeordnete IP-Adresse anzeigen.
- Subnetzmaske : Die Subnetzmaske des zugeordneten IP anzeigen.

4. <UPnP entdeckung> einstellen.
Encoder können sowohl im Client als auch im Betriebssystem mit Unterstützung des UPnP-Protokolls automatisch gefunden werden.
 - UPnP entdeckung: Gibt Befähigen oder Deaktivieren für UPnP-Ermittlung an.
 - Freundlicher name: Zeigt den Encoder-Namen an.
Der Anzeigename wird im Format von WISENET-<Modellname>--<MAC-Adresse> angezeigt.



- Innerhalb des Windows-Betriebssystems, das UPnP grundsätzlich unterstützt, werden die mit dem Netzwerk verbundenen Encoder angezeigt.

5. <Bonjour> einstellen.
Encoder können sowohl im Client als auch im Betriebssystem mit Unterstützung des Bonjour-Protokolls automatisch gefunden werden.
 - Bonjour: Gibt Aktivieren oder Deaktivieren für Bonjour an.
 - Freundlicher name: Zeigt den Encoder-Namen an.
Der Anzeigename wird im Format von WISENET-<Modellname>--<MAC-Adresse> angezeigt.



- Im Mac-Betriebssystem, das Bonjour standardmäßig unterstützt, werden die angeschlossenen Encoder automatisch im Bonjour-Lesezeichen des Safari-Webrowsers angezeigt.
Wird das Bonjour-Lesezeichen nicht angezeigt, dann prüfen Sie die Lesezeicheneinstellungen in dem "Präferenz" Menü.

6. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.



EREIGNISS-SETUP


Ereigniseinrichtung

Sie können auf einfache Weise die Kriterien zur Erkennung von Ereignissen festlegen und zu den detaillierten Einstellungen gehen.

1. Wählen Sie die Registerkarte **<Ereignis (🏠)>** aus dem Setup-Menü.
2. Klicken Sie auf **<Ereigniseinrichtung>**.
3. In der Ereignisliste die gewünschten Punkte auswählen.
4. Klicken Sie auf **[Anwenden]**, wenn Sie die Einstellungen vorgenommen haben.



- Konfigurieren Sie detaillierte Ereignis-Einstellungen, indem Sie auf den gewünschten Typ klicken. Sie werden zu den detaillierten Einstellungen umgeleitet.



Aushändigen

Die Ereigniserkennung kann in Verbindung mit einer zusätzlichen Kamera, welche eine PTZ-Voreinstellungsfunktion besitzt, verwendet werden. Sobald ein Ereignis erkannt wird, bewegt sich die PTZ-Kamera in die voreingestellte Position, und kann anschließend eine Überwachung durchführen.

1. Wählen Sie die Registerkarte **<Ereignis (🏠)>** aus dem Setup-Menü.
2. Klicken Sie auf **<Übergaben>**.

- Empfänger Kamera : Registrieren Sie die Kamera, die mit der Ereigniserkennung zusammenarbeiten soll. Klicken Sie auf die **[Hinzufügen]** am oberen Rand des Menüs und geben Sie IP, Port, ID und Passwort der zusammenarbeitenden Kamera sowie die voreingestellte Nummer ein, wohin, nachdem eine Bewegung erkannt wird, diese bewegt wird.
 - Für die Bewegungs- /Manipulationserkennung/Geräuschklassifizierung/IVA-Ereigniserkennung kann eine Übergabe verwendet werden.
 - Kann nur dann normal arbeiten, wenn die in der Empfängerkamera eingestellte Voreinstellung angegeben wird.
 - Eine Übergabe unterstützt nur eine Voreinstellung für jeden Bereich.


3. Klicken Sie auf **[Anwenden]**, wenn Sie die Einstellungen vorgenommen haben.



FTP / E-mail

Es können die FTP / E-Mail Server Einstellungen konfiguriert werden, sodass die mit der Kamera aufgenommenen Bilder an Ihren PC gesendet werden, wenn ein Ereignis eintritt.


1. Wählen Sie die Registerkarte **<Ereignis ()>** aus dem Setup-Menü.
2. Klicken Sie auf **<FTP / E-mail>**.
3. Wählen Sie **<FTP-Konfiguration>** oder **<E-mail-Konfiguration>** und geben/löschen Sie einen gewünschten Wert ein.



- **FTP-Konfiguration**
 - **Serveradresse** : Geben Sie die IP-Adresse des FTP-Servers ein, an den die Bilder eines Alarms oder Ereignisses gesendet werden sollen.
 - **ID** : Geben Sie die Benutzer-ID ein, mit der Sie sich auf dem FTP-Server anmelden werden.
 - **Kennwort** : Geben Sie ein Benutzerkennwort ein, um sich beim FTP-Server anzumelden.
 - **Verzeichnis Hochladen** : Geben Sie den Pfad auf dem FTP-Server an, unter dem die Bilder eines Alarms oder Ereignisses gespeichert werden.
 - **Port** : Standardmäßig wird für den FTP-Server Port 21 verwendet; Sie können die Portnummer jedoch den FTP-Servereinstellungen entsprechend ändern.
 - **Passivmodus** : Wählen Sie **<Ein>**, wenn aufgrund der Firewall- oder FTP-Servereinstellungen eine Verbindung mit Passivmodus erforderlich ist.
 - **E-mail-Konfiguration**
 - **Serveradresse** : Geben Sie die SMTP-Adresse des E-Mail-Servers ein, an den die Bilder eines Alarms oder Ereignisses gesendet werden sollen.
 - **Authentifizierung** : Wählen ob die Berechtigung benutzt werden soll.
 - **TLS Verwendung** : Legen Sie die Verwendung von TLS fest.
 - **ID** : Geben Sie den Benutzernamen zur Anmeldung auf dem E-Mail-Server ein.
 - **Kennwort** : Geben Sie das Benutzerkennwort ein, um sich beim E-Mail-Server anzumelden.
 - **Port** : Standardmäßig wird für den E-Mail-Server Port 25 verwendet; Sie können die Portnummer jedoch den E-Mail-Servereinstellungen entsprechend ändern.
 - **Empfänger** : Geben Sie die E-Mail-Adresse des Empfängers ein.
 - **Absender** : Geben Sie die E-Mail-Adresse des Absenders ein. Wenn Sie eine falsche Absenderadresse eingeben, wird die E-Mail vom E-Mail-Server eventuell als SPAM eingestuft und nicht verschickt.
 - **Betreff** : Geben Sie einen Betreff für Ihre E-Mail ein.
 - **Textfeld** : Geben Sie den Text Ihrer Nachricht ein. Fügen Sie die Bilder des Alarms oder Ereignisses an die E-Mail an, die Sie gerade bearbeiten.
4. Klicken Sie auf **[Anwenden]**, wenn Sie die Einstellungen vorgenommen haben.

Alarmsignal


1. Wählen Sie die Registerkarte **<Ereignis (🔔)>** aus dem Setup-Menü.
2. Klicken Sie auf **<Alarmsignal>**.
3. Legen Sie den Alarmausgang des Encoders fest.
 - Wenn Sie den Typ des Alarm Ausganges ändern, wird die Alarm Ausgang Schaltfläche auf der Überwachungsseite und der auf der Ereignis Setup Seite angezeigte Typ des Alarm Ausganges entsprechend geändert.
 - Typ
 - Normal Öffnen : Der Status „Schaltkreis offen“ des Sensors wird als normaler Zustand betrachtet. Es wird ein Alarm „Schaltkreis geschlossen“ ändert.
 - Normal schliessen : Der Status “Schaltkreis geschlossen Eingang wird als normaler Zustand betrachtet. Es wird sich auf „Schaltkreis offen“ ändert.
 - Modus : Stellt die Methode der Alarmausgabe ein.
 - Die Operationen unterscheiden sich, wenn die deaktivierte, Alarm Aus
 - Impuls: Die Taste für die unter Dauer (Schaltintervall) fest automatisch deaktiviert.
 - Aktiv/Inaktiv: Die Taste bleibt aktiv, bis der Benutzer die
 - Dauer : Stellt die Dauer des aktiven Alarms zwischen 1 bis ausgewählt wurde.
4. Klicken Sie auf **[Anwenden]**, wenn Sie die Einstellungen vorwa



ALARMEINGABE

Sie können die Art des Alarmeingangs, die Aktivierungszeit und den Betriebsmodus einstellen.


- Wählen Sie die Registerkarte <Ereignis (🏠)> aus dem Setup-Menü.
- Klicken Sie auf <ALARMEINGABE>.
- Entscheiden Sie, ob Sie die Option auf <Aktivieren> einstellen möchten oder nicht.
- Den Typ auswählen.
 - Normal Öffnen : Ist normalerweise geöffnet, wird es jedoch geschlossen, so wird ein Alarm ausgelöst.
 - Normal schliessen : Ist normalerweise geschlossen, wird es jedoch geöffnet, so wird ein Alarm ausgelöst.
- Legen Sie die <Aktivierungszeit> fest.
 - Immer : Überprüfen Sie immer, wenn ein Alarmsignal auftritt. Bei Eintreten eines Alarmzustands wird es im Betriebsmodus aktiviert.
 - Wenn <Immer> eingestellt ist, kann die Aktivierungszeit nicht geändert werden.
 - Nur festgelegte Zeit : Überprüfen Sie ob ein Alarm an einem bestimmten Wochentag um eine bestimmte Zeitperiode auftritt. Bei Eintreten eines Alarmzustands wird es im Betriebsmodus aktiviert.
 - [1 min 30 min 1 h] : Legt das Zeitanzeigeformat auf der vertikalen Achse fest.
 - [Zurücksetzen] : Setzt alle Einstellungen zurück.
- Legen Sie eine Funktion fest, die durchgeführt werden soll, wenn ein Alarm auftritt.
 - FTP : Legen Sie den Gebrauch von FTP-Übertragung im Alarmeingangs-Setup fest.
 - Lesen Sie zu mehr auf "FTP / E-Mail". (Seite 37)
 - E-mail : Legen Sie die Verwendung der E-Mail-Übertragung im Setup für den Alarmeingang fest.
 - Lesen Sie zu mehr auf "FTP / E-Mail". (Seite 37)
 - Alarmsignal : Wählen Sie, ob die Alarmausgabe eingestellt werden soll, wenn ein Alarm hereinkommt, und geben Sie die Alarmausgabezeit an.
 - Zum Preset : Dreht die Kamera zum voreingestellten Bereich, wenn der Alarm eingestellt wird.
 - Eine voreingestellte Bewegung ist nur möglich, falls sowohl Encoder als auch PTZ-Kamera angeschlossen sind.
 - Es kann nur die Voreinstellung des gleichen Kanals wie die Alarmeingangsnummer festgelegt werden. (z. B. Alarm 2 → Kanal 2 → Voreinstellung von Kanal 2)
- Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.



Zeitplan

Sie können die Einstellungen konfigurieren, um Bilder in regelmäßigen Abständen zu einer geplanten Betriebszeit zu übermitteln, und dies ungeachtet dem Auftreten eines Ereignisses.


- Wählen Sie die Registerkarte <Ereignis (🏠)> aus dem Setup-Menü.
- Klicken Sie auf <Zeitplan>.
- Entscheiden Sie, ob Sie die Option auf <Aktivieren> einstellen möchten oder nicht.
- Legen Sie das <Übertragungsintervall> fest.
- Legen Sie die <Aktivierungszeit> fest.
 - Immer : Wird immer im Betriebsmodus am eingestellten Intervall aktiviert.
 - Nur festgelegte Zeit : Wird regelmäßig im Betriebsmodus am festgelegten Datum und Uhrzeit aktiviert.
 - Damit die Bildübertragung erfolgreich ist, muss der Einstellungswert des Übertragungsintervalls kleiner als das voreingestellte Aktivierungsintervall sein.
- Legen Sie die Aktivierungsbedingungen fest.
 - FTP : Legen Sie die Verwendung der FTP-Übertragung fest, wenn ein Ereignis auftritt.
 - Lesen Sie zu mehr auf "FTP / E-Mail". (Seite 37)
- Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.



Videoverlust

Sie können die Kamera so festlegen, dass sie in der Lage ist, einen Alarm auszulösen, um den Benutzer zu benachrichtigen, wann immer das Video aufgrund einer Verbindungstrennung zur Kamera verloren gegangen war.


- Wählen Sie die Registerkarte <Ereignis (🏠)> aus dem Setup-Menü.
- Klicken Sie auf <Videoverlust>.
- Einzustellender Kanal auswählen.
- Entscheiden Sie, ob Sie die Option auf <Aktivieren> einstellen möchten oder nicht.
- Konfigurieren Sie die Ereignisbewegungsplan- und Ereignisbewegungsbedingungen.
 - Weitere Informationen über <Aktivierungszeit> und <Ereignis Aktion Setup>, finden Sie unter „ALARMEINGABE“. (Seite 38)
- Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.



Netzwerkverbindung unterbrochen

Wenn das Netzwerk physikalisch nicht verbunden ist, wird das als Ereignis betrachtet, das zu speichern ist.

1. Wählen Sie die Registerkarte **<Ereignis (🏠)>** aus dem Setup- Menü.
2. Klicken Sie auf **<Netzwerkverbindung unterbrochen>**.
3. Entscheiden Sie, ob Sie die Option auf **<Aktivieren>** einstellen möchten oder nicht.
4. Konfigurieren Sie die Ereignisbewegungsplan- und Ereignisbewegungsbedingungen.
 - Weitere Informationen über **<Aktivierungszeit>** und **<Ereignis Aktion Setup>**, finden Sie unter „ALARMEINGABE“. (Seite 38)
5. Klicken Sie auf **[Anwenden]**, wenn Sie die Einstellungen vorgenommen haben.




KONFIGURIEREN DER ANALYSEEINSTELLUNGEN

Bewegungserkennung

Sie können Einstellungen konfigurieren, um ein Ereignissignal zu generieren, wenn eine Bewegung erkannt wird.

1. Wählen Sie die Registerkarte **<Analyse (🔍)>** aus dem Setup- Menü.
2. Klicken Sie auf **<Bewegungserkennung>**.
3. Einzustellender Kanal auswählen.
4. Entscheiden Sie, ob Sie die Option auf **<Bewegungserkennung aktivieren>** einstellen möchten oder nicht.
5. Legen Sie einen **<Bereich einschließen>** und ein **<Erkennungsgreier Bereich>** fest.
Bis zu 8 Bereiche können eingerichtet werden.
Die Pegel- und Empfindlichkeitseinstellungen können separat für jeden Bereich festgelegt werden.
Ein einziger Bereich unterstützt eine Form mit bis zu 8 Scheiteln.
4 Eckpunkte auf dem Video mit der Maus auswählen, um ein Rechteck zu erstellen, und wählen Sie jede Zeile des Rechtecks und fügen Sie bis zu 4 weitere Punkte hinzu, um eine gewünschte Form zu erstellen.
6. Konfigurieren Sie die Einstellungen für jedes Element.
 - Empfindlichkeit : Stellt die Empfindlichkeit der Bewegungserkennung für jeden Bereich ein. Verringern Sie die Empfindlichkeit in einer Umgebung, in der der Hintergrund und das Objekt klar unterschieden werden, und erhöhen Sie die Empfindlichkeit in einer dunklen Umgebung, in der der Hintergrund und das Objekt nicht klar unterschieden werden können.
7. Wählen Sie aus, ob die Übergabe verwendet werden soll oder nicht.
Sollte eine Bewegung im eingestellten Erkennungsbereich erkannt werden, bewegt sich eine bestimmte Kamera zu einer bestimmten PTZ-Voreinstellungsposition.
 - Sie können Kameras nach ihrem Erkennungsbereich bestimmen.
8. Konfigurieren Sie die Ereignisbewegungsplan- und Ereignisbewegungsbedingungen.
 - Weitere Informationen über **<Aktivierungszeit>** und **<Ereignis Aktion Setup>**, finden Sie unter „ALARMEINGABE“. (Seite 38)
9. Klicken Sie auf **[Anwenden]**, wenn Sie die Einstellungen vorgenommen haben.




- In Bereichen, in denen die Bewegungserkennung häufig stattfindet, empfiehlt es sich, eher eine kontinuierliche Aufzeichnung als eine Bewegungserkennung zu verwenden.
- Da das Protokoll einmal alle 5 Minuten aufgezeichnet wird, können die gepufferten Protokolldaten für die Bewegungserkennung beschädigt werden, falls das Gerät ausgeschaltet wird.
- Die erkannte Größe eines Objekts kann aufgrund seiner Form von der tatsächlichen Größe abweichen.
- In den folgenden Fällen kann die Bewegungserkennung beeinträchtigt oder eine Funktionsstörung auftreten.
 - Die Farbe oder Helligkeit des Objekts ist ähnlich zum Hintergrund.
 - Geringe Aktivitäten in der Nähe des Randbereichs des Sichtfelds der Kamera.
 - Es treten laufend mehrere zufällige Bewegungen aufgrund eines Szenenwechsels, schnelle Änderungen der Lichtverhältnisse oder andere Gründe auf.
 - Ein feststehendes Objekt bewegt sich laufend an der selben Stelle.
 - Bewegungen mit geringen Positionswechseln, wie das Annähern an die oder sich entfernen von der Kamera.
 - Das sich bewegende Objekt erscheint zu dicht an der Kamera.
 - Ein Objekt verbirgt andere Objekte hinter sich.
 - Das Objekt ist zu schnell (für eine korrekte Erkennung muss sich ein Objekt in den überlappenden Bereichen der aneinander angrenzenden Rahmen befinden).
 - Reflexionen / Unschärfe / Schatten aufgrund starken Lichteinfalls, wie direkte Sonneneinstrahlung, Beleuchtung oder Scheinwerfer.
 - Heftiger Regen, Schneefall, Wind oder bei Dämmerung / Halbdunkel.

Manipulationserkennung

Es kann eingestellt werden Manipulationsversuche und auslösende Ereignisse zu erkennen, wie plötzliche Änderung der Aufnahmerichtung der Kamera, blockiertes Objektiv und andere allgemeine Veränderungen am Videomotiv.

1. Wählen Sie die Registerkarte <Analyse ()> aus dem Setup- Menü.
2. Klicken Sie auf <Manipulationserkennung>.
3. Einzustellender Kanal auswählen.
4. Entscheiden Sie, ob Sie die Option auf <Manipulationserkennung aktivieren> einstellen möchten oder nicht.
5. Stellen Sie die Empfindlichkeit ein.
Je höher der eingestellte Wert, desto empfindlicher ist die Kamerareaktion (Bereich: 1 bis 3).
6. Wählen Sie aus, ob die Übergabe verwendet werden soll oder nicht.
7. Konfigurieren Sie die Ereignisbewegungsplan- und Ereignisbewegungsbedingungen.
 - Weitere Informationen über <Aktivierungszeit> und <Ereignis Aktion Setup>, finden Sie unter „ALARMEINGABE“: (Seite 38)
8. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.




- ! ■ wird die Erfassung nach einer Stabilisierung für eine gewisse Zeitspanne (etwa 5 Sekunden) neu gestartet. Während der Stabilisierung ist keine Detektion möglich.
- Wenn häufig falsche Alarme erzeugt werden, sollten Sie die Empfindlichkeit allmählich verringern, um falsche Alarme zu minimieren.
- Wenn Sie eine niedrige Empfindlichkeit verwenden, können Alarme auch durch sehr kleine Änderungen auf dem Bildschirm erzeugt werden, es kann jedoch eine falsche Erkennung in Reaktion auf Änderungen in bewegten Objekten oder Helligkeit auftreten.
- In den folgenden Fällen kann es zu Fehlfunktionen der Anlasserfassungsfunktion kommen.
 - Monitoring-Umgebung mit einfachem Hintergrund, Nacht und niedrigem Lichtniveau.
 - Schwere Vibrationen der Kamera oder plötzliche Lichtveränderungen

SYSTEM-SETUP


Produktinformation

1. Wählen Sie die Registerkarte <System ()> aus dem Setup- Menü.
 2. Klicken Sie auf <Produktinformation>.
 3. Überprüfen Sie die Encoder-Informationen oder geben Sie Einzelheiten bezüglich Ihrer Netzwerkumgebung an.
 - Modell : Modellname des Geräts.
 - Seriennummer : Seriennummer des Geräts.
 - Geräte name : Den Gerätenamen eingeben, der auf dem Live Screen angezeigt wird.
 - Standort : Geben Sie den Standort an, wo der Encoder installiert ist.
 - Beschreibung : Stellen Sie detaillierte Informationen über den Standort des Encoders bereit.
 - Memo (Notizen) : Stellen Sie zum besseren Verständnis eine Erläuterung für den Encoder bereit.
 - Sprache : Wählen Sie die gewünschte Sprache für das OSD des Web Viewers.
- Die Standardsprache ist auf <English> eingestellt.
- Gerätetyp : Den Typ des Produkts einstellen.
Für weitere Details, siehe „Gerätetyp Setup-Guide“ (Seite 43).
4. Klicken Sie auf [Anwenden], wenn Sie die Einstellungen vorgenommen haben.



Aktualisierung / Neustart

1. Wählen Sie die Registerkarte <System ()> aus dem Setup- Menü.
2. Klicken Sie auf <Aktualisierung / Neustart>.
3. Wählen Sie einen bestimmten Menüpunkt und stellen Sie ihn entsprechend ein.
 - Upgraden : Führt eine Systemaktualisierung durch. Beim erneuten Verbinden wird der Web-Viewer nicht normal laufen, wenn der Browser-Cache nicht vollständig leer ist.
 - Standardwerte : Initialisiert alle Einstellungsinformationen einschließlich der Encoder-Einstellungen im Zustand der Werkseinstellungen. (Es werden jedoch keine Protokolle initialisiert)
 - Falls Sie <Außer netzwerkparameter>-Kontrollkästchen auswählen, werden die Netzwerkeinstellungen ausgeschlossen und zurückgesetzt.
 - Das IP-Adressiersystem wird standardmäßig auf DHCP zurückgesetzt, wenn immer Sie den Encoder zurücksetzen. Wenn kein DHCP-Server gefunden wird, werden die vorherigen Einstellungen automatisch wieder hergestellt.
 - Konfiguration Backup und Wiederherstellen : Zur Erzeugung einer Sicherungskopie der Systemeinstellungen, bevor der Wiederherstellungsprozess durchgeführt wird. Das System startet automatisch neu nach einem Backup oder einer.
 - Neu starten : Das System wird neu gestartet.



Eine Aktualisierung durchführen

1. Klicken Sie auf **[Durchsucher (🔍)]** und legen Sie eine Datei für die Aktualisierung fest.
2. Klicken Sie auf **[Aktualisierung]**.
3. Eine "Aktualisierung"-Fortschrittsleiste wird aufgerufen, um den Aktualisierungsstatus anzuzeigen.
4. Nach Abschluss der Aktualisierung wird der Browser beendet und der Encoder wird neu gestartet.

- Die Aktualisierung kann maximal 10 Minuten in Anspruch nehmen.
Wenn Sie den Aktualisierungsprozess abbrechen, so kann er nicht fertiggestellt werden.
- Während des System Neustarts findet der Zugriff über Web Viewer nicht statt.
- Die neueste Softwareversion kann von der Hanwha Techwin Electronics-Website heruntergeladen werden.

Sicherung der aktuellen Einstellungen

1. Klicken Sie auf **[Backup]**.
2. Eine Datei in einem ".bin"-Dateiformat wird in "Bibliothek" -> "Dokument" -> "Downloads" gespeichert.

Wiederherstellen der gesicherten Einstellungen


1. Klicken Sie auf **[Wiederhersteller]** um die Backup-Einstellungen.
2. Wählen Sie eine gewünschte Sicherungsdatei.

- Sollten Sie die Sicherung oder Wiederherstellung durchführen, wird der Webbrowser geschlossen und der Encoder wird erneut gestartet.
- Wenn Sie versuchen, die in einem anderen Modell gespeicherte, konfigurierte Datei wieder herzustellen, werden einige Funktionen nicht funktionieren und Sie müssen die Einstellung manuell ändern.

Protokoll

Sie können das System- oder das Ereignisprotokoll überprüfen.

1. Wählen Sie die Registerkarte **<System (🔍)>** aus dem Setup- Menü.
2. Klicken Sie auf **<Protokoll>**.
3. Wählen Sie einen Protokolltyp aus.
 - Zugriffsprotokoll : Sie können die Protokollinformationen überprüfen, die den Zugriff des Nutzers und den Zugriffszeitpunkt enthalten.
 - System Protokoll : Sie können anhand der Systemprotokolle nachprüfen, an welcher Stelle Systemänderungen, gemeinsam mit Zeitangaben, aufgezeichnet wurden.
 - Ereignisprotokoll : Sie können die Ereignisprotokolle gemeinsam mit Zeitangaben überprüfen.
4. Wählen Sie aus der rechten Protokollliste ein Element, nach dem gesucht werden soll.
 - Wenn Sie **<All>** in dem Aufklappenmenü oben links wählen, werden alle Protokolle des entsprechenden Protokolltyps angezeigt.
5. Wenn alle verfügbaren Protokolle nicht auf einer Seite angezeigt werden können, verwenden Sie die unteren Schaltflächen, um zum vorherigen, nächsten oder letzten Element zu wechseln.
6. Klicken Sie auf die **<Backup>**-Taste, um alle Protokolldaten für den aktuell ausgewählten Modus im "Zeitstempelwert gemäß Encoder in modelname-mode-encoder.txt erstellen" im Download-Ordner des Browsers zu speichern.



- Auf jeder Seite werden 15 Protokolle angezeigt, wobei das Aktuellste stets ganz oben angezeigt wird.
- Each log contains up to 1,000 records and after 1,000 records are saved, the oldest log is deleted when a new record is generated.

SPEZIFIKATIONEN

Elemente		Beschreibung	
		SPE-1610	SPE-410
Video	Eingangskanal	16KA BNC	4KA BNC
	Eingangssignal & Auflösung	CVBS, AHD (1 & 2 & 4 MP), CVI (1 & 2 MP), TVI (1 & 2 MP) Auto Erkennung	
	Videoausgang	1 HDMI OUT (16 Mehrfach-Image, 1920x1080)	1 HDMI OUT (4 Mehrfach-Image, 1920x1080)
Funktionsweise	Bewegungserkennung	Aus / Ein	
	Privatsphärenausblendung	Aus / Ein (4ea Rechteckzonen)	
	Alarm E/A	Eingabe je 16 / Ausgabe je 4	Eingabe je 4 / Ausgabe je 1
	Alarm Auslöser	Bewegungserkennung, Alarmeingang, Videoverlust, Manipulation, Netzwerk trennen	
	Alarmereignisse	Datei Hochladen über FTP, E-Mail	
	Audio-E/A	4 Line-Eingang / 1 Line-Ausgang	
	Interface der Fernbedienung	1ea RS-485(Halbduplex)	
	RS-485-Protokoll	SAMSUNG-T, PELCO-P/D	
	Koaxiale Steuerung	CVBS : Pelco-C (Coaxitron) AHD : ACP(AHD-Koaxialprotokoll)	
	Ethernet	RJ-45 (10/100/1000BASE-T)	
	Videokomprimierungsformat	H.264/MJPEG	
Netzwerk	Auflösung	NTSC : 2560x1440, 1920x1080, 1280x720, 928x480, 704x480, 928x240, 704x240, 352x240	
		PAL : 2560x1440, 1920x1080, 1280x720, 928x576, 704x576, 928x288, 704x288, 352x288	
	Max. Framerate	NTSC 4M Kamera H.264 15Fps/KA : 2560x1440, 1920x1080 H.264 30Fps/KA : 1280x720, 928x480, 704x480, 928x240, 704x240, 352x240 MJPEG 2Fps/KA : alle Auflösungen 2M/SD Kamera H.264 30Fps/KA : 1920x1080, 1280x720, 928x480, 704x480, 928x240, 704x240, 352x240 MJPEG 2Fps/KA : alle Auflösungen	

Elemente		Beschreibung	
		SPE-1610	SPE-410
Netzwerk	Max. Framerate	PAL 4M Kamera H.264 15Fps/KA : 2560x1440, 1920x1080 H.264 25Fps/KA : 1280x720, 928x480, 704x480, 928x240, 704x240, 352x240 MJPEG 2Fps/KA : alle Auflösungen 2M/SD Kamera H.264 25Fps/KA : 1920x1080, 1280x720, 928x480, 704x480, 928x240, 704x240, 352x240 MJPEG 2Fps/KA : alle Auflösungen	
	Video Qualität Anpassung	H.264 : Zielbitrate Pegelsteuerung MJPEG : Steuerung des Qualitätsniveaus	
	Bitrate Steuerungsmethode	H.264 : CBR oder VBR MJPEG : CBR	
	Streaming Kapazität	Duales Streaming (bis zu 3 Profile pro Kanal, 2 H.264 + 1 MJPEG)	
	Audiokomprimierungsformat	G.711 µ-law	
	Audiokommunikation	Bidirektional	
	IP	IPv4, IPv6	
	Protokoll	TCP/IP, UDP/IP, RTP(UDP), RTP(TCP), RTCP,RTSP, NTP, HTTP, HTTPS, SSL/TLS, DHCP, PPPoE, FTP, SMTP, ICMP, IGMP, SNMPv1/v2c/v3(MIB-2), ARP, DNS, DDNS, QoS, PIM-SM, UPnP, ONVIF, Bonjour	
	Sicherheit	HTTPS (SSL) Authentifizierungsprotokoll Anmelde-Übersicht Authentifizierung IP-Adressfilter Benutzerzugriff Protokoll 802.1X Authentifizierungsmethode (EAP-TLS, EAP-LEAP)	
	Streaming-Methode	Unicast / Multicast	
	Max. Benutzerzugriff	48 Benutzer (4 Benutzer / KA) im Unicast-Modus	16 Benutzer (4 Benutzer / KA) im Unicast-Modus
	Leistung	Empfohlene Bandbreite: 60Mbps, Empfohlene Bildrate: 600fps, Empfohlene verbundene Sitzungen(en): 40 ※ Falls die empfohlene Bandbreite / Bildrate / Anzahl verbundener Sitzungen überschritten wird, können einige Bilder verloren gehen.	

Elemente		Beschreibung	
		SPE-1610	SPE-410
Netzwerk	Anwendungsprogrammierschnittstelle	ONVIF Profile S SUNAPI (HTTP API)	
	Sprache der Webseite	Englisch, Koreanisch, Französisch, Deutsch, Spanisch, Italienisch, Chinesisch, Russisch, Japanisch, Schwedisch, Portugiesisch, Tschechisch, Polnisch, Türkisch, Niederländisch, Ungarisch, Griechisch	
	Web Viewer	Unterstützte Betriebssystem : Windows 7 / 8 / 10, MAC OS X 10.10, 10.11, 10.12 Plug-in freier Web-Viewer Unterstützte Webbrowser: Google Chrome 54, MS Edge 38, MS IE 11, Mozilla Firefox 49 (Window 64bit unterstützt) , Apple Safari 9 (Mac OS X unterstützt)	
	Zusammenarbeit von Software und Systemen	SmartViewer, SSM, WiseNet Mobile Viewer, NVR (*Hanwha Techwin NVR P, X, Q series)	
Betriebsbedingungen	Betriebstemperatur / Feuchtigkeit	-10°C ~ +45°C (14°F ~ +113°F) / 20% ~ 80% RH (-10°C ~ +40°C (14°F ~ 104°F) / 20% ~ 80% RH, bei Rack-Installation)	-10°C ~ +50°C (14°F ~ +122°F) / 20% ~ 80% RH
Elektrisch	Eingangsspannung/Strom	DC12V	DC12V, PoE(IEEE 802.3af)
	Energieverbrauch	MAX. 24W (12V, 2A)	MAX. 9.6W (12V, 0.8A)
Mechanisch	Farbe / Materiell	Schwarz/Metall	Dunkelgrau/Metall
	Abmessungen	B370,0 x H47,5 x T320mm	B178,0 x H34,0 x T127,8mm
	Gewicht	2,250g	540g

DETAILIERTE UNTERSTÜTZTE SPEZIFIKATIONEN DES WEB VIEWERS

Kategorie		Windows 7	Windows 10	Windows 7/10			Mac
		IE 11		Edge	Chrome	Firefox	Safari (Ver. 10.1 oder später / Ver. 11 oder später)
Live-Funktion	Erfassung	Unterstützt	Unterstützt	Unterstützt	Unterstützt	Unterstützt	Nicht unterstützt (Unterstützt / Unterstützt)
	Beispielaufnahme	Nicht unterstützt	Nicht unterstützt	Unterstützt	Unterstützt	Unterstützt	Nicht unterstützt (Unterstützt / Unterstützt)
	Pixelanzahl	Unterstützt	Unterstützt	Unterstützt	Unterstützt	Unterstützt	Unterstützt (Unterstützt/ Unterstützt)
	Ereignisanzeige	Unterstützt	Unterstützt	Unterstützt	Unterstützt	Unterstützt	Unterstützt (Unterstützt/ Unterstützt)
	Zuhören	Nicht unterstützt	Nicht unterstützt	Unterstützt	Unterstützt	Unterstützt	Unterstützt (Unterstützt/ Unterstützt)
	Sich unterhalten	Nicht unterstützt	Nicht unterstützt	Unterstützt	Unterstützt	Unterstützt	Nicht unterstützt (Nicht unterstützt/ Unterstützt)
Gängige Einstellungen	Alle Funktionen	Unterstützt	Unterstützt	Unterstützt	Unterstützt	Unterstützt	Unterstützt

GERÄTETYP SETUP-GUIDE

Siehe die Tabelle unten zum Verbinden Ihres Encoders mit SSM.


Für weitere Details, siehe „Einstellen des Systems“ im Benutzerhandbuch.

	SSM 2.0 oder niedriger	SSM 2.1 oder höher
Gerätetyp	NWC	Encoder

PRODUKTANSICHT


SPE-410

Einheit: mm [inch]



SPE-1610

Einheit: mm [inch]



FEHLERSUCHE

PROBLEM	LÖSUNG
Wenn ein Benutzer von Windows 10 über Chrome oder Firefox auf den Webviewer zugreift, ändert sich von Zeit zu Zeit die Lautstärke des Mikrofons.	Dies geschieht, wenn der Mikrofontreiber auf Realtek-Treiber festgelegt wurde. Installieren Sie das High Definition Audio-Gerät (Standardtreiber von Windows) oder den Dritttreiber als Mikrofontreiber.
Wenn Sie unter Safari per HTML auf den Plug-in-freien Webviewer zugreifen, wird kein Video angezeigt.	- Bei dem ersten Zugriff auf HTTPS klicken Sie im Pop-up-Fenster zu Authentifizierung auf "Authentifizierungszertifikat anzeigen" und wählen Sie das Feld "Beim Verbinden zur IP des designierten Webviewers immer vertrauen" aus. - Wenn im Webviewer weiterhin kein Video angezeigt wird, nachdem Sie im Nachrichtenfenster unten "Weiter" ausgewählt haben, klicken Sie auf die Befehlstaste + Q, um den Safari-Browser zu verlassen. Rufen Sie ihn dann erneut auf und folgen Sie den oben angegebenen Schritten.
Ich kann über einen Webbrowser nicht auf den Encoder zugreifen.	- Überprüfen Sie, ob die Netzwerkeinstellungen des Encoders geeignet sind. - Kontrollieren Sie, ob alle Netzkabel korrekt angeschlossen wurden. - Stellen Sie bei einer Verbindung mit einem DHCP sicher, dass der Encoder problemlos dynamische IP-Adressen beschaffen kann. - Falls der Encoder mit einem Breitbandrouter verbunden wird, überprüfen Sie, ob die Port-Weiterleitung vorschriftsmäßig konfiguriert wurde.
Der Viewer wurde während der Überwachung getrennt.	- Verbundene Viewer werden nach etwaigen Änderungen an der Encoder oder den Netzwerkkonfigurationen getrennt. - Prüfen Sie alle Netzwerkverbindungen. - Wann immer der Encoder über ein PPPoE-Netzwerk verbunden wird, kann der Viewer wegen schlechten Netzwerkbedingungen die Verbindung verlieren.
Der mit dem Netzwerk verbundene Encoder wird im IP-Installationsprogramm nicht erkannt.	Deaktivieren Sie die Firewall-Einstellungen auf Ihrem PC und lassen Sie erneut nach dem Encoder suchen.
Die Bilder überlappen.	Überprüfen Sie, ob zwei oder mehr Encoder auf eine identische Multicast-Adresse anstatt auf verschiedene Adressen eingestellt wurden. Falls eine einzelne Adresse für mehrere Encoder verwendet wird, können sich die Images überschneiden.

PROBLEM	LÖSUNG
Es wird kein Bild eingeblendet.	Falls die Übertragungsmethode auf Multicast eingestellt wird, müssen Sie prüfen, ob ein Router vorhanden ist, der Multicast in jenem LAN unterstützt, mit dem der Encoder verbunden ist.
Stimme wird nicht aufgezeichnet, obwohl die Audio-Eingabeeinstellungen konfiguriert wurden.	Sie müssen das <Audioeingang>-Kontrollkästchen im <Basic> - <Video profil> auswählen.
<Bewegungserkennung> des <Analyse> ist auf <Aktivieren> eingestellt, doch haben mich keine E-Mails mit Benachrichtigungen erreicht, selbst wenn ein Analyse-Ereignis eingetreten ist.	- Überprüfen Sie die Einstellungen in der folgenden Reihenfolge: A. Prüfen Sie die Einstellungen unter <Datum & Uhrzeit>. B. Die <Bewegungserkennung> muss auf <Aktivieren> gestellt sein. C. Prüfen Sie, ob die Option <E-mail> im <Ereigniseinrichtung> Menü markiert ist.
Das System schaltet sich nicht ein und die Anzeige an der Vorderseite funktioniert nicht.	- Überprüfen Sie, ob die Stromversorgung richtig angeschlossen ist. - Überprüfen Sie das System hinsichtlich der Eingangsspannung von der Stromquelle. - Sollte das Problem auch nach Durchführung der oben genannten Maßnahmen weiterhin bestehen, überprüfen Sie den Stromversorger und ersetzen Sie ihn gegebenenfalls durch einen neuen.
Das Video wird eingegeben, aber einige Kanäle geben kein Video aus und zeigen stattdessen einen Videoverlustbildschirm an.	- Überprüfen Sie, ob die an den Encoder angeschlossene Kamera das Bild korrekt anzeigt. Dieses Problem kann bei einer Kamera, die nicht ordnungsgemäß mit der Videoquelle verbunden ist, gelegentlich auftreten. - Überprüfen Sie, ob die Kamera ordnungsgemäß mit Strom versorgt wird. - Dieses Problem kann gelegentlich an einem Kanal mit schwachem Videosignal von einem Videoverteiler auftreten, der mit mehreren Systemen verbunden ist. In diesem Fall geben Sie die Videoquelle der Kamera direkt in den Encoder ein. Diese Vorgehensweise kann die Ursache möglicherweise finden und das Problem lösen.
Es erfolgt keine Antwort, selbst wenn ich auf das [PTZ]-Menü im Live-Bildschirm klicke.	Einrichtung → PTZ → Externer PTZ → Überprüfen Sie, ob die aktuellen Protokolle und die weiteren Einstellungen im PTZ-Gerät entsprechend der PTZ-Kamera vorschriftsmäßig konfiguriert wurden.
Ich habe das Passwort vergessen.	- Wenden Sie sich an den Encoder Administrator, um Unterstützung zu erhalten. - Führen Sie einen Factory Reset durch indem Sie die [RESET]-Taste drücken. Bitte beachten Sie, dass dadurch auch die Einstellwerte initialisiert werden.

OPEN SOURCE ANNOUNCEMENT

GPL/LGPL software license

The software included in this product contains copyrighted software that is licensed under the GPL/LGPL. You may obtain the complete Corresponding Source code from us for a period of three years after our last shipment of this product by sending email to help.cctv@hanwha.com

If you want to obtain the complete Corresponding Source code in the physical medium such as CD-ROM, the cost of physically performing source distribution might be charged.

GPL SW

Component Name	License	URL
Base Kernel	GPL 2.0	
Busybox	GPL 2.0	http://www.busybox.net/downloads/snapshots
iproute2-4.3.0	GPL 2.0	
iptables-1.4.21	GPL 2.0	http://ftp.netfilter.org/pub/iptables
ethtool-4.2	GPL 2.0	
mtdd-1.5.2	GPL 2.0	ftp://ftp.infradead.org/pub/mtdd-utils
mi-diag-2.11	GPL 2.0	
rp-pppoe-3.11	GPL 2.0	http://www.roaringpenguin.com/pppoe/
wpa_supplicant-2.5	GPL 2.0	
bash-4.3.30	GPL 3.0	
zeroconf	GPL 2.0	

LGPL SW

Component Name	License	URL
glibc	LGPL 2.0	
inetutils	LGPL 3.0	
neon-0.29.6	LGPL 2.0	http://www.webdav.org/neon/

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C)1989, 1991 Free Software Foundation, Inc. 51 Franklin Street,Fifth Floor, Boston, MA 02110-1301, USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too. When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs ; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have.

You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights. We protect your rights with two steps :

(1)Copyright the software, and (2)offer you this license which gives you legal permission to copy, distribute and/or modify the software. Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all. The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

Version 2, June 1991 Copyright (C) 1989, 1991 Free Software Foundation, Inc. 51 Franklin St

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License.

The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law : that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you". Activities other than copying, distribution and modification are not covered by this License ; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty ; and give any other recipients of the Program a copy of this License along with the Program. You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.
2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions :
 - a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
 - b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
 - c) If the modified program normally reads commands interactively when run,you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception:if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you ; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program. In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program)on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2)in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following :
 - a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange ; or,
 - b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machinereadable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange ; or,
 - c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.) The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major

components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable. If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License.

However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works.

These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all.

For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances. It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice. This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms. To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found. One line to give the program's name and an idea of what it does.

Copyright (C)yyyy name of author

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA.

Also add information on how to contact you by electronic and paper mail. If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'. This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouse-clicks or menu items—whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program 'Gnomovision' (which makes passes at compilers) written by James Hacker. signature of Ty Coon, 1 April 1989 Ty Coon, President of Vice This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is the case, you want to do, use the GNU Lesser General Public License instead of this License.

GNU GENERAL PUBLIC LICENSE

Version 3, 29 June 2007

Copyright (C) 2007 Free Software Foundation, Inc. <<http://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The GNU General Public License is a free, copyleft license for software and other kinds of works. The licenses for most software and other practical works are designed to take away your freedom to share and change the works. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change all versions of a program—to make sure it remains free software for all its users.

We, the Free Software Foundation, use the GNU General Public License for most of our software; it applies also to any other work released this way by its authors.

You can apply it to your programs, too. When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for them if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs, and that you know you can do these things.

To protect your rights, we need to prevent others from denying you these rights or asking you to surrender the rights. Therefore, you have certain responsibilities if you distribute copies of the software, or if you modify it: responsibilities to respect the freedom of others. For example, if you distribute copies of such a program, whether gratis or for a fee, you must pass on to the recipients the same freedoms that you received. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights. Developers that use the GNU GPL protect your rights with two steps: (1) assert copyright on the software, and (2) offer you this License giving you legal permission to copy, distribute and/or modify it. For the developers' and authors' protection, the GPL clearly explains that there is no warranty for this free software. For both users' and authors' sake, the GPL requires that modified versions be marked as changed, so that their problems will not be attributed erroneously to authors of previous versions. Some devices are designed to deny users access to install or run modified versions of the software inside them, although the manufacturer can do so. This is fundamentally incompatible with the aim of protecting users' freedom to change the software. The systematic pattern of such abuse occurs in the area of products for individuals to use, which is precisely where it is most unacceptable. Therefore, we have designed this version of the GPL to prohibit the practice for those products. If such problems arise substantially in other domains, we stand ready to extend this provision to those domains in future versions of the GPL, as needed to protect the freedom of users.

Finally, every program is threatened constantly by software patents. States should not allow patents to restrict development and use of software on general-purpose computers, but in those that do, we wish to avoid the special anger that patents applied to a free program could make it effectively proprietary. To prevent this, the GPL assures that patents cannot be used to render the program non-free. It precisely terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS

0. Definitions.

"This License" refers to version 3 of the GNU General Public License.

Copyright" also means copyright-like laws that apply to other kinds of works, such as semiconductor masks. "The Program" refers to any copyrightable work licensed under this License. Each licensee is addressed as "you". "Licensees" and "recipients" may be individuals or organizations.

To "modify" a work means to copy from or adapt all or part of the work in a fashion requiring copyright permission, other than the making of an exact copy. The resulting work is called a "modified version" of the earlier work or a work "based on" the earlier work.

A "covered work" means either the unmodified Program or a work based on the Program.

To "propagate" a work means to do anything with it that, without permission, would make you directly or secondarily liable for infringement under applicable copyright law, except executing it on a computer or modifying a private copy.

Propagation includes copying, distribution (with or without modification), making available to the public, and in some countries other activities as well.

To "convey" a work means any kind of propagation that enables other parties to make or receive copies. Mere interaction with a user through a computer network, with no transfer of a copy, is not conveying. An interactive user interface displays "Appropriate Legal Notices" to the extent that it includes a convenient and prominently visible feature that (1) displays an appropriate copyright notice, and (2) tells the user that there is no warranty for the work (except to the extent that warranties are provided), that licensees may convey the work under this License, and how to view a copy of this License. If the interface presents a list of user commands or options, such as a menu, a prominent item in the list meets this criterion.

1. Source Code.

The "source code" for a work means the preferred form of the work for making modifications to it. "Object code" means any non-source form of a work.

A "Standard Interface" means an interface that either is an official standard defined by a recognized standards body, or, in the case of interfaces specified for a particular programming language, one that is widely used among developers working in that language.

The "System Libraries" of an executable work include anything, other than the work as a whole, that (a) is included in the normal form of packaging a Major Component, but which is not part of that Major Component, and (b) serves only to enable use of the work with that Major Component, or to implement a Standard Interface for which an implementation is available to the public in source code form. A "Major Component", in this context, means a major essential component (kernel, window system, and so on) of the specific operating system (if any) on which the executable work runs, or a compiler used to produce the work, or an object code interpreter used to run it.

The "Corresponding Source" for a work in object code form means all the source code needed to generate, install, and (for an executable work) run the object code and to modify the work, including scripts to control those activities.

However, it does not include the work's System Libraries, or generalpurpose tools or generally available free programs which are used unmodified in performing those activities but which are not part of the work. For example, Corresponding Source includes interface definition files associated with source files for the work, and the source code for shared libraries and dynamically linked subprograms that the work is specifically designed to require, such as by intimate data communication or control flow between those subprograms and other parts of the work.

The Corresponding Source need not include anything that users can regenerate automatically from other parts of the Corresponding Source. The Corresponding Source for a work in source code form is that same work.

2. Basic Permissions.

All rights granted under this License are granted for the term of copyright on the Program, and are irrevocable provided the stated conditions are met. This License explicitly affirms your unlimited permission to run the unmodified Program. The output from running a covered work is covered by this License only if the output, given its content, constitutes a covered work. This License acknowledges your rights of fair use or other equivalent, as provided by copyright law.

You may make, run and propagate covered works that you do not convey, without conditions so long as your license otherwise remains in force. You may convey covered works to others for the sole purpose of having them make modifications exclusively for you, or provide you with facilities for running those works, provided that you comply with the terms of this License in conveying all material for which you do not control copyright. Those thus making or running the covered works for you must do so exclusively on your behalf, under your direction and control, on terms that prohibit them from making any copies of your copyrighted material outside their relationship with you. Conveying under any other circumstances is permitted solely under the conditions stated below. Sublicensing is not allowed; section 10 makes it unnecessary.

3. Protecting Users' Legal Rights From anti-Circumvention Law.

No covered work shall be deemed part of an effective technological measure under any applicable law fulfilling obligations under article 11 of the WIPO copyright treaty adopted on 20 December 1996, or similar laws prohibiting or restricting circumvention of such measures.

When you convey a covered work, you waive any legal power to forbid circumvention of technological measures to the extent such circumvention is effected by exercising rights under this License with respect to the covered work, and you disclaim any intention to limit operation or modification of the work as a means of enforcing, against the work's users, your or third parties' legal rights to forbid circumvention of technological measures.

4. Conveying Verbatim Copies.

You may convey verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice; keep intact all notices stating that this License and any non-permissive terms added in accord with section 7 apply to the code; keep intact all notices of the absence of any warranty; and give all recipients a copy of this License along with the Program. You may charge any price or no price for each copy that you convey, and you may offer support or warranty protection for a fee.

5. Conveying Modified Source Versions.

You may convey a work based on the Program, or the modifications to produce it from the Program, in the form of source code under the terms of section 4, provided that you also meet all of these conditions:

- The work must carry prominent notices stating that you modified it, and giving a relevant date.
- The work must carry prominent notices stating that it is released under this License and any conditions added under section 7. This requirement modifies the requirement in section 4 to "keep intact all notices".
- You must license the entire work, as a whole, under this License to anyone who comes into possession of a copy. This License will therefore apply, along with any applicable section 7 additional terms, to the whole of the work, and all its parts, regardless of how they are packaged. This License gives no permission to license the work in any other way, but it does not invalidate such permission if you have separately received it.
- If the work has interactive user interfaces, each must display Appropriate Legal Notices; however, if the Program has interactive interfaces that do not display Appropriate Legal Notices, your work need not make them do so. A compilation of a covered work with other separate and independent works, which are not by their nature extensions of the covered work, and which are not combined with it such as to form a larger program, in or on a volume of a storage or distribution medium, is called an "aggregate" if the compilation and its resulting copyright are not used to limit the access to legal rights of the compilation's users beyond what the individual works permit. Inclusion of a covered work in an aggregate does not cause this License to apply to the other parts of the aggregate.

6. Conveying Non-Source Forms.

You may convey a covered work in object code form under the terms of sections 4 and 5, provided that you also convey the machine-readable Corresponding Source under the terms of this License, in one of these ways:

- Convey the object code in, or embodied in, a physical product (including a physical distribution medium), accompanied by the Corresponding Source fixed on a durable physical medium customarily used for software interchange.
- Convey the object code in, or embodied in, a physical product (including a physical distribution medium), accompanied by a written offer, valid for at least three years and valid for as long as you offer spare parts or customer support for that product model, to give anyone who possesses the object code either (1) a copy of the Corresponding Source for all the software in the product that is covered by this License, on a durable physical medium customarily used for software interchange, for a price no more than your reasonable cost of physically performing this conveying of source, or (2) access to copy the Corresponding Source from a network server at no charge.
- Convey individual copies of the object code with a copy of the written offer to provide the corresponding Source. This alternative is allowed only occasionally and noncommercially, and only if you received the object code with such an offer, in accord with subsection 6b.
- Convey the object code by offering access from a designated place (gratis or for a charge), and offer equivalent access to the Corresponding Source in the same way through the same place at no further charge. You need not require recipients to copy the Corresponding Source along with the object code. If the place to copy the object code is a network server, the Corresponding Source may be on a different server (operated by you or a third party) that supports equivalent copying facilities, provided you maintain clear directions next to the object code saying where to find the Corresponding Source. Regardless of what server hosts the Corresponding Source, you remain obligated to ensure that it is available for as long as needed to satisfy these requirements.
- Convey the object code using peer-to-peer transmission, provided you inform other peers where the object code and Corresponding Source of the work are being offered to the general public at no charge under subsection 6d. A separable portion of the object code, whose source code is excluded from the Corresponding Source as a System Library, need not be included in conveying the object code work. A "User Product" is either (1) a "consumer product", which means any tangible personal property which is normally used for personal, family, or household purposes, or (2) anything designed or sold for incorporation into a dwelling. In determining whether a product is a consumer product, doubtful cases shall be resolved in favor of coverage. For a particular product received by a particular user, "normally used" refers to a typical or common use of that class of product, regardless of the status of the particular user or of the way in which the particular user actually uses, or expects or is expected to use, the product. A product is a consumer product regardless of whether the product has substantial commercial, industrial or non-consumer uses, unless such uses represent the only significant mode of use of the product.

"Installation Information" for a User Product means any methods, procedures, authorization keys, or other information required to install and execute modified versions of a covered work in that User Product from a modified version of its Corresponding Source. The information must suffice to ensure that the continued functioning of the modified object code is in no case prevented or interfered with solely because modification has been made. If you convey an object code work under this section in, or with, or specifically for use in, a User Product, and the conveying occurs as part of a transaction in which the right of possession and use of the User Product is transferred to the recipient in perpetuity or for a fixed term (regardless of how the transaction is characterized), the Corresponding Source conveyed under this section must be accompanied by the Installation Information. But this requirement does not apply if neither you nor any third party retains the ability to install modified object code on the User Product (for example, the work has been installed in ROM).

The requirement to provide Installation Information does not include a requirement to continue to provide support service, warranty, or updates for a work that has been modified or installed by the recipient, or for the User Product in which it has been modified or installed. Access to a network may be denied when the modification itself materially and adversely affects the operation of the network or violates the rules and protocols for communication across the network. Corresponding Source conveyed, and Installation Information provided, in accord with this section must be in a format that is publicly documented (and with an implementation available to the public in source code form), and must require no special password or key for unpacking, reading or copying.

7. Additional Terms.

"Additional permissions" are terms that supplement the terms of this License by making exceptions from one or more of its conditions. Additional permissions that are applicable to the entire Program shall be treated as though they were included in this License, to the extent that they are valid under applicable law. If additional permissions apply only to part of the Program, that part may be used separately under those permissions, but the entire Program remains governed by this License without regard to the additional permissions. When you convey a copy of a covered work, you may at your option remove any additional permissions from that copy, or from any part of it. (Additional permissions may be written to require their own removal in certain cases when you modify the work.) You may place additional permissions on material, added by you to a covered work, for which you have or can give appropriate copyright permission. Notwithstanding any other provision of this License, for material you add to a covered work, you may (if authorized by the copyright holders of that material) supplement the terms of this License with terms:

- Disclaiming warranty or limiting liability differently from the terms of sections 15 and 16 of this License; or
- Requiring preservation of specified reasonable legal notices or author attributions in that material or in the Appropriate Legal Notices displayed by works containing it; or
- Prohibiting misrepresentation of the origin of that material, or requiring that modified versions of such material be marked in reasonable ways as different from the original version; or
- Limiting the use for publicity purposes of names of licensors or authors of the material; or
- Declining to grant rights under trademark law for use of some trade names, trademarks, or service marks; or
- Requiring indemnification of licensors and authors of that material by anyone who conveys the material (or modified versions of it) with contractual assumptions of liability to the recipient, for any liability that these contractual assumptions directly impose on those licensors and authors. All other non-permissive additional terms are considered "further restrictions" within the meaning of section 10. If the Program as you received it, or any part of it, contains a notice stating that it is governed by this License along with a term that is a further restriction, you may remove that term. If a license document contains a further restriction but permits relicensing or conveying under this License, you may add to a covered work material governed by the terms of that license document, provided that the further restriction does not survive such relicensing or conveying. If you add terms to a covered work in accord with this section, you must place, in the relevant source files, a statement of the additional terms that apply to those files, or a notice indicating where to find the applicable terms. Additional terms, permissive or non-permissive, may be stated in the form of a separately written license, or stated as exceptions; the above requirements apply either way.

8. Termination.

You may not propagate or modify a covered work except as expressly provided under this License. Any attempt otherwise to propagate or modify it is void, and will automatically terminate your rights under this License (including any patent licenses granted under the third paragraph of section 11).

However, if you cease all violation of this License, then your license from a particular copyright holder is reinstated (a) provisionally, unless and until the copyright holder explicitly and finally terminates your license, and (b) permanently, if the copyright holder fails to notify you of the violation by some reasonable means prior to 60 days after the cessation. Moreover, your license from a particular copyright holder is reinstated permanently if the copyright holder notifies you of the violation by some reasonable means, this is the first time you have received notice of violation of this License for any work from that copyright holder, and you cure the violation prior to 30 days after your receipt of the notice. Termination of your rights under this section does not terminate the licenses of parties who have received copies or rights from you under this License. If your rights have been terminated and not permanently reinstated, you do not qualify to receive new licenses for the same material under section 10.

9. Acceptance Not Required for Having Copies.

You are not required to accept this License in order to receive or run a copy of the Program. Ancillary propagation of a covered work occurring solely as a consequence of using peer-to-peer transmission to receive a copy likewise does not require acceptance. However, nothing other than this License grants you permission to propagate or modify any covered work. These actions infringe copyright if you do not accept this License. Therefore, by modifying or propagating a covered work, you indicate your acceptance of this License to do so.

10. Automatic Licensing of Downstream Recipients.

Each time you convey a covered work, the recipient automatically receives a license from the original licensors, to run, modify and propagate that work, subject to this License. You are not responsible for enforcing compliance by third parties with this License. An "entity transaction" is a transaction transferring control of an organization, or substantially all assets of one, or subdividing an organization, or merging organizations. If propagation of a covered work results from an entity transaction, each party to that transaction who receives a copy of the work also receives whatever licenses to the work the party's predecessor in interest had or could give under the previous paragraph, plus a right to possession of the Corresponding Source of the work from the predecessor in interest, if the predecessor has it or can get it with reasonable efforts. You may not impose any further restrictions on the exercise of the rights granted or affirmed under this License. For example, you may not impose a license fee, royalty, or other charge for exercise of rights granted under this License, and you may not initiate litigation (including a cross-claim or counterclaim in a lawsuit) alleging that any patent claim is infringed by making, using, selling, offering for sale, or importing the Program or any portion of it.

11. Patents.

A "contributor" is a copyright holder who authorizes use under this License of the Program or a work on which the Program is based. The work thus licensed is called the contributor's "contributor version". A contributor's "essential patent claims" are all patent claims owned or controlled by the contributor, whether already acquired or hereafter acquired, that would be infringed by some manner, permitted by this License, of making, using, or selling its contributor version, but do not include claims that would be infringed only as a consequence of further modification of the contributor version. For purposes of this definition, "control" includes the right to grant patent sublicenses in a manner consistent with the requirements of this License. Each contributor grants you a non-exclusive, worldwide, royalty-free patent license under the contributor's essential patent claims, to make, use, sell, offer for sale, import and otherwise run, modify and propagate the contents of its contributor version.

In the following three paragraphs, a "patent license" is any express agreement or commitment, however denominated, not to enforce a patent (such as an express permission to practice a patent or covenant not to sue for patent infringement). To "grant" such a patent license to a party means to make such an agreement or commitment not to enforce a patent against the party. If you convey a covered work, knowingly relying on a patent license, and the Corresponding Source of the work is not available for anyone to copy, free of charge and under the terms of this License, through a publicly available network server or other readily accessible means, then you must either (1) cause the Corresponding Source to be so available, or (2) arrange to deprive yourself of the benefit of the patent license for this particular work, or (3) arrange, in a manner consistent with the requirements of this License, to extend the patent license to downstream recipients. "Knowingly relying" means you have actual knowledge that, but for the patent license, your conveying the covered work in a country, or your recipient's use of the covered work in a country, would infringe one or more identifiable patents in that country that you have reason to believe are valid. If, pursuant to or in connection with a single transaction or arrangement, you convey, or propagate by procuring conveyance of, a covered work, and grant a

patent license to some of the parties receiving the covered work authorizing them to use, propagate, modify or convey a specific copy of the covered work, then the patent license you grant is automatically extended to all recipients of the covered work and works based on it. A patent license is "discriminatory" if it does not include within the scope of its coverage, prohibits the exercise of, or is conditioned on the non-exercise of one or more of the rights that are specifically granted under this License. You may not convey a covered work if you are a party to an arrangement with a third party that is in the business of distributing software, under which you make payment to the third party based on the extent of your activity of conveying the work, and under which the third party grants, to any of the parties who would receive the covered work from you, a discriminatory patent license

- (a) in connection with copies of the covered work conveyed by you (or copies made from those copies), or
- (b) primarily for and in connection with specific products or compilations that contain the covered work, unless you entered into that arrangement, or that patent license was granted, prior to 28 March 2007. Nothing in this License shall be construed as excluding or limiting any implied license or other defenses to infringement that may otherwise be available to you under applicable patent law.

12. No Surrender of Others' Freedom.

If conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot convey a covered work so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not convey it at all. For example, if you agree to terms that obligate you to collect a royalty for further conveying from those to whom you convey the Program, the only way you could satisfy both those terms and this License would be to refrain entirely from conveying the Program.

13. Use with the GNU Affero General Public License.

Notwithstanding any other provision of this License, you have permission to link or combine any covered work with a work licensed under version 3 of the GNU Affero General Public License into a single combined work, and to convey the resulting work. The terms of this License will continue to apply to the part which is the covered work, but the special requirements of the GNU Affero General Public License, section 13, concerning interaction through a network will apply to the combination as such.

14. Revised Versions of this License.

The Free Software Foundation may publish revised and/or new versions of the GNU General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies that a certain numbered version of the GNU General Public License "or any later version" applies to it, you have the option of following the terms and conditions either of that numbered version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of the GNU General Public License, you may choose any version ever published by the Free Software Foundation. If the Program specifies that a proxy can decide which future versions of the GNU General Public License can be used, that proxy's public statement of acceptance of a version permanently authorizes you to choose that version for the Program. Later license versions may give you additional or different permissions. However, no additional obligations are imposed on any author or copyright holder as a result of your choosing to follow a later version.

15. Disclaimer of Warranty.

THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. Limitation of Liability.

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MODIFIES AND/OR CONVEYS THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

17. Interpretation of Sections 15 and 16.

If the disclaimer of warranty and limitation of liability provided above cannot be given local legal effect according to their terms, reviewing courts shall apply local law that most closely approximates an absolute waiver of all civil liability in connection with the Program, unless a warranty or assumption of liability accompanies a copy of the Program in return for a fee.

OpenSSL Combined License

The OpenSSL toolkit stays under a dual license, i.e. both the conditions of the OpenSSL License and the original SSLeay license apply to the toolkit. See below for the actual license texts. Actually both licenses are BSD-style Open Source licenses. In case of any license issues related to OpenSSL please contact openssl-core@openssl.org.		
Component Name	License	URL
openssl-1.0.2e	OpenSSL	Combined License http://www.openssl.org/source

Copyright (c) 1998-2011 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment: "This product includes software developed by the OpenSSL Project or use in the OpenSSL Toolkit. (<http://www.openssl.org/>)"
4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact openssl-core@openssl.org.
5. Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.

6. Redistributions of any form whatsoever must retain the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>)"

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young(ey@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

Original SSLeay License

Copyright (C) 1995-1998 Eric Young (ey@cryptsoft.com). All rights reserved.

This package is an SSL implementation written by Eric Young (ey@cryptsoft.com).

The implementation was written so as to conform with Netscapes SSL.

This library is free for commercial and non-commercial use as long as the following conditions are aheared to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed. If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: "This product includes cryptographic software written by Eric Young (ey@cryptsoft.com)" The word 'cryptographic' can be left out if the routines from the library being used are not cryptographic related :-).
4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement: "This product includes software written by Tim Hudson (tjh@cryptsoft.com)"

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The licence and distribution terms for any publicly available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution licence [including the GNU Public Licence.]

BSD License

Some software components of this product incorporate source code covered under the BSD license as follows.

Component Name	License	URL
net-snmp-5.7.3	BSD	http://www.net-snmp.org/about/license.html
pcrc-8.38	BSD	
libcap-1.7.4	BSD 2.0	http://www.kernel.org/pub/linux/libs/security/linux-privs/libcap2
lighttpd-1.4.35	BSD 2.0	http://www.opensource.org/licenses/bsd-license.html
MiniUPnP Project Client	BSD 2.0	
pppd-2.4.7	BSD 2.0	http://opensource.org/licenses/BSD-3-Clause

lighttpd is a secure, fast, compliant, and very flexible webserver that has been optimized for high-performance environments. It has a very low memory footprint compared to other webserver and takes care of opload. Its advanced feature-set (FastCGI, CGI, Auth, Output-Compression, URL-Rewriting and many more) make lighttpd the perfect webserver-software for every server that suffers load problems. Simple Network Management Protocol (SNMP) is an Internetstandard protocol for managing devices on IP networks. It is used mostly in network management systems to monitor the devices attached to the network for conditions that need administrative attention. Net-SNMP is a suite of applications used to implement SNMP v1, SNMP v2c and SNMP v3 using both IPv4 and IPv6. For more additional information, send email to help.cctv@hanwha.com.

Copyright (C) 2004, Kneschke, incremental

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met :

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the 'incremental' nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 1998-2001 University College London

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, is permitted provided that the following conditions are met :

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: This product includes software developed by the Computer Science Department at University College London.
4. Neither the name of the University nor of the Department may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHORS AND CONTRIBUTORS "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHORS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 1988, 1989, 1990, 1991, 1993, 1994, 1995, 1996 The Regents of the University of California.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the Regents of the University of California nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2006, Creative Labs Inc

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the Creative Labs nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2005-2012, Thomas BERNARD

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of Thomas BERNARD nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR

TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Various copyrights apply to this package, listed in various separate parts below. Please make sure that you read all the parts.

Part 1 : CMU/UCD copyright notice: (BSD like)

Copyright 1989, 1991, 1992 by Carnegie Mellon University Derivative Work - 1996, 1998-2000

Copyright 1996, 1998-2000 The Regents of the University of California

All Rights Reserved

Permission to use, copy, modify and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appears in all copies and that both that copyright notice and this permission notice appear in supporting documentation, and that the name of CMU and The Regents of the University of California not be used in advertising or publicity pertaining to distribution of the software without specific written permission.

CMU AND THE REGENTS OF THE UNIVERSITY OF CALIFORNIA DISCLAIM ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL CMU OR THE REGENTS OF THE UNIVERSITY OF CALIFORNIA BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM THE LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Part 2 : Networks Associates Technology, Inc copyright notice (BSD)

Copyright (c) 2001-2003, Networks Associates Technology, Inc

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: yy Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. yy Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. yy Neither the name of the Networks Associates Technology, Inc nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Part 3 : Cambridge Broadband Ltd. copyrightnotice (BSD)

Portions of this code are copyright (c) 2001-2003, Cambridge Broadband Ltd.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: yy Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. yy Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. yy The name of Cambridge Broadband Ltd. may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Part 4 : Sun Microsystems, Inc. copyright notice (BSD)

(BSD)

Copyright (c) 2003 Sun Microsystems, Inc., 4150 Network

Circle, Santa Clara, California 95054, U.S.A.

All rights reserved.

Use is subject to license terms below. This distribution may include materials developed by third parties. Sun, Sun Microsystems, the Sun logo and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: yy Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. yy Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. yy Neither the name of the Sun Microsystems, Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Part 5 : Sparta, Inc copyright notice (BSD)

Copyright (c) 2003-2009, Sparta, Inc

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: yy Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. yy Redistributions in binary form must reproduce the

above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. yy Neither the name of Sparta, Inc nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Part 6: Cisco/BUPTNIC copyright notice (BSD)

Copyright (c) 2004, Cisco, Inc and Information Network

Center of Beijing University of Posts and Telecommunications.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: yy Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. yy Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. yy Neither the name of Cisco, Inc, Beijing University of Posts and Telecommunications, nor the names of their contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Part 7: Fabasoft R&D Software Software GmbH & Co KG copyright Notice (BSD)

Copyright (c) Fabasoft R&D Software GmbH & Co KG, 2003oss@fabasoft.com

Author: Bernhard Penz

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: yy Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. yy Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. yy The name of Fabasoft R&D Software GmbH & Co KG or any of its subsidiaries, brand or product names may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Part 8: Apple Inc. copyright notice (BSD)

Copyright (c) 2007 Apple Inc.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. 3. Neither the name of Apple Inc. ("Apple") nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY APPLE AND ITS CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL APPLE OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Part 9: ScienceLogic, LLC copyright notice(BSD)

Copyright (c) 2009, ScienceLogic, LLC

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: yy Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. yy Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. yy Neither the name of ScienceLogic, LLC nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE

The MIT License

Some software components of this product incorporate source code covered under the MIT license as follows

MIT License 2.0

- Acewidget, bettermeans, jquery-ui, libxml, libxml2, Mesa3D-MesaLib,mwEmbed,OpenGL Samples Pack, Wide Studio, xorg-server, dropbear-2012.55, ncurses-5.7

Copyright (c) 2011, The Dojo Foundation

Copyright 2010, AUTHORS.txt (<http://jqueryui.com/about>)

Dual licensed under the MIT or GPL Version 2 licenses.

- <http://jquery.org/license>

- <http://docs.jquery.com/UI/Widget>

Copyright Daniel Veillard

Copyright Igor Zlatovic <igor@zlatkovic.com>

Copyright Aleksey Sarin

Copyright Gary Pennington <Gary.Pennington@uk.sun.com>

Copyright Alfred Mickautsch <alfred@mickautsch.de>

Copyright Bjorn Reese <bjorn.reese@systematic.dk>

Copyright Joel W. Reed

Copyright William Brack <wbrack@mmm.com.hk>

Copyright (c) 2007-2010 The Khronos Group Inc.

Copyright Atish Kumar Patra

Copyright (c) 2006 Free Software Foundation, Inc.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Mozilla Public License

Since we, at Hanwha Techwin, used the Mozilla Firefox component without modifying the source code according to the MOZILLA Public license 1.1, we are not obliged to provide the source code of the corresponding component.

- Version 1.1

1. Definitions.

1.0.1. "Commercial Use" means distribution or otherwise making the Covered Code available to a third party.

1.1. "Contributor" means each entity that creates or contributes to the creation of Modifications.

1.2. "Contributor Version" means the combination of the Original Code, prior Modifications used by a Contributor, and the Modifications made by that particular Contributor.

1.3. "Covered Code" means the Original Code or Modifications or the combination of the Original Code and Modifications, in each case including portions thereof.

1.4. "Electronic Distribution Mechanism" means a mechanism generally accepted in the software development community for the electronic transfer of data.

1.5. "Executable" means Covered Code in any form other than Source Code.

1.6. "Initial Developer" means the individual or entity identified as the Initial Developer in the Source Code notice required by Exhibit A.

1.7. "Larger Work" means a work which combines Covered Code or portions thereof with code not governed by the terms of this License.

1.8. "License" means this document.

1.8.1. "Licensable" means having the right to grant, to the maximum extent possible, whether at the time of the initial grant or subsequently acquired, any and all of the rights conveyed herein.

1.9. "Modifications" means any addition to or deletion from the substance or structure of either the Original Code or any previous Modifications. When Covered Code is released as a series of files, a Modification is:

A. Any addition to or deletion from the contents of a file containing Original Code or previous Modifications.

B. Any new file that contains any part of the Original Code or previous Modifications.

1.10. "Original Code" means Source Code of computer software code which is described in the Source Code notice required by Exhibit A as Original Code, and which, at the time of its release under this License is not already Covered Code governed by this License.

1.10.1. "Patent Claims" means any patent claim(s), now owned or hereafter acquired, including without limitation, method, process, and apparatus claims, in any patent Licensable by grantor.

1.11. "Source Code" means the preferred form of the Covered Code for making modifications to it, including all modules it contains, plus any associated interface definition files, scripts used to control compilation and installation of an Executable, or source code differential comparisons against either the Original Code or another well known, available Covered Code of the Contributor's choice. The Source Code can be in a compressed or archival form, provided the appropriate decompression or de-archiving software is widely available for no charge.

1.12. "You" (or "Your") means an individual or a legal entity exercising rights under, and complying with all of the terms of, this License or a future version of this License issued under Section 6.1. For legal entities, "You" includes any entity which controls, is controlled by, or is under common control with You. For purposes of this definition, "control" means (a) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (b) ownership of more than fifty percent (50%) of the outstanding shares or beneficial ownership of such entity.

2. Source Code License.

2.1. The Initial Developer Grant. The Initial Developer hereby grants You a world-wide, royalty-free, non-exclusive license, subject to third party intellectual property claims:

- (a) under intellectual property rights (other than patent or trademark) licensable by Initial Developer to use, reproduce, modify, display, perform, sublicense and distribute the Original Code (or portions thereof) with or without Modifications, and/or as part of a Larger Work; and
- (b) under Patents Claims infringed by the making, using or selling of Original Code, to make, have made, use, practice, sell, and offer for sale, and/or otherwise dispose of the Original Code (or portions thereof).
- (c) the licenses granted in this Section 2.1(a) and (b) are effective on the date Initial Developer first distributes Original Code under the terms of this License.

(d) Notwithstanding Section 2.1(b) above, no patent license is granted: 1) for code that You delete from the Original Code; 2) separate from the Original Code; or 3) for infringements caused by: i) the modification of the Original Code or ii) the combination of the Original Code with other software or devices.

2.2. Contributor Grant. Subject to third party intellectual property claims, each Contributor hereby grants You a world-wide, royalty-free, non-exclusive license

- (a) under intellectual property rights (other than patent or trademark) licensable by Contributor, to use, reproduce, modify, display, perform, sublicense and distribute the Modifications created by such Contributor (or portions thereof) either on an unmodified basis, with other Modifications, as Covered Code and/or as part of a Larger Work; and
- (b) under Patent Claims infringed by the making, using, or selling of Modifications made by that Contributor either alone and/or in combination with its Contributor Version (or portions of such combination), to make, use, sell, offer for sale, have made, and/or otherwise dispose of: 1) Modifications made by that Contributor (or portions thereof); and 2) the combination of Modifications made by that Contributor with its Contributor Version (or portions of such combination).
- (c) the licenses granted in Sections 2.2(a) and 2.2(b) are effective on the date Contributor first makes Commercial Use of the Covered Code.
- (d) Notwithstanding Section 2.2(b) above, no patent license is granted: 1) for any code that Contributor has deleted from the Contributor Version; 2) separate from the Contributor Version; 3) for infringements caused by: i) third party modifications of Contributor Version or ii) the combination of Modifications made by that Contributor with other software (except as part of the Contributor Version) or other devices; or 4) under Patent Claims infringed by Covered Code in the absence of Modifications made by that Contributor.

3. Distribution Obligations.

3.1. Application of License. The Modifications which You create or to which You contribute are governed by the terms of this License, including without limitation Section 2.2. The Source Code version of Covered Code may be distributed only under the terms of this License or a future version of this License released under Section 6.1, and You must include a copy of this License with every copy of the Source Code You distribute. You may not offer or impose any terms on any Source Code version that alters or restricts the applicable version of this License or the recipients' rights hereunder. However, You may include an additional document offering the additional rights described in Section 3.5.

3.2. Availability of Source Code. Any Modification which You create or to which You contribute must be made available in Source Code form under the terms of this License either on the same media as an Executable version or via an accepted Electronic Distribution Mechanism to anyone to whom you made an Executable version available; and if made available via Electronic Distribution Mechanism, must remain available for at least twelve (12) months after the date it initially became available, or at least six (6) months after a subsequent version of that particular Modification has been made available to such recipients. You are responsible for ensuring that the Source Code version remains available even if the Electronic Distribution Mechanism is maintained by a third party.

3.3. Description of Modifications. You must cause all Covered Code to which You contribute to contain a file documenting the changes You made to create that Covered Code and the date of any change. You must include a prominent statement that the Modification is derived, directly or indirectly, from Original Code provided by the Initial Developer and including the name of the Initial Developer in (a) the Source Code, and (b) in any notice in an Executable version or related documentation in which You describe the origin or ownership of the Covered Code.

3.4. Intellectual Property Matters

- (a) Third Party Claims. If Contributor has knowledge that a license under a third party's intellectual property rights is required to exercise the rights granted by such Contributor under Sections 2.1 or 2.2, Contributor must include a text file with the Source Code distribution titled "LEGAL" which describes the claim and the party making the claim in sufficient detail that a recipient will know whom to contact. If Contributor obtains such knowledge after the Modification is made available as described in Section 3.2, Contributor shall promptly modify the LEGAL file in all copies Contributor makes available thereafter and shall take other steps (such as notifying appropriate mailing lists or newsgroups) reasonably calculated to inform those who received the Covered Code that new knowledge has been obtained.
- (b) Contributor APIs. If Contributor's Modifications include an application programming interface and Contributor has knowledge of patent licenses which are reasonably necessary to implement that API, Contributor must also include this information in the LEGAL file.
- (c) Representations.

Contributor represents that, except as disclosed pursuant to Section 3.4(a) above, Contributor believes that Contributor's Modifications are Contributor's original creation(s) and/or Contributor has sufficient rights to grant the rights conveyed by this License.

3.5. Required Notices. You must duplicate the notice in Exhibit A in each file of the Source Code. If it is not possible to put such notice in a particular Source Code file due to its structure, then You must include such notice in a location (such as a relevant directory) where a user would be likely to look for such a notice. If You created one or more Modifications(s) You may add your name as a Contributor to the notice described in Exhibit A. You must also duplicate this License in any documentation for the Source Code where You describe recipients' rights or ownership rights relating to Covered Code. You may choose to offer, and to charge a fee for, warranty, support, indemnity or liability obligations to one or more recipients of Covered Code. However, You may do so only on Your own behalf, and not on behalf of the Initial Developer or any Contributor. You must make it absolutely clear than any such warranty, support, indemnity or liability obligation is offered by You alone, and You hereby agree to indemnify the Initial Developer and every Contributor for any liability incurred by the Initial Developer or such Contributor as a result of warranty, support, indemnity or liability terms You offer.

3.6. Distribution of Executable Versions. You may distribute Covered Code in Executable form only if the requirements of Section 3.1-3.5 have been met for that Covered Code, and if You include a notice stating that the Source Code version of the Covered Code is available under the terms of this License, including a description of how and where You have fulfilled the obligations of Section 3.2. The notice must be conspicuously included in any notice in an Executable version, related documentation or collateral in which You describe recipients' rights relating to the Covered Code. You may distribute the Executable version of Covered Code or ownership rights under a license of Your choice, which may contain terms different from this License, provided that You are in compliance with the terms of this License and that the license

for the Executable version does not attempt to limit or alter the recipient's rights in the Source Code version from the rights set forth in this License. If You distribute the Executable version under a different license You must make it absolutely clear that any terms which differ from this License are offered by You alone, not by the Initial Developer or any Contributor. You hereby agree to indemnify the Initial Developer and every Contributor for any liability incurred by the Initial Developer or such Contributor as a result of any such terms You offer.

3.7. Larger Works. You may create a Larger Work by combining Covered Code with other code not governed by the terms of this License and distribute the Larger Work as a single product. In such a case, You must make sure the requirements of this License are fulfilled for the Covered Code.

4. Inability to Comply Due to Statute or Regulation.

If it is impossible for You to comply with any of the terms of this License with respect to some or all of the Covered Code due to statute, judicial order, or regulation then You must: (a) comply with the terms of this License to the maximum extent possible; and (b) describe the limitations and the code they affect. Such description must be included in the LEGAL file described in Section 3.4 and must be included with all distributions of the Source Code. Except to the extent prohibited by statute or regulation, such description must be sufficiently detailed for a recipient of ordinary skill to be able to understand it.

5. Application of this License.

This License applies to code to which the Initial Developer has attached the notice in Exhibit A and to related Covered Code.

6. Versions of the License.

6.1. New Versions. Netscape Communications Corporation ("Netscape") may publish revised and/or new versions of the License from time to time. Each version will be given a distinguishing version number.

6.2. Effect of New Versions. Once Covered Code has been published under a particular version of the License, You may always continue to use it under the terms of that version. You may also choose to use such Covered Code under the terms of any subsequent version of the License published by Netscape. No one other than Netscape has the right to modify the terms applicable to Covered Code created under this License.

6.3. Derivative Works. If You create or use a modified version of this License (which you may only do in order to apply it to code which is not already Covered Code governed by this License), You must (a) rename your license so that the phrases "Mozilla", "MOZILLAPL", "MOZPL", "Netscape", "MPL", "NPL" or any confusingly similar phrase do not appear in your license (except to note that your license differs from this License) and (b) otherwise make it clear that Your version of the license contains terms which differ from the Mozilla Public License and Netscape Public License. (Filling in the name of the Initial Developer, Original Code or Contributor in the notice described in Exhibit A shall not of themselves be deemed to be modifications of this License.)

7. DISCLAIMER OF WARRANTY.

COVERED CODE IS PROVIDED UNDER THIS LICENSE ON AN "AS IS" BASIS, WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, WARRANTIES THAT THE COVERED CODE IS FREE OF DEFECTS, MERCHANTABLE, FIT FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE COVERED CODE IS WITH YOU. SHOULD ANY COVERED CODE PROVE DEFECTIVE IN ANY RESPECT, YOU (NOT THE INITIAL DEVELOPER OR ANY OTHER CONTRIBUTOR) ASSUME THE COST OF ANY NECESSARY SERVICING, REPAIR OR CORRECTION. THIS DISCLAIMER OF WARRANTY CONSTITUTES AN ESSENTIAL PART OF THIS LICENSE. NO USE OF ANY COVERED CODE IS AUTHORIZED HEREUNDER EXCEPT UNDER THIS DISCLAIMER.

8. TERMINATION.

8.1. This License and the rights granted hereunder will terminate automatically if You fail to comply with terms herein and fail to cure such breach within 30 days of becoming aware of the breach. All sublicenses to the Covered Code which are properly granted shall survive any termination of this License. Provisions which, by their nature, must remain in effect beyond the termination of this License shall survive.

8.2. If You initiate litigation by asserting a patent infringement claim (excluding declaratory judgment actions) against Initial Developer or a Contributor (the Initial Developer or Contributor against whom You file such action is referred to as "Participant") alleging that:

- (a) such Participant's Contributor Version directly or indirectly infringes any patent, then any and all rights granted by such Participant to You under Sections 2.1 and/or 2.2 of this License shall, upon 60 days notice from Participant terminate prospectively, unless if within 60 days after receipt of notice You either: (i) agree in writing to pay Participant a mutually agreeable reasonable royalty for Your past and future use of Modifications made by such Participant, or (ii) withdraw Your litigation claim with respect to the Contributor Version against such Participant. If within 60 days of notice, a reasonable royalty and payment arrangement are not mutually agreed upon in writing by the parties or the litigation claim is not withdrawn, the rights granted by Participant to You under Sections 2.1 and/or 2.2 automatically terminate at the expiration of the 60 day notice period specified above.

- (b) any software, hardware, or device, other than such Participant's Contributor Version, directly or indirectly infringes any patent, then any rights granted to You by such Participant under Sections 2.1(b) and 2.2(b) are revoked effective as of the date You first made, used, sold, distributed, or had made, Modifications made by that Participant.

8.3. If You assert a patent infringement claim against Participant alleging that such Participant's Contributor Version directly or indirectly infringes any patent where such claim is resolved (such as by license or settlement) prior to the initiation of patent infringement litigation, then the reasonable value of the licenses granted by such Participant under Sections 2.1 or 2.2 shall be taken into account in determining the amount or value of any payment or license.

8.4. In the event of termination under Sections 8.1 or 8.2 above, all end user license agreements (excluding distributors and resellers) which have been validly granted by You or any distributor hereunder prior to termination shall survive termination.

9. LIMITATION OF LIABILITY.

UNDER NO CIRCUMSTANCES AND UNDER NO LEGAL THEORY, WHETHER TORT (INCLUDING NEGLIGENCE), CONTRACT, OR OTHERWISE, SHALL YOU, THE INITIAL DEVELOPER, ANY OTHER CONTRIBUTOR, OR ANY DISTRIBUTOR OF COVERED CODE, OR ANY SUPPLIER OF ANY OF SUCH PARTIES, BE LIABLE TO ANY PERSON FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY CHARACTER INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF GOODWILL, WORK STOPPAGE, COMPUTER FAILURE OR MALFUNCTION, OR ANY AND ALL OTHER COMMERCIAL DAMAGES OR LOSSES, EVEN IF SUCH PARTY SHALL HAVE BEEN INFORMED OF THE POSSIBILITY OF SUCH DAMAGES. THIS LIMITATION OF LIABILITY SHALL NOT APPLY TO LIABILITY FOR DEATH OR PERSONAL INJURY RESULTING FROM SUCH PARTY'S NEGLIGENCE TO THE EXTENT APPLICABLE LAW PROHIBITS SUCH LIMITATION. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. SO THIS EXCLUSION AND LIMITATION MAY NOT APPLY TO YOU. 10. U.S. GOVERNMENT END USERS.

The Covered Code is a "commercial item," as that term is defined in 48 C.F.R. 2.101 (Oct. 1995), consisting of "commercial computer software" and "commercial computer software documentation," as such terms are used in 48 C.F.R. 12.212 (Sept. 1995). Consistent with 48 C.F.R. 12.212 and 48 C.F.R. 227.7202-1 through 227.7202-4 (June 1995), all U.S. Government End Users acquire Covered Code with only those rights set forth herein.

11. MISCELLANEOUS.

This License represents the complete agreement concerning subject matter hereof. If any provision of this License is held to be unenforceable, such provision shall be reformed only to the extent necessary to make it enforceable. This License shall be governed by California law provisions (except to the extent applicable law, if any, provides otherwise), excluding its conflict-of-law provisions. With respect to disputes in which at least one party is a citizen of, or an entity chartered or registered to do business in the United States of America, any litigation relating to this License shall be subject to the jurisdiction of the Federal Courts of the Northern District of California, with venue lying in Santa Clara County, California, with the losing party responsible for costs, including without limitation, court costs and reasonable attorneys' fees and expenses. The application of the United Nations Convention on Contracts for the International Sale of Goods is expressly excluded. Any law or regulation which

provides that the language of a contract shall be construed against the drafter shall not apply to this License.

12. RESPONSIBILITY FOR CLAIMS.

As between Initial Developer and the Contributors, each party is responsible for claims and damages arising, directly or indirectly, out of its utilization of rights under this License and You agree to work with Initial Developer and Contributors to distribute such responsibility on an equitable basis. Nothing herein is intended or shall be deemed to constitute any admission of liability.

13. MULTIPLE-LICENSED CODE.

Initial Developer may designate portions of the Covered Code as Multiple-Licensed. Multiple-Licensed means that the Initial Developer permits you to utilize portions of the Covered Code under Your choice of the MPL or the alternative licenses, if any, specified by the Initial Developer in the file described in Exhibit A.

EXHIBIT A -Mozilla Public License.

The contents of this file are subject to the Mozilla Public License Version 1.1 (the "License"); you may not use this file except in compliance with the License. You may obtain a copy of the License at <http://www.mozilla.org/MPL/Software> distributed under the License is distributed on an "AS IS" basis, WITHOUT WARRANTY OF ANY KIND, either express or implied. See the License for the specific language governing rights and limitations under the License.

The Original Code is _____.

The Initial Developer of the Original Code is _____. Portions created by _____ are Copyright (C) _____, All Rights Reserved.

Contributor(s): _____.

Alternatively, the contents of this file may be used under the terms of the _____ license (the [_____] License), in which case the provisions of [_____] License are applicable instead of those above. If you wish to allow use of your version of this file only under the terms of the [_____] License and not to allow others to use your version of this file under the MPL, indicate your decision by deleting the provisions above and replace them with the notice and other provisions required by the [_____] License. If you do not delete the provisions above, a recipient may use your version of this file under either the MPL or the [_____] License."

[NOTE: The text of this Exhibit A may differ slightly from the text of the notices in the Source Code files of the Original Code. You should use the text of this Exhibit A rather than the text found in the Original Code Source Code for Your Modifications

The Independent JPEG Group's JPEG Software

The software included in this product contains copyrighted software that is licensed under the JPEG license.

- JPEG license
- Code project . Generating Outline OpenGL, Libjpeg

This distribution contains the sixth public release of the Independent JPEG Group's free JPEG software. You are welcome to redistribute this software and to use it for any purpose, subject to the conditions under LEGAL ISSUES, below.

Serious users of this software (particularly those incorporating it into larger programs) should contact IJG at jpeg-info@uunet.uu.net to be added to our electronic mailing list. Mailing list members are notified of updates and have a chance to participate in technical discussions, etc.

This software is the work of Tom Lane, Philip Gladstone, Jim Boucher, Lee Crocker, Julian Minguijon, Luis Ortiz, George Phillips, Davide Rossi, Guido Vollbeding, Ge' Weijers, and other members of the Independent JPEG Group.

IJG is not affiliated with the official ISO JPEG standards committee.

LEGAL ISSUES

=====

In plain English:

1. We don't promise that this software works. (But if you find any bugs, please let us know!)
2. You can use this software for whatever you want. You don't have to pay us.
3. You may not pretend that you wrote this software. If you use it in a program, you must acknowledge somewhere in your documentation that you've used the IJG code.

In legalese:

The authors make NO WARRANTY or representation, either express or implied, with respect to this software, its quality, accuracy, merchantability, or fitness for a particular purpose. This software is provided "AS IS", and you, its user, assume the entire risk as to its quality and accuracy.

This software is copyright (C) 1991-1998, Thomas G. Lane. All Rights Reserved except as specified below.

Permission is hereby granted to use, copy, modify, and distribute this software (or portions thereof) for any purpose, without fee, subject to these conditions:

- (1) If any part of the source code for this software is distributed, then this README file must be included, with this copyright and no-warranty notice unaltered; and any additions, deletions, or changes to the original files must be clearly indicated in accompanying documentation.
- (2) If only executable code is distributed, then the accompanying documentation must state that "this software is based in part on the work of the Independent JPEG Group".
- (3) Permission for use of this software is granted only if the user accepts full responsibility for any undesirable consequences; the authors accept NO LIABILITY for damages of any kind.

These conditions apply to any software derived from or based on the IJG code, not just to the unmodified library. If you use our work, you ought to acknowledge us.

Permission is NOT granted for the use of any IJG author's name or company name in advertising or publicity relating to this software or products derived from it. This software may be referred to only as "the Independent JPEG Group's software".

We specifically permit and encourage the use of this software as the basis of commercial products, provided that all warranty or liability claims are assumed by the product vendor.

ansi2knr.c is included in this distribution by permission of L. Peter Deutsch, sole proprietor of its copyright holder, Aladdin Enterprises of Menlo Park, CA.

ansi2knr.c is NOT covered by the above copyright and conditions, but instead by the usual distribution terms of the Free Software Foundation; principally, that you must include source code if you redistribute it. (See the file ansi2knr.c for full details.) However, since ansi2knr.c is not needed as part of any program generated from the IJG code, this does not limit you more than the foregoing paragraphs do.

The Unix configuration script "configure" was produced with GNU Autoconf. It is copyright by the Free Software Foundation but is freely distributable. The same holds for its supporting scripts (config.guess, config.sub, ltconfig, ltmain.sh). Another support script, install-sh, is copyright by M.I.T. but is also freely distributable.

It appears that the arithmetic coding option of the JPEG spec is covered by patents owned by IBM, AT&T, and Mitsubishi. Hence arithmetic coding cannot legally be used without obtaining one or more licenses. For this reason, support for arithmetic coding has been removed from the free JPEG software. (Since arithmetic coding provides only a marginal gain over the unpatented Huffman mode, it is unlikely that very many implementations will support it.) So far as we are aware, there are no patent restrictions on the remaining code.

The IJG distribution formerly included code to read and write GIF files. To avoid entanglement with the Unisys LZW patent, GIF reading support has been removed altogether, and the GIF writer has been simplified to produce "uncompressed GIFs". This technique does not use the LZW algorithm; the resulting GIF files are larger than usual, but are readable by all standard GIF decoders.

We are required to state that

"The Graphics Interchange Format(c) is the Copyright property of CompuServe Incorporated. GIF(sm) is a Service Mark property of CompuServe Incorporated."

T-Kernel License

- This Product uses the Source Code of T-Kernel under T-License granted by the T-Engine Forum(www.t-engine.org)

T-License [License Agreement for Source Code of T-Kernel]

established by T-Engine Forum
on January 23, 2004
revised on June 17, 2004
revised on December 21, 2006
revised on March 24, 2009

Article 1. Scope of License Agreement

1. This License Agreement sets forth copyrights and the terms and conditions of use applicable to the source code of T-Kernel distributed by T-Engine Forum and any derivative work created therefrom.

Article 2. Definition

1. "T-Kernel" means a real-time operating system controlled and distributed by T-Engine Forum on behalf of the copyright holder thereof.
2. "Source Code" means a source program, including related comments and documentations, for the T-Kernel and the Ported Source Code defined in Article 2.8 which is registered with T-Engine Forum.
3. "Hardware-dependent Part" means the part of the Source Code which depends on hardware and needs to be changed when the Source Code is ported and operated on the target hardware, and is designated and separated as such part.
4. "Compiler-dependent Part" means the part of the Source Code which depends on compiler and needs to be changed when the Source Code is ported and operated on the target hardware, and is designated and separated as such part.
5. "Header File" means the part of the Source Code which contains definitions necessary to develop application programs.
6. "T-Engine Hardware" means the hardware which is manufactured in accordance with the T-Engine Hardware specifications or the μ T-Engine Hardware specifications issued by T-Engine Forum, and registered with T-Engine Forum.
7. "Similar Hardware to T-Engine Hardware" means any hardware (including software which emulates hardware) other than that defined in Article 2.6 above, on which the T-Kernel can be operated.
8. "Ported Source Code" means a source program produced from the Source Code by modifying only its Hardwaredependent Part and/or Compiler-dependent Part to enable it to be operated on the T-Engine Hardware or the Similar Hardware to T-Engine Hardware. The Ported Source Code which is registered with T-Engine Forum shall be included in the Source Code.
9. "Modified Source Code" means a source program modified from the Source Code for the purpose of improving its performance, increasing or decreasing its function, and the like. The Ported Source Code shall not be included in the Modified Source Code.
10. "Binary Code" means an executable code form which is created by compiling programs, which include all or part of the Source Code or the Modified Source Code.
11. "Derivative Work" means the Modified Source Code or the Binary Code.
12. "Embedded Product" means any product which operates with executable code form of the Source Code, the Modified Source Code or the Binary Code loaded on its hardware.
13. "End User" means a consumer who uses the Embedded Product.
14. "System Developer" means any person who develops the Embedded Product by itself or has a third party develop the same, and provides, whether with or without payment, the End User with the Embedded Product.
15. "Distributor of Modification" means any person who produces the Modified Source Code and, whether with or without payment, distributes the same to any third party.

16. "Patch for Modification" means a difference, program, system, or the like in order to create the Modified Source Code from the Source Code or the Binary Code thereof.

17. "Vicarious Execution of Patch Processing" means vicarious execution service to create the Modified Source Code applying the Patch for Modification to the Source Code or the Binary Code thereof.

18. "Source Code User" means a person who uses the Source Code.

19. "Distribution" means any of the following acts:

1. to transmit a work to a large number of specific persons through the Internet communication, broadcasting, and the like;
2. to transmit a work to the general public through the Internet communication, broadcasting, and the like automatically in response to a request from the public; and
3. to distribute a copy of a work to the general public or a large number of specific persons.

Article 3. Copyright

1. The copyrights of the Source Code shall be owned by Ken Sakamura.

Article 4. License of Source Code

1. As provided for in this Article, T-Engine Forum shall provide, and grant a license to use, the Source Code free of charge to any person who has taken the necessary procedure for registration as prescribed by T-Engine Forum and agreed to the T-License.
2. The Source Code shall be distributed exclusively by T-Engine Forum. Any person who obtains the Source Code under Article 4.1 above shall not make any re-Distribution of the Source Code.
3. In accordance with the license granted under Article 4.1 above, the Source Code User may perform the following acts:
 1. to copy and/or modify the Source Code provided by T-Engine Forum hereunder for its own research, development and the like.
 2. to run the Source Code provided by T-Engine Forum hereunder for its own research, development and the like.
 3. to run the Source Code modified in accordance with the provision of Article 4.3 (1) above for its own research, development and the like.
 4. to distribute the Binary Code created from the Source Code provided by T-Engine Forum hereunder or from the Source Code modified in accordance with the provision of Article 4.3 (1) above.
4. In accordance with the license granted under Article 4.1 above, the System Developer may perform the following acts:
 1. to perform any and all acts set forth in the Article 4.3 above.
 2. to develop and manufacture the Embedded Product containing the Binary Code, and, whether with or without payment, provide the End User with the same and make the Binary Code available to the End User on the Embedded Product.
5. The Source Code User and the System Developer shall be obligated to give a notice that the Source Code is used, in such a way as separately specified by T-Engine Forum, when they use the Source Code or the Binary Code, or make the Binary Code available for the End User on the Embedded Product.

Article 5. Distribution of Modified Source Code

1. Any of A- members of T-Engine Forum may become the Distributor of Modification by obtaining the approval of T-Engine Forum through the registration procedure as prescribed by the Forum provided that only the department of the A- member which has taken the registration procedure may distribute the Modified Source Code in such a way as provided for in this Article as long as it holds the Amembership.
2. The Distributor of Modification may create the Modified Source Code based on the Source Code provided by T-Engine Forum and the Patch for Modification to be applied to create such Modified Source Code from the Source Code.
3. The Distributor of Modification shall, prior to the distribution, inform T-Engine Forum of and register a name and description of the Modified Source Code in such a way as specified by T-Engine Forum.
4. The Distributor of Modification shall determine the name of the Modified Source Code subject to the rules separately established by T-Engine Forum and publish an appropriate notice as required by the rules on the Patch for Modification and the Modified Source Code.
5. The Distributor of Modification may distribute the Modified Source Code to a third party, whether with or without payment, provided that the Distributor of Modification shall take the necessary measures to prohibit the third party from making the re-Distribution of the Modified Source Code.
6. Developer with the Patch for Modification. Provided, however, that the Distributor of Modification shall be obligated to confirm that the System Developer is the Source Code User duly licensed under Article 4.1.
7. The Distributor of Modification may perform the Vicarious Execution of Patch Processing for the System Developer.
8. The System Developer shall not distribute the Modified Source Code in further modified form to any third party as a stand-alone software product.
9. The System Developer may, under the same obligation as imposed in Article 4.5, make the Embedded Product available for the End User through use of the Patch for Modification distributed by the Distributor of Modification or the Derivative Works obtained through the Vicarious Execution of Patch Processing.

Article 6. Distribution and Registration of the Ported Source Code

1. The Source Code User and the System Developer may, whether with or without charge, distribute to any third party only the following parts of the Ported

Source Code on the T-Engine Hardware or the Similar Hardware to T-Engine Hardware:

1. The Hardware-dependent Part and/or Compiler-dependent Part; provided that the Source Code User and the System Developer shall inform T-Engine Forum of, and T-Engine Forum may publish, a method for distributing said Part(s) to third parties.
2. The Header File; provided that the Header File shall be distributed together with the Binary Code of the Ported Source Code.
2. Any member of T-Engine Forum may request T-Engine Forum to register and distribute, as an original source code for T-Kernel, the Ported Source Code on the T-Engine Hardware or the Similar Hardware to T-Engine Hardware.
3. Any member of T-Engine Forum who requests the distribution mentioned in the preceding paragraph shall accede to the following conditions:
 1. The member shall confirm that the object hardware is the T-Engine Hardware or the Similar Hardware to T-Engine Hardware.
 2. The member shall provide T-Engine Forum with a complete set of operational environment for the object hardware and T-Kernel free of charge when requesting the distribution.
 3. The member shall submit test results of the Ported Source Code to T-Engine Forum when requesting the distribution.
4. In the event that T-Engine Forum accepts the request mentioned in Article 6.2, T-Engine Forum shall register and distribute the Ported Source Code as the Source Code for T-Kernel. Provided, however, that the Ported Source Code may be treated in the same way as the Modified Source Code until the time of registration hereunder.
5. The provision set forth in Article 3 shall apply to the Ported Source Code registered in accordance with this Article.

Article 7. Use for Other Purpose

1. Any use of the Source Code, the Modified Source Code or the Ported Source Code other than those stipulated in Articles 4, 5 and 6 shall be subject to the prior approval of T-Engine Forum.

Article 8. Limited Warranty

1. T-Engine Forum and the copyright holder of the Source Code warrant that the Source Code does not infringe third party's copyrights. Provided, however, that T-Engine Forum and the copyright holder of the Source Code make no warranty as to the Hardware-dependent Part and/or Compiler- dependent Part set forth in Article 6.2 in the Ported Source Code by any third party.
2. Neither T-Engine Forum nor the copyright holder of the Source Code warrants that the Source Code will fit for any particular purpose of the Source Code User.
3. Neither T-Engine Forum nor the copyright holder of the Source Code warrants that the Source Code does not infringe any third party's industrial property rights. In no event shall T-Engine Forum and the copyright holder of the Source Code be liable for any dispute which may arise between the Source Code User and a third party in connection with the third party's industrial property rights.

Article 9. Indemnity

1. Neither T-Engine Forum nor the copyright holder of the Source Code shall be liable for any damages (including, but not limited to, damages resulting from loss of profit, business interruption, loss of business information or any other pecuniary damage) arising out of use or impossibility of use of the Source Code, even if T-Engine Forum and the copyright holder have been informed of the possibility of such damages.

Article 10. Breach of Agreement

1. In case that T-Engine Forum considers that this License Agreement is breached or that the popularization of T-Kernel is obstructed, T-Engine Forum shall take measures to correct such breach or such obstruction, take measures on the ground of copyright infringement, or take any other necessary measures against the breaching person or the obstructing person, regardless of whether or not the said person is a member of T-Engine Forum.
2. In case of breach of this License Agreement by a member of T-Engine Forum, T-Engine Forum may take appropriate measures against the member; for example, the member is disqualified from membership, depending on what kind of breach has been committed by it.
3. Any legal dispute which may arise in relation to any breach of this License Agreement shall be subject to the exclusive jurisdiction of the Tokyo District Court.

Article 11. Governing Law and Language

1. This License Agreement shall be governed by and interpreted under the laws of Japan.
2. This License Agreement is executed in both Japanese text and English text provided that the Japanese text shall govern the interpretation and performance of this License Agreement.

Apache License 2.0

Component	Name License	URL
mDNSResponder_bonjour	Apache License 2.0	http://www.apache.org/licenses/LICENSE-2.0

TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

1. Definitions.
"License" shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document.
"Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50%) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License. "Source" form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or Legal Entity authorized to submit on behalf of the copyright owner. For the purposes of this definition, "submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution." "Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

- Grant of Copyright License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.
- Grant of Patent License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a crossclaim or counterclaim in a lawsuit) alleging that the Work or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.
- Redistribution. You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:
 - You must give any other recipients of the Work or Derivative Works a copy of this License; and
 - You must cause any modified files to carry prominent notices stating that You changed the files; and
 - You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work, excluding those notices that do not pertain to any part of the Derivative Works; and
 - If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places:
 - within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or
 - within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

- Submission of Contributions. Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions. Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.
- Trademarks. This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.
- Disclaimer of Warranty. Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NONINFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.
- Limitation of Liability. In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.
- Accepting Warranty or Additional Liability. While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

END OF TERMS AND CONDITIONS

APPENDIX: How to apply the Apache License to your work.

To apply the Apache License to your work, attach the following boilerplate notice, with the fields enclosed by brackets "[]" replaced with your own identifying information. (Don't include the brackets!) The text should be enclosed in the appropriate comment syntax for the file format. We also recommend that a file or class name and description of purpose be included on the same "printed page" as the copyright notice for easier identification within third-party archives.

Copyright [yyyy] [name of copyright owner]

Licensed under the Apache License, Version 2.0 (the "License"); you may not use this file except in compliance with the License. You may obtain a copy of the License at <http://www.apache.org/licenses/LICENSE-2.0>

Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied. See the License for the specific language governing permissions and limitations under the License.

BZip2 License

This program, "bzip2", the associated library "libbzip2", and all documentation, are copyright (C) 1996-2007 Julian R Seward. All rights reserved.

Component Name	License	URL
bzip2- 1.0.6	Bzip2	http://www.bzip.org/

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
- Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
- The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Julian Seward, jseward@bzip.org

bzip2/libbzip2 version 1.0.5 of 10 December 2007

University of Illinois / NCSA Open Source License

Copyright (c) 1999-2007, The Board of Trustees of the University of Illinois All Rights Reserved.

Component Name	License
iperf-2.0.5	University of Illinois / NCSA Open Source

Ipert performance test

Mark Gates

Ajay Tirumala

Jim Ferguson

Jon Dugan

Feng Qin

Kevin Gibbs

John Estabrook

National Laboratory for Applied Network Research

National Center for Supercomputing Applications

University of Illinois at Urbana-Champaign

<http://www.ncsa.uiuc.edu>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software (Ipert) and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimers.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimers in the documentation and/or other materials provided with the distribution.

Neither the names of the University of Illinois, NCSA, nor the names of its contributors may be used to endorse or promote products derived from this Software without specific prior written permission. THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE CONTRIBUTORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

PHP 3.01 License

The PHP License, version 3.01 Copyright (c) 1999 - 2010 The PHP Group. All rights reserved.

Component Name	License	URL
php-5.2.17	PHP 3.01	http://www.php.net/distributions

Redistribution and use in source and binary forms, with or without modification, is permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name "PHP" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact group@php.net.
4. Products derived from this software may not be called "PHP", nor may "PHP" appear in their name, without prior written permission from group@php.net. You may indicate that your software works in conjunction with PHP by saying "Foo for PHP" instead of calling it "PHP Foo" or "phpfoo".
5. The PHP Group may publish revised and/or new versions of the license from time to time. Each version will be given a distinguishing version number. Once covered code has been published under a particular version of the license, you may always continue to use it under the terms of that version. You may also choose to use such covered code under the terms of any subsequent version of the license published by the PHP Group. No one other than the PHP Group has the right to modify the terms applicable to covered code created under this License.
6. Redistributions of any form whatsoever must retain the following acknowledgment: "This product includes PHP software, freely available from <http://www.php.net/software/>".

THIS SOFTWARE IS PROVIDED BY THE PHP DEVELOPMENT TEAM "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE PHP DEVELOPMENT TEAM OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This software consists of voluntary contributions made by many individuals on behalf of the PHP Group. The PHP Group can be contacted via Email at group@php.net.

For more information on the PHP Group and the PHP project, please see <http://www.php.net>. PHP includes the Zend Engine, freely available at <http://www.zend.com>.

zlib / libpng License

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Component Name	License	URL
zlib-1.2.8	zlib / libpng	http://zlib.net/

Copyright (C) 1995-2010 Jean-loup Gailly and Mark Adler

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
3. This notice may not be removed or altered from any source distribution.

Jean-loup Gailly Mark Adler

jloup@gzip.org madler@alumni.caltech.edu

The data format used by the zlib library is described by RFCs (Request for Comments) 1950 to 1952 in the files <http://www.ietf.org/rfc/rfc1950.txt> (zlib format), [rfc1951.txt](http://www.ietf.org/rfc/rfc1951.txt) (deflate format) and [rfc1952.txt](http://www.ietf.org/rfc/rfc1952.txt) (gzip format).

Portions of this software are copyright 1996-2002 The FreeType Project (www.freetype.org). All rights reserved.



Hanwha Techwin hat sich dem Schutz der Umwelt verpflichtet und wendet in allen Phasen des Produktherstellungsprozesses umweltfreundliche Verfahren an, um seinen Kunden umweltgerechtere Produkte zu liefern.

Das Eco-Gütesiegel ist ein Zeichen für die Absicht von Hanwha Techwin, Produkte zu liefern, und zeigt an, dass die Produkte die RoHS-Richtlinie der EU erfüllen.



Korrekte Entsorgung von Altgeräten (Elektroschrott)

(In den Ländern der Europäischen Union und anderen europäischen Ländern mit einem separaten Sammelsystem)
Die Kennzeichnung auf dem Produkt, Zubehörteilen bzw. auf der dazugehörigen Dokumentation gibt an, dass das Produkt und Zubehörteile (z. B. Ladegerät, Kopfhörer, USB-Kabel) nach ihrer Lebensdauer nicht zusammen mit dem normalen Haushaltsmüll entsorgt werden dürfen. Entsorgen Sie dieses Gerät und Zubehörteile bitte getrennt von anderen Abfällen, um der Umwelt bzw. der menschlichen Gesundheit nicht durch unkontrollierte Müllbeseitigung zu schaden. Helfen Sie mit, das Altgerät und Zubehörteile fachgerecht zu entsorgen, um die nachhaltige Wiederverwertung von stofflichen Ressourcen zu fördern.

Private Nutzer wenden sich an den Händler, bei dem das Produkt gekauft wurde, oder kontaktieren die zuständigen Behörden, um in Erfahrung zu bringen, wo Sie das Altgerät bzw. Zubehörteile für eine umweltfreundliche Entsorgung abgeben können.

Gewerbliche Nutzer wenden sich an ihren Lieferanten und gehen nach den Bedingungen des Verkaufsvertrags vor. Dieses Produkt und elektronische Zubehörteile dürfen nicht zusammen mit anderem Gewerbemüll entsorgt werden.



Korrekte Entsorgung der Batterien dieses Produkts

(In den Ländern der Europäischen Union und anderen europäischen Ländern mit einem separaten Altbatterie-Rücknahmesystem)

Die Kennzeichnung auf der Batterie bzw. auf der dazugehörigen Dokumentation oder Verpackung gibt an, dass die Batterie zu diesem Produkt nach seiner Lebensdauer nicht zusammen mit dem normalen Haushaltsmüll entsorgt werden darf. Wenn die Batterie mit den chemischen Symbolen Hg, Cd oder Pb gekennzeichnet ist, liegt der Quecksilber-, Cadmium- oder Blei-Gehalt der Batterie über den in der EG-Richtlinie 2006/66 festgelegten Referenzwerten. Wenn Batterien nicht ordnungsgemäß entsorgt werden, können sie der menschlichen Gesundheit bzw. der Umwelt schaden.

Bitte helfen Sie, die natürlichen Ressourcen zu schützen und die nachhaltige Wiederverwertung von stofflichen Ressourcen zu fördern, indem Sie die Batterien von anderen Abfällen getrennt über Ihr örtliches kostenloses Altbatterie-Rücknahmesystem entsorgen.

Head Office

6, Pangyo-ro 319 beon-gil, Bundang-gu, Seongnam-si,
Gyeonggi-do, 463-400 Rep. of KOREA
Tel : +82.70.7147.8753 Fax : +82.31.8018.3740
www.hanwha-security.com

Hanwha Techwin America

500 Frank W. Burr Blvd. Suite 43 Teaneck, NJ 07666
Toll Free +1.877.213.1222 Direct +1.201.325.6920
Fax +1.201.373.0124
www.hanwhasecurity.com

Hanwha Techwin Europe

Heriot House, Heriot Road, Chertsey, Surrey, KT16 9DT, United Kingdom
Tel +44.1372.235663 Fax +44.1932.57.8101
www.hanwha-security.eu

Hanwha Techwin Vietnam Hanoi Office

28th Floor, Handico Building, Pham Hung Street, Me Tri ward,
Nam Tu Liem District, Hanoi City, Vietnam
Tel : +84.91.982.40.88
<http://hanwha-security.com>
