

Occupancy monitoring Application 1.11 Release Notes

V1.11 (2020-11-18)

New and advanced function:

- Add SUNAPI event
 - . dynamic event _ under/over
- Duration 2sec -> 1sec
 - . up to two cameras registration
- Change setting scenario
 - . After device setting, move to Display edit page
- Default BG image change
- Monitoring page, Side slider response speed (2sec -> 1 or 0.5sec)

Bug fix:

- HTTP command test button enable, setting page when re-enter setting page
- HTTP commands without username / password

New and advanced function:

- Display Edit
 - . Edit Text : Title/Occupancy limitation message/Warning message/Entry allowed message/Entry blocked message, Font size/color/bold
 - . Custom image upload(Logo, custom images, Background Image) and resize
 - . Display Horizontal/vertical mode
 - . Remaining Occupancy/Current Occupancy
- Event action for master camera
 - . E-mail (Title, Description)
 - . Event type (Over, Under, Over/Under), Duration setting (1~15 sec)
- Visitor counting function : generate http events at the specified number of visitors interval.
- Support HTTPS
- Change the HTTP port
- Reset schedule disable/enable and reset default value change
- Counting number up to 9999