

遙控攝影機鏡頭 快速入門指南

PNM-C20000QB



Important

Please check 'Manuals' from our website, before connecting to the Supply,
<https://www.hanwhavision.com/en/download-data/>

Warranty

Please check "Product warranty information" from our website.
<https://www.hanwhavision.com/en/support/warranty/>

We recommend to use the officially compatible VMS version or latest Hanwha NVR version when integrating with VMS or Hanwha NVR.



Hanwha Vision cares for the environment at all product manufacturing stages, and is taking measures to provide customers with more environmentally friendly products.

The Eco mark represents Hanwha Vision's devotion to creating environmentally friendly products, and indicates that the product satisfies the EU RoHS Directive.



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract.

This product and its electronic accessories should not be mixed with other commercial wastes for disposal.




Correct disposal of batteries in this product

(Applicable in the European Union and other European countries with separate battery return systems.)

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.




To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.

SAFETY INFORMATION




COMPONENT

各個販售國家/地區提供的配件不盡相同。




- 不包含:SD 卡




INSTALLATION

1




2




INSTALLATION

3




4



INSTALLATION

5

- 不包含: 鏡頭模組




- 連接或移除鏡頭模組時，請關閉攝影機電源。

INSTALLATION

6

- 不包含:WiFi 轉接器 OTG 轉接頭




7




INSTALLATION

8




9



設定密碼

首次存取產品，須註冊登入密碼。



The image shows a web form titled "Administrator password change". It has two input fields: "New password" and "Confirm new password". Below these fields is a list of password requirements:

- If the password is 8 to 9 characters long, it must include at least 3 of the following character types: English uppercase letters, English lowercase letters, numbers, and special characters. (support up to 64 characters)
- If the password is 10 characters or longer, it must include at least 2 of the following character types: English uppercase letters, English lowercase letters, numbers, and special characters.
- ID may not be used as password. The password and ID cannot be identical.
- The following special characters can be used: ~!@#\$%^&*()_+={}|[]\.;'"/<>.,?/
- You may not use more than 4 consecutive characters. (example: 1234, abcd, etc.)
- You may not use the same character 4 or more times consecutively. (example: 1111, aaaa, etc.)

At the bottom of the form is an "Apply" button.



- 若新密碼長度為 8 到 9 個字元，須至少包含下列 3 種字元：大小寫字母、數字與特殊字元；若密碼長度超過 10 個字元，則須至少包含上述 2 種字元。(長度上限為 64 個字元)
 - 可使用的特殊字元：
~!@#\$%^&*()_+={}|[]\.;'"/<>.,?/
- 密碼不可包含空白字元。
- 為提高安全性，建議密碼不要包含重複的字元，或鍵盤上的相鄰字元。
- 請務必牢記所設定的密碼。萬一忘記密碼，請按 **[RESET]** 按鈕重新設定本產品。

登入

只要存取攝影機，就會出現登入視窗。
請輸入使用者 ID 與密碼來存取攝影機。

- 1 請在 <User Name> 輸入方塊中輸入「admin」。
- 2 請在 <Password> 輸入欄位中輸入密碼。
- 3 按一下 **[Sign in]**。

連線至 WIFI

設定攝影機

- 1 將 OTG 公接頭 (Type-C) 與 WiFi 轉接器連接至 USB Type C 端子。

設定智慧型手機

- 1 安裝 Wisenet Installation 應用程式。
- 2 開啟 WiFi 後，選取攝影機 SSID。
- 3 執行 Wisenet Installation 應用程式。
- 4 登入攝影機，系統便會連接視訊畫面。
- 5 可在透過智慧型手機觀看視訊時，調整拍攝角度。



microSD, microSDHC, and microSDXC Logos are trademarks of SD-3C LLC. microSD, microSDHC, microSDXC are trademarks or registered trademarks of SD-3C, LLC in the United States, other countries or both.



Подлежит использованию по назначению
в нормальных условиях
Срок службы : 7 лет.

Türkiye Distribütörü

EDS Elektronik Destek Sanayi ve Ticaret Ltd. Şti.

Meclis Mah. Teraziler Cad. Hayran Sk. (Eskisi Kılıç Sk.) No: 4 Sancaktepe / İstanbul / Türkiye
Tel +90.216.313.25.15

ENTES ELEKTRONİK CİHAZLAR İMALAT VE TİC. A.Ş.

Dudullu Org.San.Bölg. 1. Cad. No:23 34776 Ümraniye / İstanbul / Türkiye
Tel +90.216.313.01.10

TEKNOMAKS TEKNOLOJİ / TEKNOMAKS BİLİSİM

MERDİVENKÖY MAH.DİKYOL SOK. BUSINESS İSTANBUL No:2, Kat:7, D:B67, 34732 Kadıköy / İstanbul / Türkiye
Tel +90.212.217.54.22

Cihazın Ticaret Bakanlığına önerilen ortalama ömrü

Cihazın EEE yönetmeliklerine uygun olduğuna benzer beyan

