

SAMSUNG TECHWIN

CONTROLADOR DO SISTEMA

Manual do Usuário

SPC-6000



SAMSUNG

SAMSUNG

Controlador do sistema

Manual do usuário

Direitos autorais

©2011 Samsung Techwin Co., Ltd. Todos os direitos reservados.

Marca comercial

 **SAMSUNG TECHWIN** é o logotipo registrado da Samsung Techwin Co., Ltd.

O nome deste produto é a marca comercial registrada da Samsung Techwin Co., Ltd.

As outras marcas comerciais mencionadas neste manual são marcas comerciais registradas de suas respectivas empresas.

Restrição

Samsung Techwin Co., Ltd. shall reserve the copyright of this document. Under no circumstances, this document shall be reproduced, distributed or changed, partially or wholly, without formal authorization of Samsung Techwin.

Disclaimer

A Samsung Techwin esforça-se ao máximo para verificar a integridade e exatidão do conteúdo deste documento, mas nenhuma garantia formal deve ser fornecida. O uso deste documento e dos resultados subsequentes deve ser inteiramente responsabilidade do usuário. A Samsung Techwin reserva-se o direito de alterar o conteúdo deste documento sem aviso prévio.

- ❖ **Design e especificações estão sujeitos a alterações sem aviso prévio.**
- ❖ **A senha padrão pode ser exposta a uma ameaça de hackers, portanto é recomendado alterá-la após a instalação do produto.**
Observe que a segurança e outras questões relacionadas causadas por uma senha inalterada devem ser de responsabilidade do usuário.

INSTRUÇÕES IMPORTANTES DE SEGURANÇA

1. Leia estas instruções.
2. Guarde estas instruções.
3. Preste atenção a todos os avisos.
4. Siga todas as instruções.
5. Não utilize este leitor próximo à água.
6. Limpe apenas com um pano seco.
7. Não bloqueie as aberturas de ventilação. Instale de acordo com as instruções do fabricante.
8. Não o instale perto de fontes de calor, como radiadores, sistemas de aquecimento ou outros aparelhos que produzam calor, (incluindo amplificadores).
9. O plugue polarizado ou de aterramento desempenha uma importante função de segurança. Um plugue polarizado contém duas lâminas com uma mais larga do que a outra. Um plugue do tipo-terra contém duas lâminas e um terceiro pino de aterramento. A lâmina larga ou o terceiro pino são fornecidos para sua segurança. Se o plugue fornecido não encaixar na tomada, chame um eletricitista para trocar a tomada inadequada.
10. O cabo de alimentação deve ser posicionado de maneira que não seja deformado nem comprimido, especialmente nos plugues, em tomadas elétricas e nos pontos de saída do leitor.
11. Utilize apenas conexões / acessórios especificados pelo fabricante.
12. Utilize apenas carrinhos, bases, tripés, suportes ou mesas especificados pelo fabricante ou vendidos com o leitor. Ao utilizar um carrinho, tenha cuidado ao deslocá-lo com o leitor, para evitar ferimentos caso tombem.
13. Desligue este leitor da tomada durante tempestades com raios ou quando não for utilizá-lo por um longo período.
14. Todos os serviços de manutenção devem ser executados por técnicos qualificados. A manutenção será necessária quando o leitor for danificado de alguma forma, como danos ao cabo de alimentação ou plugue, derramamento de líquidos ou queda de objetos sobre o leitor, exposição à chuva ou umidade, mau funcionamento ou queda.



visão geral

AVISO

PARA REDUZIR O RISCO DE INCÊNDIO OU CHOQUE ELÉTRICO, NÃO EXPONHA ESTE PRODUTO À CHUVA OU UMIDADE.

NÃO INSIRA OBJETOS METÁLICOS PELAS GRADES DE VENTILAÇÃO OU POR OUTROS ORIFÍCIOS NO EQUIPAMENTO.

O aparelho não deve ser exposto a goteiras ou respingos e não deve servir de base para recipientes com líquido, como vasos.

CUIDADO

	CUIDADO RISCO DE CHOQUE ELÉTRICO NÃO ABRA	
CUIDADO : PARA REDUZIR O RISCO DE CHOQUE ELÉTRICO, NÃO REMOVA A TAMPÁ (OU PARTE TRASEIRA). NÃO EXISTEM PEÇAS INTERNAS QUE POSSAM SER REPARADAS PELO USUÁRIO. OS SERVIÇOS DE MANUTENÇÃO DEVEM SER EXECUTADOS POR TÉCNICOS QUALIFICADOS.		

EXPLICAÇÃO DOS SÍMBOLOS GRÁFICOS



O raio com uma seta na ponta dentro de um triângulo equilátero destina-se a alertar o usuário sobre a presença de "tensão perigosa" dentro da caixa do produto, cuja grandeza talvez seja suficiente para constituir risco de choque elétrico nas pessoas.



O ponto de exclamação dentro de um triângulo equilátero tem o objetivo de alertar o usuário sobre a presença de importantes instruções de operação e manutenção (serviço) na literatura que acompanha o produto.

Leia as seguintes precauções recomendadas de segurança com atenção.

Não coloque este aparelho em uma superfície irregular. 	Não o instale em uma superfície onde ficará exposto à luz direta do sol, perto de equipamentos que emitem calor ou áreas extremamente frias. 
Não coloque este aparelho próximo de recipientes com água. 	Não tente reparar pessoalmente este aparelho. 
Não coloque um copo de água sobre o produto. 	Não o instale perto de fontes magnéticas. 
Não bloqueie as aberturas de ventilação. 	Não coloque objetos pesados sobre o produto. 

O Manual do Usuário é um guia contendo informações sobre como usar o produto.

O significado dos símbolos no manual é o seguinte:

- Referência: caso existam informações que ajudam a usar o produto
- Nota: caso exista qualquer possibilidade de ocorrerem danos ao produto e ao ser humano causados pelo não cumprimento das instruções

※ Leia este manual quanto aos itens de segurança antes de usar o produto e mantenha-o em local seguro.



Este equipamento foi testado e constatado como atendendo os limites para um dispositivo digital Classe A, de acordo com a seção 15 das Regras FCC. Estes limites se destinam a fornecer uma proteção razoável contra interferência prejudicial quando o equipamento for operado em uma ambiente comercial. Este equipamento gera, utiliza e pode irradiar energia de radiofrequência e, se não instalado e utilizado de acordo com o manual de instruções poderá causar interferência prejudicial às comunicações de rádio. A operação deste equipamento em uma área residencial irá provavelmente causar interferência prejudicial e neste caso o usuário será solicitado a corrigir a interferência às suas próprias expensas.



A Samsung Techwin respeita e preserva o meio ambiente em todos os estágios de produção e toma várias medidas para oferecer aos clientes aparelhos mais ecológicos.

A marca Eco representa a determinação da Samsung Techwin em criar aparelhos ecológicos e indica que o aparelho satisfaz a diretiva RoHS da União Europeia.



Eliminação Correcta Deste Produto (Resíduos de Equipamentos Eléctricos e Electrónicos)

Esta marca - apresentada no produto, nos acessórios ou na literatura — indica que o produto e os seus acessórios electrónicos (por exemplo, o carregador, o auricular, o cabo USB) não deverão ser eliminados juntamente com os resíduos domésticos no final do seu período de vida útil. Para impedir danos ao ambiente ou à saúde humana causados pela eliminação incontrolada de resíduos, deverá separar estes equipamentos de outros tipos de resíduos e reciclá-los de forma responsável, para promover uma reutilização sustentável dos recursos materiais.

Os utilizadores domésticos deverão contactar o estabelecimento onde adquiriram este produto ou as entidades oficiais locais para obterem informações sobre onde e de que forma podem entregar estes equipamentos para permitir efectuar uma reciclagem segura em termos ambientais.

Os utilizadores profissionais deverão contactar o seu fornecedor e consultar os termos e condições do contrato de compra. Este produto e os seus acessórios electrónicos não deverão ser misturados com outros resíduos comerciais para eliminação.

ÍNDICE

VISÃO GERAL

3

- 3 Instruções importantes de segurança
- 7 Índice
- 9 Características-chave
- 10 O que está incluso
- 11 Visão geral do controlador do sistema

INSTALLATION

14

- 14 Precauções
- 15 Antes da instalação
- 15 Ajustando o ângulo da tela do controlador do sistema
- 16 Alternando o layout do joystick e jog shuttle

CONEXÃO A UM DISPOSITIVO EXTERNO

17

- 17 Para conectar um dispositivo RS-485
- 23 Conexão a outro controlador do sistema

USANDO O MENU

24

- 24 Primeiros passos
- 24 Controlando a câmera PTZ
- 30 Controlando o DVR
- 32 Controlando o Matrix

CONFIGURAÇÕES DO MENU

34

- 34 Para acessar o menu principal
- 34 Configuração de PTZ
- 35 Configuração de DVR
- 35 Configuração do controlador
- 40 Atualização do firmware
- 42 Para verificar as informações do controlador

APÊNDICE

43

- 43 Specifications
- 44 Perguntas e respostas
- 45 GPL/LGPL Software License

CARACTERÍSTICAS-CHAVE

O controlador do sistema SPC-6000 permite que você controle dispositivos externos tais como câmera PTZ, DVR e MATRIX utilizando comunicações RS-485.

Ele fornece uma interface amigável ao usuário com menu na tela, tela de toque e joystick.

- Controle remoto de longa distância
- Com as comunicações RS-485, é possível controlar um alcance máximo de 1km.
- Controle de sistema integrado
- Com um único controlador do sistema, é possível ter controle da câmera (unidade receptora), DVR e MATRIX.
- Possibilidade de conexão de vários controladores de sistemas
- É possível controlar o sistema em locais diferentes e conectar até 16 controladores simultaneamente.
- Alterne a posição entre joystick e módulo jog shuttle
- Para a comodidade do usuário, as posições do joystick e do módulo jog shuttle podem ser alternadas entre esquerda e direita.
- Interface amigável ao usuário

O status de operação do controle do sistema é exibido na tela; a tela de toque permite que você selecione um menu com facilidade; o joystick simplifica e facilita a manipulação.

❖ Lista de compatibilidade

- Câmera
- MATRIX
SMX-25632
- DVR
Série SRD-XXXX, série SHR-8/7/6XXX, SVR-1670, SRD-480D

❖ Especificações do adaptador

- Tensão : 1) Entrada (CA) : 100~240V
2) Saída (CC) : 12V
- Capacidade (corrente de saída) : 4A
- Carga Padrão Contínua : 48W
- Temperatura : 1) Temperatura de operação : 0 ~+40℃
2) Armazenamento : -20 ~+60℃

visão geral

O QUE ESTÁ INCLUSO


Abra o pacote do produto e o coloque no chão ou em uma superfície plana. Verifique se os seguintes componentes acompanham o pacote do produto.




Unidade principal



CD Manual do usuário



Guia de consulta rápida



Adaptador de alimentação 1EA




Cabo de alimentação 1EA



Bloco de terminais 1EA

VISÃO GERAL DO CONTROLADOR DO SISTEMA

Parte frontal




Item	Descrição
1 Barra de reprodução do DVR	Reproduzir/Pausar, Avanço rápido/Retrocesso rápido, Parar, Gravar
2 Barra de controle do DVR	Acesse o menu selecionado, pesquise, selecione um modo de divisão ou controle o alarme.
3 LCD Exibição	Mostre o status de operação e o menu de configuração do controlador do sistema.
4 Barra de CONFIGURAÇÃO	Pressione o botão [FUNC] e clique em [SETUP] para entrar no menu de configuração.
5 Barra de operação da câmera	Acesse o menu PTZ selecionado ou execute Predefinição, Grupo ou Faixa.
6 Controlador joystick	É possível manipular a operação Expan/Inclin. para cima ou para baixo em conexão com a câmera PTZ ou unidade de recepção. Gire o joystick em sentido horário ou anti-horário para controlar o zoom. É possível controlar a orientação do controlador conectado a partir da tela do menu do controlador.

visão geral

Item		Descrição
7 Barra de lente da câmera	IRIS	Íris de controle (CLOSE/OPEN)
	FOCUS	Ajuste o foco (NEAR/FAR)
	ZOOM	Mais zoom/Menos zoom (WIDE/TELE)
8 Navegar, ENTER, ESC	Navegar	Navegue pelos itens do menu.
	ENTER	Vá para um item desejado usando os botões de navegação e o seleccione.
	ESC	Cancele a operação atual.
9 Botões numéricos (0 a 9)	Utilizados para especificar caracteres numéricos para câmera, monitor, DVR ou Configurações predefinidas.	
10 Barra de seleção do controlador	Utilizada para selecionar uma câmera, monitor ou DVR.	
11 Jog Shuttle	Jog	Utilizado para pesquisar quadros de avanço rápido/retrocesso em modo de execução de DVR.
	Frente/Trás	Avançar/Retroceder/Reproduzir/Avanço rápido/Rebobinar e modo de execução de DVR.

Parte traseira



Item	Descrição	
1 Entrada/saída de vídeo	Porta de entrada/saída de vídeo	
2 MATRIX	Porta de conexão para Matrix	
3 RS-485	PORT 1	Conectada a um controlador, como câmera ou DVR, por meio de comunicações RS-485.
	PORT 2	Conecte a outro controlador do sistema SPC-6000.
4 USB Port	Usada para backup das configurações do controlador do sistema ou para atualizar o firmware.	
5 Alimentação	Porta de entrada de CC de 12 V (— — — +)	
6 Engate do cabo	Para evitar que o cabo de alimentação fique solto. ☒ ■ Certifique-se de utilizar o engate do cabo ao instalar e usar o controlador.	

- ☒ ■ A porta MATRIX contém a linha de alimentação para que você não precise fornecer 12 V de CC separadamente caso esteja utilizando a porta MATRIX.
- A porta MATRIX contém uma única linha que controla os sinais de controle principal e secundário.
- O sinal MATRIX é de nível TTL.
Use o cabo de extensão em menos de 10 metros.

PRECAUÇÕES

- O produto tem o objetivo de ser utilizado apenas em interiores.
- Mantenha-o longe de água ou umidade.
- Não exerça muita força sobre ele.
- Não remova o cabo de alimentação com força.
- Não o desmonte sozinho.
- Use apenas a faixa de E/S classificada.
- Use apenas o cabo de alimentação fornecido.
- Use o plugue de alimentação que contenha o fio terra, caso esteja disponível.
- Instale o controlador do sistema em uma mesa plana.
- O layout da unidade principal e o sistema de fiação são muito importantes para a operação adequada do sistema.
- Se os dispositivos estiverem muito próximos um do outro ou em um ambiente com pouca ventilação, pode ser que o sistema não funcione corretamente.
A inacessibilidade ao sistema torna a reparação difícil ou até mesmo impossível.
- Para evitar uma falha no sistema ou para reduzir o desligamento do sistema, providencie espaço suficiente para ventilação e feche a tampa com firmeza.
- Não desmonte o controlador do sistema sem o devido cuidado, pois há alta tensão em seu interior.

- Temperatura de operação : 0°C a 40°C
- Temperatura de armazenamento : -20°C a 60°C
- Umidade de operação : 10% a 70% de umidade relativa
- Umidade de armazenamento : 10% a 90% de umidade relativa
- Consumo de energia : CC de 12 V, máx. 4 W (—⎓—+)

ANTES DA INSTALAÇÃO

- É necessário desligar o produto antes de sua instalação.
- Um impacto ou vibração grave podem ocasionar falha no sistema.
- Mantenha o equipamento longe de campo magnético forte, interferência elétrica ou de dispositivos sem fio, tais como rádios ou aparelhos de TV.
- Mantenha o local de instalação sempre limpo e sem poeira ao instalar ou após você instalar o produto.
- Coloque-o sobre uma superfície não vedada e plana em temperatura ideal. Instale-o a pelo menos 15 cm de distância de uma parede.
- Não feche o orifício de ventilação ou coloque um objeto condutor sobre o equipamento.
- Não exponha o equipamento a luz solar direta. Mantenha os acessórios ou ferramentas fora do alcance das pessoas e tente evitar risco de danos físicos.
- Caso o equipamento emane fumaça ou odor anormais, isso pode ocasionar um incêndio ou choque elétrico.
Se for o caso, desligue o produto imediatamente e entre em contato conosco para assistência técnica.
- Tome uma atitude adequada se encontrar: chão úmido, cabo de extensão de alimentação não aterrado, cabo de alimentação descascado ou ausência de aterramento de segurança.



- Use um pano seco para limpar. Caso esteja muito sujo ou manchado, use um pano embebido em detergente neutro para limpar.
Não use solventes voláteis, tais como álcool, benzeno ou diluente, pois podem danificar a superfície do produto.
- Não opere o monitor LCD em altas temperaturas; recomenda-se usar a proteção de tela para economizar energia.

AJUSTANDO O ÂNGULO DA TELA DO CONTROLADOR DO SISTEMA

É possível puxar a tela para frente para obter melhor visualização.




installation

ALTERNANDO O LAYOUT DO JOYSTICK E JOG SHUTTLE

É possível alternar a posição do joystick e do módulo jog shuttle segundo sua conveniência.



- Para alternar entre esquerda e direita, desligue o controlador do sistema e alterne os módulos manualmente. Ou, pressione <Alterar> no menu de configuração do controlador e alterne os módulos manualmente. (▶ página 38)



<Inferior>

1. Pressione os dois engates na parte inferior do controlador do sistema para remover o módulo.
2. Remova o joystick e os módulos jog shuttle do controlador e alterne a posição.
Depois que o fizer, insira-os até ouvir um clique.



conexão a um dispositivo externo

O controlador do sistema SPC-6000 pode ser utilizado ligado a um dispositivo externo, como uma câmera ou um DVR.


PARA CONECTAR UM DISPOSITIVO RS-485

Com o controlador do sistema, é possível controlar a câmera PTZ ou DVR compatíveis com protocolos de comunicação RS-485.

1. Conecte a PORT 1 traseira à porta RS-485 da câmera PTZ ou DVR.
2. De acordo com o sistema do dispositivo externo, selecione Half Duplex ou Full Duplex para a conexão.




- Para o sistema Half Duplex, use os terminais TX +/-.
- Para comunicações RS-485, preste bastante atenção à polaridade (+/-).
- Use o bloco de terminais fornecido no pacote do produto.
- Verifique se o dispositivo RS-485 é compatível com SPC-6000.




conexão a um dispositivo externo

Se for conectar o teclado sem o MATRIX



Se for conectar o teclado com o MATRIX



1. Conecte a porta do **[MATRIX]** do controlador principal à porta do **[KEYBOARD]** do matrix. A porta MATRIX contém uma linha de alimentação para que você não precise fornecer 12V de CC separadamente.
2. Conecte TX+ e TX- do subcontrolador a TX+ e TX- do matrix, respectivamente.
 - A taxa de transferência entre subcontroladores em sincronia com MATRIX será fixada em 9600 bps.
 - A ID MATRIX é fixada em <SUB 09>.
3. Conecte o DVR e a câmera PTZ à porta MATRIX.

conexão a um dispositivo externo

Conexão via câmera PTZ

Conectando a porta RS-485 na parte traseira da câmera PTZ à PORT 1 do SPC-6000, é possível controlar a câmera.



- Dependendo da câmera, a polaridade pode ser diferente.


Para obter mais informações, consulte o manual do usuário da câmera PTZ.

Para o sistema half duplex

- Conecte o RX (+) da porta RS-485 da câmera PTZ ao TX (+) da PORT 1 do SPC-6000.
- Conecte o RX (-) da porta RS-485 da câmera PTZ ao TX (-) da PORT 1 do SPC-6000.

Para o sistema full duplex

- Conecte o RX (+) da porta RS-485 da câmera PTZ ao TX (+) da PORT 1 do SPC-6000.
- Conecte o RX (-) da porta RS-485 da câmera PTZ ao TX (-) da PORT 1 do SPC-6000.
- Conecte o TX (+) da porta RS-485 da câmera PTZ ao RX (+) da PORT 1 do SPC-6000.
- Conecte o TX (-) da porta RS-485 da câmera PTZ ao RX (-) da PORT 1 do SPC-6000.



Conexão de DVR das séries SRD-16XX/8XX ou SHR-8/7/6XXX


Conecte DVR e SPC-6000 usando a porta RS-485 na parte traseira do DVR.

Para o sistema half duplex

- Conecte o TX (+) da porta RS-485 do DVR ao TX (+) da PORT 1 do SPC-6000.
- Conecte o TX (-) da porta RS-485 do DVR ao TX (-) da PORT 1 do SPC-6000.

Para o sistema full duplex

- Conecte o TX (+) da porta RS-485 do DVR ao RX (+) da PORT 1 do SPC-6000.
- Conecte o TX (-) da porta RS-485 do DVR ao RX (-) da PORT 1 do SPC-6000.
- Conecte o RX (+) da porta RS-485 do DVR ao TX (+) da PORT 1 do SPC-6000.
- Conecte o RX (-) da porta RS-485 do DVR ao TX (-) da PORT 1 do SPC-6000.




conexão a um dispositivo externo

Conexão da série SRD-4XX ou SHR-604X ao DVR

Conecte a porta RS-485 na parte traseira da série SRD-4XX ou SHR-604X ao SPC-6000.

❖ Para o sistema half duplex

- Conecte o TX (+) do SRD-4XX ou SHR-604X ao TX (+) da PORT 1 do SPC-6000.
- Conecte o TX (-) do SRD-4XX ou SHR-604X ao TX (-) da PORT 1 do SPC-6000.




CONEXÃO A OUTRO CONTROLADOR DO SISTEMA

- É possível conectar até 16 controladores simultaneamente.
- Para configurações de comunicação do controlador, consulte “sublista” da “configurações do menu”. (▶ página 37)


Para o sistema half duplex

- Conecte o TX (+) da PORT 2 do SPC-6000 ao TX (+) da PORT 2 do outro SPC-6000.
- Conecte o TX (-) da PORT 2 do SPC-6000 ao TX (-) da PORT 2 do outro SPC-6000.



Para o sistema full duplex

- Conecte o TX (+) da PORT 2 do SPC-6000 do controlador principal ao RX (+) da PORT 2 do SPC-6000 do subcontrolador.
- Conecte o TX (-) da PORT 2 do SPC-6000 do controlador principal ao RX (-) da PORT 2 do SPC-6000 do subcontrolador.
- Conecte o RX (+) da PORT 2 do SPC-6000 do controlador principal ao TX (+) da PORT 2 do SPC-6000 do subcontrolador.
- Conecte o RX (-) da PORT 2 do SPC-6000 do controlador principal ao TX (-) da PORT 2 do SPC-6000 do subcontrolador.



- É necessário usar a PORT 2 caso você queira se conectar a outro controlador do sistema.

usando o menu

PRIMEIROS PASSOS

1. Ligue todos os dispositivos dos componentes do sistema.



2. Ao conectar o adaptador de alimentação à porta traseira do controlador do sistema, a caixa de diálogo de login é exibida.

3. Use o teclado numérico para inserir a senha e pressione [ENTER].

O menu principal do sistema de controle PTZ é exibido.
■ A senha padrão é "4321".



CONTROLANDO A CÂMERA PTZ

Para entrar no modo de controle PTZ

Pressione [PTZ] no controlador.

Para selecionar uma câmera

1. Use os botões numéricos para inserir o número da câmera de sua escolha.
2. Pressione [CAM] ou [ENTER].



Controle de Expansão/inclinação

Você pode usar o joystick do controlador para ajustar o ângulo de expansão/inclinação da câmera. Quanto mais afastado do centro estiver o joystick, mais rápido será o movimento.

Zoom

Gire o joystick no sentido horário ou pressione **[ZOOM TELE]** para controlar a função de aproximação da câmera.

Gire o joystick no sentido anti-horário ou pressione **[ZOOM TELE]** para controlar a função de afastamento da câmera.

Foco

Pressione **[FOCUS FAR]** ou **[FOCUS NEAR]** no controlador para ajustar o foco da câmera.

Íris

Pressione **[IRIS OPEN]** ou **[IRIS CLOSE]** no controlador para ajustar o brilho do vídeo da câmera.

Predefinição

Mova a câmera até um ponto predeterminado.

Para configurar uma predefinição

1. Selecione a câmera para a qual você deseja configurar uma predefinição.
2. Use o joystick para mover a câmera até um ponto desejado.
3. Pressione **[SETUP]** e digite um número desejado usando os botões numéricos. Pressione **[PRESET]**.

Para executar a predefinição

1. Selecione uma câmera.
2. Insira os números desejados usando os botões numéricos e pressione **[PRESET]**.
3. A predefinição será executada.



- Para as séries de dome PTZ SCP-3430, SCP-2430, SCP-3250 e SCP-2250, no máximo 512 predefinições serão suportadas se apenas o protocolo Samsung E for selecionado.

usando o menu

Oscilação

Você pode mover a câmera entre dois pontos de predefinição para monitorar o curso.

Configuração da oscilação


1. Selecione <Oscilação> na tela de menu.
2. Pressione <CONFIGURAÇÃO>.



3. Use os botões numéricos para selecionar PAN/TILT e especificar a predefinição inicial e final.
4. Especifique a velocidade e o tempo de permanência.
5. Pressione <Salvar>.

Para executar a oscilação

1. Selecione <Oscilação> na tela de menu.
2. Use os botões numéricos para selecionar PAN ou TILT para o tipo de oscilação.
3. A função de oscilação será executada.




Grupo

Você pode fazer um grupo de várias predefinições antes de chamá-las em sequência.


Para configurar um grupo

1. Selecione <Grupo/VARRED.> na tela de menu.
2. Selecione <Configuração do Grupo>.
3. Insira o número do grupo e pressione [ENTER].
4. Especifique a velocidade e o tempo de permanência.
5. Pressione <Salvar>.



Para executar a função de grupo

1. Selecione <Grupo/VARRED.> na tela de menu.
2. Selecione <Execução do Grupo>.
3. Insira o número do grupo e pressione [ENTER].
4. A função de grupo será executada.



usando o menu

Tour

Você pode fazer um tour em pelo menos um grupo antes de executar os grupos em sequência.

Para configurar um tour

1. Selecione <Tour> na tela de menu.
2. Selecione <Configuração do Tour>.
3. Cada vez em que você pressionar o número de um grupo que deseja adicionar ao tour, o grupo será adicionado a ele.
 - Você pode adicionar até 6 grupo a um tour.
4. Pressione <Salvar> para aplicar suas configurações.



Para executar a função de tour

1. Selecione <Tour> na tela de menu.
2. Selecione <Execução do Tour>.
3. A função de tour será executada.

Reconhecimento

Com o joystick ou os botões da câmera, você pode instruir o controlar a registrar o movimento da câmera por um período específico e repetir o movimento.

Para configurar um reconhecimento

1. Selecione <Reconhecimento/PADRÃO> na tela de menu.
2. Selecione <GRAVAR>.
3. Especifique um número de reconhecimento para a gravação.
4. Com o joystick ou os botões da câmera, controle o movimento da câmera conforme desejado.



Para executar um reconhecimento

1. Selecione <Reconhecimento/Padrão> na tela de menu.
2. Selecione <REPROD.>.
3. Especifique o número de reconhecimento a ser executado.
4. A função de reconhecimento será executada.



Foco automático

1. Selecione <A/F> na tela de menu.
2. O recurso de foco automático será ativado.

Redefinir

1. Selecione <Redefinir> na tela de menu.
2. A câmera será redefinida.

Travar alvo

1. Selecione <Travar Alvo> na tela de menu.
Aparecerá uma caixa retangular no vídeo da câmera.
2. Mova o objeto a ser reconhecido para baixo e pressione [ENTER].
 - Isso se aplica apenas a uma câmera que suporta a função de rastreamento.



Rastrear

1. Selecione <Rastrear> na tela de menu.
2. A função de rastreamento será executada.
 - Isso se aplica apenas a uma câmera que suporta a função de rastreamento.

usando o menu

CONTROLANDO O DVR

Dependendo do modelo, o DVR pode ter diferentes recursos disponíveis. Para obter mais detalhes, consulte o manual de usuário aplicável.



- Uma configuração incorreta pode causar um problema no uso do DVR.

Para selecionar um DVR

1. Pressione **[DVR]**.
2. Use os botões numéricos para inserir um número de DVR (0~255) e pressione **[ENTER]**.



3. A tela principal será exibida.
Varia dependendo do modelo.



- Para um DVR que suporte protocolos SRD, a tela de menu exibe apenas os itens de menu disponíveis.
- Se você conectar um DVR que suporte protocolos SRD, as configurações de PTZ serão feitas automaticamente.



Para selecionar um canal de DVR

1. Use os botões numéricos para inserir o número do canal de DVD desejado.
2. Pressione **[CAM]**.

Para controlar o menu do DVR

1. Para controlar os menus do DVR selecionado, pressione **[MENU]** na barra de controle do DVR.
2. Use os botões de direção para passar ao item desejado e pressione o botão **[ENTER]**.

Para controlar o dispositivo PTZ conectado ao DVR

Dependendo do modelo de DVR, você pode não controlar o dispositivo PTZ conectado ao DVR. Nesse caso, pressione **[PTZ]** para alternar entre o modo de controle do DVR e o modo de controle da câmera.

Para controlar o dispositivo PTZ no modo DVR

1. Pressione **[PTZ]** no canto inferior direito da tela de menu do DVR.
2. Use o joystick para controlar a câmera PTZ em conexão com o DVR.
Para obter mais detalhes, consulte o manual do usuário do DVR.

Login no DVR

Você deve acessar o menu do DVR com a conta de usuário correta.



- Selecione **<Entrada>** para desativar a caixa de entrada. Agora você pode usar apenas os botões numéricos para mudar o canal ou inserir a senha do DVR sem usar o botão **[CAM]**.
Selecione **<Entrada>** novamente para voltar ao modo anterior.



usando o menu

CONTROLANDO O MATRIX

Para controlar o monitor e a câmera no modo Matrix

Você pode controlar o monitor e a câmera no modo Matrix.

1. Pressione [MTX].
2. Selecione um número de monitor e pressione [MON].
3. Selecione um número de câmera e pressione [CAM].
O monitor selecionado reproduzirá o vídeo da câmera selecionada.



Para reproduzir o vídeo atual no monitor anterior

Insira o número da câmera a ser selecionada.

1. Pressione o número da câmera na tela de configuração Matrix e pressione [CAM].
2. O monitor anterior reproduzirá o vídeo da câmera selecionada no momento.

Seleção automática

Você pode fazer uma programação de operações no menu de configuração Matrix.

1. Selecione um número de monitor no menu de configuração Matrix e pressione [MON].
2. Na tela do menu, pressione <Sel. Conf. Autom.>.



3. Quando a tela <Sel. Conf. Autom.> aparecer, selecione o monitor e a câmera a serem conectados e especifique o tempo de permanência.
4. Quando as configurações da câmera 1 estiverem concluídas, pressione <Continuar> e especifique o tempo de permanência da câmera 2.
5. Ao concluir a configuração do tempo de permanência, pressione <Salvar>.



Executar / Manter

Executar/suspender executará ou suspenderá a configuração de seleção automática feita.

Pressione a combinação de <Tudo> + <Exec.> para executar a seleção automática definida.

Pressione a combinação de <Tudo> + <Manter> para interromper a seleção automática e aguardar sua entrada.



- Para instruir uma operação de um monitor individual, pressione uma combinação de "número do monitor" + <Exec.> ou "número do monitor" + <Manter>.

Tocar Alarme

Se o sensor for disparado no modo Repr. Alarme, a sirene soará se a unidade de alarme a tiver definido como LIG, ou você pode controlar dispositivos externos usando os indicadores, se a unidade de alarme tiver a saída de controle do indicador.

Para liberar o alarme da unidade, pressione <Repr. Alarme> novamente.

configurações do menu

PARA ACESSAR O MENU PRINCIPAL


1. Pressione o botão **[FUNC]** no controlador e clique em **[SETUP]**.
2. Quando a tela do sistema de configuração aparecer, selecione o item de menu desejado.



CONFIGURAÇÃO DE PTZ

Na tela de configuração de PTZ, você pode especificar o protocolo e a taxa de transmissão.

1. Pressione **<PTZ>** na tela principal de configuração.
2. Use os botões de direção ou o joystick para passar ao menu desejado.
3. Você pode alterar as configurações usando **[ZOOM WIDE]** ou **[ZOOM TELE]**.
4. Ao concluir as configurações do protocolo e taxa de transmissão, pressione **<Salvar>**.
5. Para sair da tela Conf. PTZ, pressione **<OK>** ou **[ESC]**.



- Antes de passar a uma página diferente, grave suas configurações.

CONFIGURAÇÃO DE DVR

Na tela de configuração de DVR, você pode especificar o tipo de DVR e a taxa de transmissão.

1. Na tela de configuração principal, pressione <DVR>.
2. Use os botões de direção ou o joystick para selecionar o número da câmera e especificar o tipo de DVR.
3. Especifique a taxa de transmissão.
4. Quando estiver pronto, pressione <Salvar>.
5. Para sair da tela Conf. de DVR, pressione <OK> ou [ESC].



- Antes de passar a uma página diferente, grave suas configurações.

• Sistema Conf.

NO.	TIPO DVR	BAUD
00000	SRD	9600
00001	SRD	9600
00002	SRD	9600
00003	SRD	9600
00004	SRD	9600
00005	SRD	9600
00006	SRD	9600

Salvar OK

CONFIGURAÇÃO DO CONTROLADOR

ID do controlador

Você pode selecionar RS-485 ou RS-422 para o sistema de comunicação.

1. Selecione RS-485 ou RS-422 para o sistema de comunicação entre o controlador e os dispositivos externos.
2. Pressione o botão da porta para especificar o ID da porta.

• Sistema Conf.

☒ ID Controlador

RS-485 PORT 1 PORT 2

☒ Joystick Botão ☒ Módulo Alterar

☒ Protetor de Tela On ☒ Idioma Português

☒ Redef. Fábrica Redef. ☒ Senha Conf.


Salvar OK

configurações do menu

ID PORTA 1

Você pode especificar o ID do controlador para uso em comunicação com outros dispositivos.


1. Pressione **[Port 1]** na tela de configuração do ID de controle.
2. Especifique o ID e pressione **<Salvar>**.



ID PORTA 2

Você pode especificar o controlador principal ou o subcontrolador para comunicações entre os controladores e também definir o uso da matriz e da sublista.


1. Pressione **[Port 2]** na tela de configuração do ID de controle.
2. Use os botões de direção para selecionar um item desejado e selecionar um sistema de comunicação entre os controladores.
 - Você deve definir a sublista em um ambiente de vários controladores.
3. Quando estiver pronto, pressione **<Salvar>**.



Sub-lista

Para um sistema de comunicação envolvendo o controlador principal e o subcontrolador, você deve configurar a <Sub-lista>.

1. Pressione <Sub-lista>.
2. Use os botões de direção para selecionar um item desejado e configurar as definições usando [ZOOM WIDE] ou [ZOOM TELE].
 - A ID MATRIX é fixada em <SUB 09>.
3. Quando estiver pronto, pressione <Salvar>.
4. Para sair da tela <Sub-lista>, pressione <OK> ou [ESC].



Operação do botão do joystick

You can set the operation for the joystick button.

1. Pressione o <Botão> do joystick.
2. Na tela de operação do botão do joystick, selecione um botão de função para o botão do joystick selecionado.
3. Verifique a configuração atual e pressione <Sair>.



Protetor de tela

Você pode ativar a proteção de tela se não pretender usar o controlador por um longo período.

1. Se desejar exibir uma tela de logotipo, defina a proteção como <On>.
2. Para aplicar as alterações, pressione <OK>; para cancelar sua configuração pressione <Sair>.

configurações do menu

Padrão de fábrica

Você pode restaurar as configurações atuais para o padrão de fábrica.


1. Pressione <Redefinir>.
2. Pressione <OK>.
As configurações atuais retornarão ao padrão de fábrica.
3. Para sair do menu, pressione <Sair>.



Para alternar entre os módulos

Você pode alterar a posição entre o jog shuttle e o joystick da esquerda para a direita e vice-versa.

1. Pressione <Alterar>.
2. Na tela Alterar módulo que aparecer, você pode alternar a posição entre o jog shuttle e o joystick.
3. Para sair da tela, pressione <Sair>.



Idioma

Você pode selecionar um idioma preferencial para a interface do usuário.

1. Pressione <Idioma>.
2. Na tela de seleção de idiomas que aparecer, use os botões de direção ou o joystick para selecionar um idioma preferencial.
 - O idioma será alterado para o selecionado imediatamente.
3. Para sair da tela de seleção de idioma, pressione <Sair>.



Senha

Você pode ativar ou desativar a senha do controlador.

1. Pressione o botão <Conf.> de senha.
2. Para ativar a senha, defina-a como <On>. Se não, defina-a como <Off>.
3. Digite a senha atual.
4. Para aplicar as alterações, pressione <OK>; para cancelar sua configuração pressione <Sair>.



Para alterar a senha

Você pode alterar a senha.

1. Pressione o botão <Conf.> de senha.
2. Digite a senha atual.
3. Forneça uma nova senha.
4. Para aplicar as alterações, pressione <OK>; para cancelar sua configuração pressione <Sair>.



- A senha padrão é "4321".



- A senha padrão pode ser exposta a uma ameaça de hackers, portanto é recomendado alterá-la após a instalação do produto. Observe que a segurança e outras questões relacionadas causadas por uma senha inalterada devem ser de responsabilidade do usuário.

configurações do menu

ATUALIZAÇÃO DO FIRMWARE

Você pode atualizar o firmware atual usando os arquivos de firmware na memória USB.

Para atualizar o firmware do controlador

Você pode baixar os arquivos de firmware mais recentes e atualizar o controlador.

1. Conecte a memória USB contendo os arquivos de firmware mais recentes para o controlador do sistema.
2. Na tela de configuração do menu, pressione <Atualizar>.
3. Pressione <Atual. Firmware Controlador>.



4. Na tela de atualização, pressione <OK>.
O status da atualização será exibido na barra de progresso.
5. Aguarde até que o sistema seja reiniciado após a atualização.



- Não desconecte a memória USB ou o cabo de alimentação durante a atualização. Caso contrário, pode haver falha na atualização do firmware ou falha no sistema.




Para fazer backup das configurações do controlador

Se você deseja alterar o controlador ou substituir a câmera, é possível salvar as configurações do controlador como um arquivo e carregá-las na nova câmera.

1. Na tela de configuração do menu, pressione **<Atualizar>**.
2. Pressione **<Backup Conf. Controlador>**.
3. Pressione **<OK>**.
Será iniciado o processo de backup.



- Não desconecte a memória USB ou o cabo de alimentação durante o backup. Caso contrário, pode haver falha no backup das configurações do controlador.




Para restaurar as configurações do controlador

Se você tiver configurado o controlador inadequadamente ou reinicializado, é possível carregar as configurações atuais para um controlador diferente.

1. Na tela de configuração do menu, pressione **<Atualizar>**.
2. Pressione **<Restaurar Conf. Controlador>**.
3. Pressione **<OK>**.
Será iniciado o processo de restauração.



- Não desconecte a memória USB ou o cabo de alimentação durante a restauração. Caso contrário, pode haver falha na restauração das configurações do controlador.



configurações do menu


PARA VERIFICAR AS INFORMAÇÕES DO CONTROLADOR

Você pode verificar o nome do modelo e a versão do software do controlador do sistema.

Tela de status

Você pode verificar o status do controlador.

1. Na tela de configuração do menu, pressione <Status>.
2. Verifique o status do controlador.



apêndice

SPECIFICATIONS

Item	Descrição
Sistema de comunicação	RS-485/422 (alcance do controle remoto : máx. de 1km) TTL (para controle do matrix)
Unidades a controlar	Máx. 255
Taxa de transmissão	2.400 a 38.400 bps
Compatibilidade	PTZ / DVR / MATRIX / RECEPTOR
Protocolo (PTZ)	Samsung-T, Samsung-E, PELCO-D, PELCO-P, Panasonic, Vicon, AD, Honeywell, ELMO, BOSCH, GE
Protocolo (DVR)	SVR, SRD, SRP
Protocolo (MATRIX)	SMX-25632
Protocolo (RECEPTOR)	Samsung-T
Suporte multilíngüe	Inglês, Espanhol, Francês, Italiano, Alemão, Turco, Polonês, Russo, Português, Sueco, Holandês, Tcheco, Sérvio, Coreano, Chinês, Japonês
LCD Exibição	LCD TFT de 5 pol. + LCD de toque
Porta de vídeo	Backup / restauração, atualização de software
Video Port	Entrada de vídeo BNC, saída loop-through
Joystick	Controle PTZ (zoom de 3 eixos)
Jog Shuttle	Controle de reprodução do DVD
Alimentação	12VCC, máx. 4W
Temperatura de operação	0°C a 40°C
Umidade de operação	10 a 70% (sem condensação)
Dimensão	459,1(L) x 59,1(A) x 177,9(P) mm
Peso	Aproximadamente 1,5 kg (adaptador excluído)

PERGUNTAS E RESPOSTAS

Problema	Ação
Não consigo me comunicar com o controlador do sistema.	• Verifique se o cabo de comunicação RS-485 está conectado apropriadamente. • Se o estado da comunicação for instável devido a um ruído na linha de comunicação, conecte a porta G do dispositivo à porta G da SPC-6000.
	• Verifique se o endereço do controlador do sistema está especificado apropriadamente. • Para especificar o endereço, consulte "Configuração de Comunicação RS-485" em "Configurações do Menu". (► página 35)
A memória USB não foi reconhecida apropriadamente.	• Verifique se a memória USB está funcionando apropriadamente. • Use apenas uma memória USB e tente novamente.



- O painel de LCD do controlador do sistema é uma peça consumível.
Para comprar o painel, entre em contato com o distribuidor ou centro de serviços.

GPL/LGPL SOFTWARE LICENSE

The software included in this product contains copyrighted software that is licensed under the GPL/LGPL. You may obtain the complete Corresponding Source code from us for a period of three years after our last shipment of this product by sending email to help.cctv@samsung.com

If you want to obtain the complete Corresponding Source code in the physical medium such as CD-ROM, the cost of physically performing source distribution might be charged.

- GPL S/W
 - Linux Kernel, QT, Busybox, Sysvinit, dosfstools, Uboot, Bash, initutils
 - LGPL S/W
 - gLibc
-

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.
51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software-- to make sure the software is free for all its users.

This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price.

Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs ; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have.

You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps :

(1)copyright the software, and (2)offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

Version 2, June 1991 Copyright (C) 1989, 1991 Free Software Foundation, Inc.
51 Franklin S

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License.

The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law : that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License ; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty ; and give any other recipients of the Program a copy of this License along with the program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions :

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception:if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you ; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program. In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following :

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange ; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange ; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License.

However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works.

These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all.

For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances. It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system ; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation ; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING

RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

one line to give the program's name and an idea of what it does.

Copyright (C)yyyy name of author

This program is free software ; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation ; either version 2 of the License, or (at your option)any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY ; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program ; if not, write to the Free Software Foundation, Inc.,51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA.

Also add information on how to contact you by electronic and paper mail. If the program is interactive, make it output a short notice like this when it starts in an interactive mode :

Gnomovision version 69,

Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO

WARRANTY ; for details type 'show w'. This is free software, and you are welcome to redistribute it under certain conditions ; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c' ; they could even be mouse-clicks or menu items-- whatever suits your program.

You should also get your employer (if you work as a programmer)or your school, if any, to sign a "copyright disclaimer" for the program,if necessary. Here is a sample ; alter the names:

Yoyodyne, Inc.,hereby disclaims all copyright interest in the program 'Gnomovision' (which makes passes at compilers) written by James Hacker.

signature of Ty Coon, 1 April 1989 Ty Coon, President of Vice This General Public License does not permit incorporating your program into proprietary programs.

If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

GNU GENERAL PUBLIC LICENSE

Version 3, 29 June 2007

Copyright © 2007 Free Software Foundation, Inc. <<http://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The GNU General Public License is a free, copyleft

license for software and other kinds of works. The licenses for most software and other practical works are designed to take away your freedom to share and change the works. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change all versions of a program--to make sure it remains free software for all its users.

We, the Free Software Foundation, use the GNU General Public License for most of our software; it applies also to any other work released this way by its authors. You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for them if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs, and that you know you can do these things.

To protect your rights, we need to prevent others from denying you these rights or asking you to surrender the rights. Therefore, you have certain responsibilities if you distribute copies of the software, or if you modify it: responsibilities to respect the freedom of others.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must pass on to the recipients the same freedoms that you received. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

Developers that use the GNU GPL protect your rights with two steps: (1) assert copyright on the software, and (2) offer you this License giving you legal permission to copy, distribute and/or modify it.

For the developers' and authors' protection, the GPL clearly explains that there is no warranty for this free software. For both users' and authors' sake, the GPL requires that modified versions be marked as changed, so that their problems will not be attributed erroneously to authors of previous versions.

Some devices are designed to deny users access to install or run modified versions of the software inside them, although the manufacturer can do so. This is fundamentally incompatible with the aim of protecting users' freedom to change the software. The systematic pattern of such abuse occurs in the area of products for individuals to use, which is precisely where it is most unacceptable. Therefore, we have designed this version of the GPL to prohibit the practice for those products. If such problems arise substantially in other domains, we stand ready to extend this provision to those domains in future versions of the GPL, as needed to protect the freedom of users.

Finally, every program is threatened constantly by software patents. States should not allow patents to restrict development and use of software on general-purpose computers, but in those that do, we wish to avoid the special danger that patents applied to a free program could make it effectively proprietary. To prevent this, the GPL states that patents cannot be used to render the program non-free.

The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS

0. Definitions.

"This License" refers to version 3 of the GNU General Public License.

"Copyright" also means copyright-like laws that apply to other kinds of works, such as semiconductor masks.

"The Program" refers to any copyrightable work licensed under this License. Each licensee is addressed as "you". "Licensees" and "recipients" may be individuals or organizations.

To "modify" a work means to copy from or adapt all or part of the work in a fashion requiring copyright permission, other than the making of an exact copy. The resulting work is called a "modified version" of the earlier work or a work "based on" the earlier work.

A "covered work" means either the unmodified Program or a work based on the Program.

To "propagate" a work means to do anything with it that, without permission, would make you directly or secondarily liable for infringement under applicable copyright law, except executing it on a computer or modifying a private copy. Propagation includes copying, distribution (with or without modification), making available to the public, and in some countries other activities as well.

To "convey" a work means any kind of propagation that enables other parties to make or receive copies. Mere interaction with a user through a computer network, with no transfer of a copy, is not conveying.

An interactive user interface displays "Appropriate Legal Notices" to the extent that it includes a convenient and prominently visible feature that (1) displays an appropriate copyright notice, and (2) tells the user that there is no warranty for the work (except to the extent that warranties are provided), that licensees may convey the work under this License, and how to view a copy of this License. If the interface presents a list of user commands or options, such as a menu, a prominent item in the list meets this criterion.

1. Source Code.

The "source code" for a work means the preferred form of the work for making modifications to it. "Object code" means any non-source form of a work.

A "Standard Interface" means an interface that either is an official standard defined by a recognized standards body, or, in the case of interfaces specified for a particular programming language, one that is widely used among developers working in that language.

The "System Libraries" of an executable work include anything, other than the work as a whole, that (a) is included in the normal form of packaging a Major Component, but which is not part of that Major Component, and (b) serves only to enable use of the work with that Major Component, or to implement a Standard Interface for which an implementation is available to the public in source code form. A "Major Component", in this context, means a major essential component (kernel, window system, and so on) of the specific operating system (if any) on which the executable work runs, or a compiler used to produce the work, or an object code interpreter used to run it.

The "Corresponding Source" for a work in object code form means all the source code needed to generate, install, and (for an executable work) run the object code and to modify the work, including scripts to control those activities. However, it does not include the work's System Libraries, or general-purpose tools or generally available free programs which are used unmodified in performing those activities but which are not part of the work. For example, Corresponding Source includes interface definition files associated with source files for the work, and the source code for shared libraries and dynamically linked subprograms that the work is specifically designed to require, such as by intimate data communication or control flow between those subprograms and other parts of the work.

The Corresponding Source need not include anything that users can regenerate automatically from other parts of the Corresponding Source.

The Corresponding Source for a work in source code form is that same work.

2. Basic Permissions.

All rights granted under this License are granted for the term of copyright on the Program, and are inalienable provided the stated conditions are met. This License explicitly affirms your unlimited permission to run the unmodified Program. The output from running a covered work is covered by this License only if the output, given its content, constitutes a covered work. This License acknowledges your rights of fair use or other equivalent, as provided by copyright law.

You may make, run and propagate covered works that you do not convey, without conditions so long as your license otherwise remains in force. You may convey covered works to others for the sole purpose of having them make modifications exclusively for you, or provide you with facilities for running those works, provided that you comply with the terms of this License in conveying all material for which you do not control copyright. Those thus making or running the covered works for you must do so exclusively on your behalf, under your direction and control, on terms that prohibit them from making any copies of your copyrighted material outside their relationship with you.

Conveying under any other circumstances is permitted solely under the conditions stated below. Sublicensing is not allowed; section 10 makes it unnecessary.

3. Protecting Users' Legal Rights From Anti-Circumvention Law.

No covered work shall be deemed part of an effective technological measure under any applicable law fulfilling obligations under article 11 of the WIPO copyright treaty adopted on 20 December 1996, or similar laws prohibiting or restricting circumvention of such measures.

When you convey a covered work, you waive any legal power to forbid circumvention of technological measures to the extent such circumvention is effected by exercising rights under this License with respect to the covered work, and you disclaim any intention to limit operation or modification of the work as a means of enforcing, against the work's users, your or third parties' legal rights to forbid circumvention of technological measures.

4. Conveying Verbatim Copies.

You may convey verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice; keep intact all notices stating that this License and any non-permissive terms added in accord with section 7 apply to the code; keep intact all notices of the absence of any warranty; and give all recipients a copy of this License along with the Program.

You may charge any price or no price for each copy that you convey, and you may offer support or warranty protection for a fee.

5. Conveying Modified Source Versions.

You may convey a work based on the Program, or the modifications to produce it from the Program, in the form of source code under the terms of section 4, provided that you also meet all of these conditions:

- The work must carry prominent notices stating that you modified it, and giving a relevant date.
- The work must carry prominent notices stating that it is released under this License and any conditions added under section 7. This requirement modifies the requirement in section 4 to "keep intact all notices".
- You must license the entire work, as a whole, under this License to anyone who comes into possession of a copy. This License will therefore apply, along with any applicable section 7 additional terms, to the whole of the work, and all its parts, regardless of how they are packaged. This License gives no permission to license the work in any other way, but it does not invalidate such permission if you have separately received it.
- If the work has interactive user interfaces, each must display Appropriate Legal Notices; however, if the Program has interactive interfaces that do not display Appropriate Legal Notices, your work need not make them do so.

A compilation of a covered work with other separate and independent works, which are not by their nature extensions of the covered work, and which are not combined with it such as to form a larger program, or in or on a volume of a storage or distribution medium, is called an "aggregate" if the compilation and its resulting copyright are not used to limit the access or legal rights of the compilation's users beyond what the individual works permit. Inclusion of a covered work in an aggregate does not cause this License to apply to the other parts of the aggregate.

6. Conveying Non-Source Forms.

You may convey a covered work in object code form under the terms of sections 4 and 5, provided that you also convey the machine-readable Corresponding Source under the terms of this License, in one of these ways:

- Convey the object code in, or embodied in, a physical product (including a physical distribution medium), accompanied by the Corresponding Source fixed on a durable physical medium customarily used for software interchange.
- Convey the object code in, or embodied in, a physical product (including a physical distribution medium), accompanied by a written offer, valid for at least three years and valid for as long as you offer spare parts or customer support for that product model, to give anyone who possesses the object code either (1) a copy of the Corresponding Source for all the software in the product that is covered

by this License, on a durable physical medium customarily used for software interchange, for a price no more than your reasonable cost of physically performing this conveying of source, or (2) access to copy the Corresponding Source from a network server at no charge.

- c) Convey individual copies of the object code with a copy of the written offer to provide the corresponding Source. This alternative is allowed only occasionally and noncommercially, and only if you received the object code with such an offer, in accord with subsection 6b.
- d) Convey the object code by offering access from a designated place (gratis or for a charge), and offer equivalent access to the Corresponding Source in the same way through the same place at no further charge. You need not require recipients to copy the Corresponding Source along with the object code. If the place to copy the object code is a network server, the Corresponding Source may be on a different server (operated by you or a third party) that supports equivalent copying facilities, provided you maintain clear directions next to the object code saying where to find the Corresponding Source. Regardless of what server hosts the Corresponding Source, you remain obligated to ensure that it is available for as long as needed to satisfy these requirements.
- e) Convey the object code using peer-to-peer transmission, provided you inform other peers where the object code and Corresponding Source of the work are being offered to the general public at no charge under subsection 6d.

A separable portion of the object code, whose source code is excluded from the Corresponding Source as a System Library, need not be included in conveying the object code work.

A "User Product" is either (1) a "consumer product", which means any tangible personal property which is normally used for personal, family, or household purposes, or (2) anything designed or sold for incorporation into a dwelling. In determining whether a product is a consumer product, doubtful cases shall be resolved in favor of coverage. For a particular product received by a particular user, "normally used" refers to a typical or common use of that class of product, regardless of the status of the particular user or of the way in which the particular user actually uses, or expects or is expected to use, the product. A product is a consumer product regardless of whether the product has substantial commercial, industrial or non-consumer uses, unless such uses represent the only significant mode of use of the product.

"Installation Information" for a User Product means any methods, procedures, authorization keys, or other information required to install and execute modified versions of a covered work in that User Product from a modified version of its Corresponding Source. The information must suffice to ensure that the continued functioning of the modified object code is in no case prevented or interfered with solely because modification has been made.

If you convey an object code work under this section in, or with, or specifically for use in, a User Product, and the conveying occurs as part of a transaction in which the right of possession and use of the User Product is transferred to the recipient in perpetuity or for a fixed term (regardless of how the transaction is characterized), the Corresponding Source conveyed under this section must be accompanied by the Installation Information. But this requirement does not apply if neither you nor any third party retains the ability to install modified object code on the User Product (for example, the work has been installed in ROM).

The requirement to provide Installation Information does not include a requirement to continue to provide support service, warranty, or updates for a work that has been modified or installed by the recipient, or for the User Product in which it has been modified or installed. Access to a network may be denied when the modification itself materially and adversely affects the operation of the network or violates the rules and protocols for communication across the network.

Corresponding Source conveyed, and Installation Information provided, in accord with this section must be in a format that is publicly documented (and with an implementation available to the public in source code form), and must require no special password or key for unpacking, reading or copying.

7. Additional Terms.

"Additional permissions" are terms that supplement the terms of this License by making exceptions from one or more of its conditions. Additional permissions that are applicable to the entire Program shall be treated as though they were included in this

License, to the extent that they are valid under applicable law. If additional permissions apply only to part of the Program, that part may be used separately under those permissions, but the entire Program remains governed by this License without regard to the additional permissions.

When you convey a copy of a covered work, you may at your option remove any additional permissions from that copy, or from any part of it. (Additional permissions may be written to require their own removal in certain cases when you modify the work.) You may place additional permissions on material, added by you to a covered work, for which you have or can give appropriate copyright permission.

Notwithstanding any other provision of this License, for material you add to a covered work, you may (if authorized by the copyright holders of that material) supplement the terms of this License with terms:

- a) Disclaiming warranty or limiting liability differently from the terms of sections 15 and 16 of this License; or
- b) Requiring preservation of specified reasonable legal notices or author attributions in that material or in the Appropriate Legal Notices displayed by works containing it; or
- c) Prohibiting misrepresentation of the origin of that material, or requiring that modified versions of such material be marked in reasonable ways as different from the original version; or
- d) Limiting the use for publicity purposes of names of licensors or authors of the material; or
- e) Declining to grant rights under trademark law for use of some trade names, trademarks, or service marks; or
- f) Requiring indemnification of licensors and authors of that material by anyone who conveys the material (or modified versions of it) with contractual assumptions of liability to the recipient, for any liability that these contractual assumptions directly impose on those licensors and authors.

All other non-permissive additional terms are considered "further restrictions" within the meaning of section 10. If the Program as you received it, or any part of it, contains a notice stating that it is governed by this License along with a term that is a further restriction, you may remove that term. If a license document contains a further restriction but permits relicensing or conveying under this License, you may add to a covered work material governed by the terms of that license document, provided that the further restriction does not survive such relicensing or conveying.

If you add terms to a covered work in accord with this section, you must place, in the relevant source files, a statement of the additional terms that apply to those files, or a notice indicating where to find the applicable terms.

Additional terms, permissive or non-permissive, may be stated in the form of a separately written license, or stated as exceptions; the above requirements apply either way.

8. Termination.

You may not propagate or modify a covered work except as expressly provided under this License. Any attempt otherwise to propagate or modify it is void, and will automatically terminate your rights under this License (including any patent licenses granted under the third paragraph of section 11).

However, if you cease all violation of this License, then your license from a particular copyright holder is reinstated (a) provisionally, unless and until the copyright holder explicitly and finally terminates your license, and (b) permanently, if the copyright holder fails to notify you of the violation by some reasonable means prior to 60 days after the cessation.

Moreover, your license from a particular copyright holder is reinstated permanently if the copyright holder notifies you of the violation by some reasonable means, this is the first time you have received notice of violation of this License (for any work) from that copyright holder, and you cure the violation prior to 30 days after your receipt of the notice.

Termination of your rights under this section does not terminate the licenses of parties who have received copies or rights from you under this License. If your rights have been terminated and not permanently reinstated, you do not qualify to receive new licenses for the same material under section 10.

9. Acceptance Not Required for Having Copies.

You are not required to accept this License in order to receive or run a copy of the Program. Ancillary propagation of a covered work occurring solely as a consequence of using peer-to-peer transmission to receive a copy likewise does not require acceptance. However, nothing other than this License grants you permission to propagate or modify any covered work. These actions infringe copyright if you do not accept this License. Therefore, by modifying or propagating a covered work, you indicate your acceptance of this License to do so.

10. Automatic Licensing of Downstream Recipients.

Each time you convey a covered work, the recipient automatically receives a license from the original licensors, to run, modify and propagate that work, subject to this License. You are not responsible for enforcing compliance by third parties with this License.

An "entity transaction" is a transaction transferring control of an organization, or substantially all assets of one, or subdividing an organization, or merging organizations. If propagation of a covered work results from an entity transaction, each party to that transaction who receives a copy of the work also receives whatever licenses to the work the party's predecessor in interest had or could give under the previous paragraph, plus a right to possession of the Corresponding Source of the work from the predecessor in interest, if the predecessor has it or can get it with reasonable efforts.

You may not impose any further restrictions on the exercise of the rights granted or affirmed under this License. For example, you may not impose a license fee, royalty, or other charge for exercise of rights granted under this License, and you may not initiate litigation (including a cross-claim or counterclaim in a lawsuit) alleging that any patent claim is infringed by making, using, selling, offering for sale, or importing the Program or any portion of it.

11. Patents.

A "contributor" is a copyright holder who authorizes use under this License of the Program or a work on which the Program is based. The work thus licensed is called the contributor's "contributor version".

A contributor's "essential patent claims" are all patent claims owned or controlled by the contributor, whether already acquired or hereafter acquired, that would be infringed by some manner, permitted by this License, of making, using, or selling its contributor version, but do not include claims that would be infringed only as a consequence of further modification of the contributor version. For purposes of this definition, "control" includes the right to grant patent sublicenses in a manner consistent with the requirements of this License.

Each contributor grants you a non-exclusive, worldwide, royalty-free patent license under the contributor's essential patent claims, to make, use, sell, offer for sale, import and otherwise run, modify and propagate the contents of its contributor version.

In the following three paragraphs, a "patent license" is any express agreement or commitment, however denominated, not to enforce a patent (such as an express permission to practice a patent or covenant not to sue for patent infringement). To "grant" such a patent license to a party means to make such an agreement or commitment not to enforce a patent against the party.

If you convey a covered work, knowingly relying on a patent license, and the Corresponding Source of the work is not available for anyone to copy, free of charge and under the terms of this License, through a publicly available network server or other readily accessible means, then you must either (1) cause the Corresponding Source to be so available, or (2) arrange to deprive yourself of the benefit of the patent license for this particular work, or (3) arrange, in a manner consistent with the requirements of this License, to extend the patent license to downstream recipients. "Knowingly relying" means you have actual knowledge that, but for the patent license, your conveying the covered work in a country, or your recipient's use of the covered work in a country, would infringe one or more identifiable patents in that country that you have reason to believe are valid.

If, pursuant to or in connection with a single transaction or arrangement, you convey, or propagate by procuring conveyance of, a covered work, and grant a patent license to some of the parties receiving the covered work authorizing them to use, propagate, modify or convey a specific copy of the covered work, then the patent license you

grant is automatically extended to all recipients of the covered work and works based on it.

A patent license is "discriminatory" if it does not include within the scope of its coverage, prohibits the exercise of, or is conditioned on the non-exercise of one or more of the rights that are specifically granted under this License. You may not convey a covered work if you are a party to an arrangement with a third party that is in the business of distributing software, under which you make payment to the third party based on the extent of your activity of conveying the work, and under which the third party grants, to any of the parties who would receive the covered work from you, a discriminatory patent license

- a) in connection with copies of the covered work conveyed by you (or copies made from those copies), or
- b) primarily for and in connection with specific products or compilations that contain the covered work, unless you entered into that arrangement, or that patent license was granted, prior to 28 March 2007.

Nothing in this License shall be construed as excluding or limiting any implied license or other defenses to infringement that may otherwise be available to you under applicable patent law.

12. No Surrender of Others' Freedom.

If conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot convey a covered work so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not convey it at all. For example, if you agree to terms that obligate you to collect a royalty for further conveying from those to whom you convey the Program, the only way you could satisfy both those terms and this License would be to refrain entirely from conveying the Program.

13. Use with the GNU Affero General Public License.

Notwithstanding any other provision of this License, you have permission to link or combine any covered work with a work licensed under version 3 of the GNU Affero General Public License into a single combined work, and to convey the resulting work. The terms of this License will continue to apply to the part which is the covered work, but the special requirements of the GNU Affero General Public License, section 13, concerning interaction through a network will apply to the combination as such.

14. Revised Versions of this License.

The Free Software Foundation may publish revised and/or new versions of the GNU General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies that a certain numbered version of the GNU General Public License "or any later version" applies to it, you have the option of following the terms and conditions either of that numbered version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of the GNU General Public License, you may choose any version ever published by the Free Software Foundation.

If the Program specifies that a proxy can decide which future versions of the GNU General Public License can be used, that proxy's public statement of acceptance of a version permanently authorizes you to choose that version for the Program.

Later license versions may give you additional or different permissions. However, no additional obligations are imposed on any author or copyright holder as a result of your choosing to follow a later version.

15. Disclaimer of Warranty.

THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. Limitation of Liability.

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MODIFIES AND/OR CONVEYS THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

17. Interpretation of Sections 15 and 16.

If the disclaimer of warranty and limitation of liability provided above cannot be given local legal effect according to their terms, reviewing courts shall apply local law that most closely approximates an absolute waiver of all civil liability in connection with the Program, unless a warranty or assumption of liability accompanies a copy of the Program in return for a fee.

END OF TERMS AND CONDITIONS

GNU LESSER GENERAL PUBLIC LICENSE

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc. 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301

USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages—typically libraries—of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed

on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each license is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code

for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) The modified work must itself be a software library. b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change. c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License. d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful. (For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.) These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete

corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that

(1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.

- d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.
- e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

- a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.
- b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE, EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found. one line to give the library's name and an idea of what it does.

Copyright (C) year name of author

This library is free software; you can redistribute it and/ or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA Also add information on how to contact you by electronic and paper mail.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the library 'Frob' (a library for tweaking knobs) written by James Random Hacker.

signature of Ty Coon, 1 April 1990 Ty Coon, President of Vice.



REDE DE VENDAS

SAMSUNG TECHWIN CO., LTD.

Samsungtechwin R&D Center, 701, Sampyeong-dong, Bundang-gu, Seongnam-si, Gyeonggi-do, Korea, 463-400
TEL : +82-70-7147-8740~60 FAX : +82-31-8018-3745

SAMSUNG TECHWIN AMERICA Inc.

100 Challenger Rd. Suite 700 Ridgefield Park, NJ 07660
Toll Free : +1-877-213-1222 Direct : +1-201-325-6920
Fax : +1-201-373-0124
www.samsungcctvusa.com

SAMSUNG TECHWIN EUROPE LTD.

Samsung House, 1000 Hillswood Drive, Hillswood Business
Park Chertsey, Surrey, UNITED KINGDOM KT16 0PS
TEL : +44-1932-45-5300 FAX : +44-1932-45-5325

www.samsungtechwin.com
www.samsungsecurity.com