

SÍŤOVÁ TERMOKAMERA

Stručná příručka

TNO-C4040T/TNO-C4042T

TNO-C4050T/TNO-C4052T

TNO-C4060T/TNO-C4062T

TNO-C4080T/TNO-C4082T



Important

Please check 'Manuals' from our website, before connecting to the Supply,
<https://www.hanwhavision.com/en/download-data/>

Warranty

For details, see the Product Warranty Information page on Hanwha Vision website.
<https://www.hanwhavision.com/en/support/warranty/>

Videos processed by surveillance equipment cannot be accessed arbitrarily by the manufacturer.

We recommend to use the officially compatible VMS version or latest Hanwha NVR version when integrating with VMS or Hanwha NVR.



Hanwha Vision cares for the environment at all product manufacturing stages, and is taking measures to provide customers with more environmentally friendly products.

The Eco mark represents Hanwha Vision's devotion to creating environmentally friendly products, and indicates that the product satisfies the EU RoHS Directive.



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract.

This product and its electronic accessories should not be mixed with other commercial wastes for disposal.






Correct disposal of batteries in this product

(Applicable in the European Union and other European countries with separate battery return systems.)

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.

SAFETY INFORMATION




COMPONENT

Príslušenství se může lišit v závislosti na zemi nebo regionu.


- TNO-C4040T/TNO-C4042T/TNO-C4050T/TNO-C4052T/TNO-C4060T/TNO-C4062T

* Tvar objektivu se může lišit v závislosti na čísle modelu.




- TNO-C4080T/TNO-C4082T

* Tvar objektivu se může lišit v závislosti na čísle modelu.




INSTALLATION

1





2



INSTALLATION

3



- Nezahrnuto: Micro SD karta




INSTALLATION

4-1

- Přímá instalace na zeď/strop




4-2





INSTALLATION

5-1

- Instalace pomocí trubky




5-2




INSTALLATION

6-1

- Instalace síťového kabelu (IP66/IP67)




6-2




INSTALLATION

6-3




6-4




INSTALLATION

7-1

- Instalace kabelů audio/alarmu/RS-485/napájení




7-2




INSTALLATION

8





9




INSTALLATION

10




INSTALLATION

11




12




- Nezahmuto: Kličenka Wi-Fi, adaptér OTG



INSTALLATION


13-1






INSTALLATION

13-3




INSTALLATION



14-1



- Při zaostřování (TNO-C404*T/TNO-C405*T/TNO-C406*T)




INSTALLATION

14-2

- Při zaostřování (TNO-C408*T)



15



NASTAVENÍ HESLA

Při prvním otevření produktu musíte zaregistrovat přihlašovací heslo.

Change administrator password

New password

Confirm new password

- If the password is 8 to 9 characters long, it must include at least 2 of the following character types: English uppercase letters, English lowercase letters, numbers, and special characters. (support up to 64 characters)
- If the password is 10 characters or longer, it must include at least 2 of the following character types: English uppercase letters, English lowercase letters, numbers, and special characters.
- ID may not be used as password. The password and ID cannot be identical.
- The following special characters can be used: ~!@#\$%^&*()_+=-{}[]\|;:'" <>.,?/
- You may not use more than 4 consecutive characters, (example: 1234, abcd, etc.)
- You may not use the same character 4 or more times consecutively, (example: 11, 1111, aaaa, etc.)

Apply



- Pro nové heslo s 8 až 9 znaky musíte použít alespoň 3 z následujících typů znaků: velké písmeno/malé písmeno, číslice a speciální znaky. Pro heslo s 10 znaky nebo delší musíte použít alespoň 2 typy výše uvedených znaků. (podporováno je až 64 znaků)

- Povolené speciální znaky. :

~!@#\$%^&*()_+=-{}[]\|;:'" <>.,?/

- Mezera není v heslu povolena.
- Heslo a ID nesmí být totožné.
- Z důvodu zvýšení bezpečnosti nelze jako heslo použít opakovaně stejný znak nebo použít znaky, které na klávesnici následují za sebou.
- Zapamatujte si nastavené heslo, protože v případě jeho ztráty budete muset produkt resetovat stisknutím tlačítka [SET].

PŘIHLÁŠENÍ

Při pokusu o přístup ke kameře se zobrazí okno pro přihlášení.

Pro přístup ke kameře zadejte uživatelské jméno a heslo.

- 1 Vepište „admin“ do vstupního pole <User Name>.
- 2 Zadejte heslo do pole <Password>.
- 3 Klepněte na tlačítko [Sign in].

PŘIPOJOVÁNÍ K WIFI

Nastavení kamery

- 1 Připojte do zásuvky USB typu C konektor OTG (typ C) a hardwarový klíč WiFi.

Nastavení smartphonu

- 1 Proveďte instalaci instalační aplikace Wisenet.
- 2 Po zapnutí WiFi vyberte SSID kamery.
- 3 Spustíte instalační aplikaci Wisenet.
- 4 Když se přihlásíte ke kameře, video se připojí.
- 5 Během sledování videa na smartphonu můžete nastavit úhel zobrazení.



microSD, microSDHC, and microSDXC Logos are trademarks of SD-3C LLC.

microSD, microSDHC, microSDXC are trademarks or registered trademarks of SD-3C, LLC in the United States, other countries or both.



Подлежит использованию по назначению
в нормальных условиях
Срок службы : 7 лет.

Türkiye Distribütörü

EDS Elektronik Destek Sanayi ve Ticaret Ltd. Şti.

Meclis Mah. Teraziler Cad. Hayran Sk. (Eskisi Kılıç Sk.) No: 4 Sancaktepe / İstanbul / Türkiye
Tel +90.216.313.25.15

ENTES ELEKTRONİK CİHAZLAR İMALAT VE TİC. A.Ş.

Dudullu Org.San.Bölg. 1. Cad. No:23 34776 Ümraniye / İstanbul / Türkiye
Tel +90.216.313.01.10

TEKNOMAKS TEKNOLOJİ / TEKNOMAKS BİLİSİM

MERDİVENKÖY MAH.DİKYOL SOK. BUSINESS İSTANBUL No:2, Kat:7, D:B67, 34732 Kadıköy / İstanbul / Türkiye
Tel +90.212.217.54.22

Cihazın Ticaret Bakanlığına önerilen ortalama ömrü

Cihazın EEE yönetmeliklerine uygun olduğuna benzer beyan

