

CÂMARA DE REDE

Guia de consulta rápida

XNO-6083R/XNO-8083R/XNO-9083R
XNB-6003/XNB-8003/XNB-9003



Important

Please check 'Manuals' from our website, before connecting to the Supply,
<https://www.hanwhavision.com/en/download-data/>

Warranty

Please check "Product warranty information" from our website.
<https://www.hanwhavision.com/en/support/warranty/>

We recommend to use the officially compatible VMS version or latest Hanwha NVR version when integrating with VMS or Hanwha NVR.



Hanwha Vision cares for the environment at all product manufacturing stages, and is taking measures to provide customers with more environmentally friendly products.

The Eco mark represents Hanwha Vision's devotion to creating environmentally friendly products, and indicates that the product satisfies the EU RoHS Directive.



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.





Correct disposal of batteries in this product

(Applicable in the European Union and other European countries with separate battery return systems.)






This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.

SAFETY INFORMATION




SAFETY INFORMATION




Câmera canhão

XNO-6083R/XNO-8083R/XNO-9083R



Câmera da caixa




XNB-6003/XNB-8003/XNB-9003



COMPONENT


Dado que para cada país de vendas, os acessórios não são os mesmos.

- XNO-6083R/XNO-8083R/XNO-9083R




INSTALLATION

1




2

- Não incluído : Cartão Micro SD




INSTALLATION

3




4



INSTALLATION


5

- Instalação direta em parede/teto




6-1

- Instalação com tubo




INSTALLATION

6-2




7-1

- Instalar cabo de rede/de alimentação




INSTALLATION

7-2




8-1




INSTALLATION

8-2




9




INSTALLATION

10




11




13

INSTALLATION

12



13




14

INSTALLATION

14

- Não incluído: Dongle Wi-fi, adaptador OTG




15





INSTALLATION

16



17








COMPONENT

Dado que para cada país de vendas, os acessórios não são os mesmos.

- XNB-6003/XNB-8003/XNB-9003




! Opção (não incluídas)



Lente de suporte CS


INSTALLATION

1




INSTALLATION

2





3




INSTALLATION

4




INSTALLATION

5



6

- Não incluído: Dongle Wi-fi, adaptador OTG




INSTALLATION

7




8



CONFIGURAÇÃO DE SENHA

Quando voce acessar o produto pela primeira vez, voce deve registrar o logon e senha.



The image shows a web form titled "Administrator password change". It has two input fields: "New password" and "Confirm new password". Below these fields is a list of password requirements:

- If the password is 8 to 9 characters long, then it must include a combination of at least 3 of the following character types: alphabet letters with uppercase or lowercase, numbers, and special characters
- If the password is longer than 10 characters, then it must include a combination of at least 2 of the following character types: alphabet letters with uppercase or lowercase, numbers, and special characters
- User name may not be used as password
- The following special characters can be used: ~!@#\$%^&*()_-=+[]{}.;:/
- You may not use more than 4 consecutive characters (example: 1234, abcd, etc.)
- You may not use the same character 4 or more times consecutively (example: 111, 1111, aaas, etc.)

At the bottom of the form is an "Apply" button.



- Para uma nova senha com 8 a 9 dígitos, você deve usar pelo menos 3 dos seguintes: letras maiúsculas/minúsculas, números e caracteres especiais. Para uma senha com 10 a 15 dígitos, você deve usar pelo menos 2 tipos dos mencionados.
 - Caracteres especiais são permitidos. : ~!@#\$%^&*()_-=+[]{}.;:/
- Não é possível usar espaço na senha.
- A senha e a ID não podem ser idênticas.
- Para garantir mais segurança, não crie senhas que usem caracteres repetidos ou em sequência no teclado.
- Lembre-se da senha definida, pois será necessário redefinir o produto pressionando o botão **[RESET]** caso perca a senha.

LOGIN

Sempre que você acessar a câmera, a janela de logon é exibida. Insira o ID do usuário e a senha para acessar a câmera.

- 1 Digite "admin" na caixa de entrada <User Name>.
- 2 Digite a senha no campo de entrada <Password>
- 3 Clique em [Sign in].

CONEXÃO WIFI

Configuração da câmera

- 1 Ligue o adaptador OTG (5-pinos) e o dongle WiFi ao terminal Micro USB.

Configuração e Smartphone

- 1 Instale o aplicativo Wisenet Installation.
- 2 Selecione o SSID da câmera após ligar o WiFi.
- 3 Execute o aplicativo Wisenet Installation.
- 4 Quando você se conecta à câmera, o vídeo será ligado.
- 5 Você pode ajustar o ângulo de visualização vendo o vídeo através de seu smartphone.



microSD, microSDHC, and microSDXC Logos are trademarks of SD-3C LLC. microSD, microSDHC, microSDXC are trademarks or registered trademarks of SD-3C, LLC in the United States, other countries or both.



Подлежит использованию по назначению
в нормальных условиях
Срок службы : 7 лет.

Türkiye Distribütörü

EDS Elektronik Destek Sanayi ve Ticaret Ltd. Şti.

Meclis Mah. Teraziler Cad. Hayran Sk. (Eskisi Kılıç Sk.) No: 4 Sancaktepe / İstanbul / Türkiye
Tel +90.216.313.25.15

ENTES ELEKTRONİK CİHAZLAR İMALAT VE TİC. A.Ş.

Dudullu Org.San.Bölg. 1. Cad. No:23 34776 Ümraniye / İstanbul / Türkiye
Tel +90.216.313.01.10

TEKNOMAKS TEKNOLOJİ / TEKNOMAKS BİLİSİM

MERDİVENKÖY MAH.DİKYOL SOK. BUSINESS İSTANBUL No:2, Kat:7, D:B67, 34732 Kadıköy / İstanbul / Türkiye
Tel +90.212.217.54.22

Cihazın Ticaret Bakanlığına önerilen ortalama ömrü
Cihazın EEE yönetmeliklerine uygun olduğuna benzer beyan

